

BNI PNT-538-105-Z063 IP67 Module User's Guide






Table of Contents

| | | |
|----------|-------------------------------------|-----------|
| 1 | General | 4 |
| 1.1. | Structure of the guide | 4 |
| 1.2. | Typographical Conventions | 4 |
| | Enumerations | 4 |
| | Actions | 4 |
| | Syntax | 4 |
| | Cross-references | 4 |
| 1.3. | Symbols | 4 |
| 1.4. | Abbreviations | 4 |
| 1.5. | Deviating views | 4 |
| 2 | Safety | 5 |
| 2.1. | Intended use | 5 |
| 2.2. | Installation and Startup | 5 |
| 2.3. | General Safety Notes | 5 |
| 2.4. | Resistance to Aggressive Substances | 5 |
| | Dangerous Voltage | 5 |
| 3 | First Steps | 6 |
| 3.1. | Module overview | 6 |
| 3.2. | Mechanical Connection | 7 |
| 3.3. | Electrical Connection | 7 |
| | Power supply | 7 |
| | Grounding | 7 |
| | PROFINET interface | 7 |
| | IO-Link Port | 8 |
| | Port | 8 |
| 4 | Technical Data | 9 |
| 4.1. | Dimensions | 9 |
| 4.2. | Mechanical Data | 9 |
| 4.3. | Operating conditions | 9 |
| 4.4. | Electrical Data | 9 |
| 4.5. | PROFINET | 10 |
| 4.6. | Function indicators | 10 |
| | Module Status | 10 |
| | Port | 11 |
| 5 | Integration | 12 |
| 5.1. | Configuration | 12 |
| | GSDML file | 12 |
| | Integration of the module | 12 |
| | Parameterizing the header module | 13 |
| | Hardware configuration | 14 |
| | IO-Link configuration | 15 |
| | IO-Link functions | 15 |
| | Cycle Settings | 15 |
| | Data selection | 15 |
| | Validation | 15 |
| | Device name, Profinet address | 16 |
| | Establishing device relationship | 17 |
| | Assigning device name | 17 |
| | Concluding the configuration | 18 |
| 5.2. | Functions in module properties | 19 |
| | Module settings | 19 |
| | Port functions | 19 |
| | Safe state | 19 |
| 5.3. | Bit mapping and function | 20 |
| | Inputs pin 4 | 20 |

| | |
|---|-----------|
| Inputs pin 2 | 20 |
| Outputs pin 4 | 20 |
| Outputs pin 2 | 20 |
| IO-Link modules | 20 |
| Actuator shutdown Pin 4 / Pin 2 | 20 |
| Actuator warning Pin 4 / Pin 2 | 20 |
| Restart Pin 4 / Pin 2 | 20 |
| Switching IO-Link diagnostics on / off | 21 |
| IO-Link communication | 21 |
| Peripheral error, socket | 21 |
| Sensor supply | 21 |
| Short circuit | 21 |
| Station diagnostics | 21 |
| IO-Link PD Valid | 21 |
| Parameter server | 22 |
| 6 Configuration of IO-Link devices | 23 |
| General | 23 |
| Function module | 23 |
| Read | 23 |
| Write | 23 |
| 7 Monitoring & Diagnosis | 24 |
| 7.1. General | 24 |
| 7.2. SNMP MIBs | 24 |
| 8 Display | 26 |
| 8.1. General | 26 |
| 8.2. Control and Display | 26 |
| 8.3. Display Information | 27 |
| 8.4. Design and Symbols | 27 |
| 8.5. Startup | 27 |
| 8.6. Main Menu | 27 |
| 8.7. Factory Reset | 28 |
| 8.8. Module information | 28 |
| 9 Web Server | 29 |
| 9.1. General information | 29 |
| 9.2. Navigation / Info | 30 |
| 9.3. Login/Logout | 31 |
| 9.4. "Home" dialog | 32 |
| 9.5. "Ports" dialog | 34 |
| No appropriate IODD uploaded | 34 |
| Appropriate IODD uploaded | 35 |
| 9.6. "IODD" Dialog | 37 |
| 9.7. "Config" dialog | 38 |
| 9.8. "Log" dialog | 40 |
| 10 Diagnostics | 42 |
| 10.1. Diagnostics message | 42 |
| 10.2. Block Header | 43 |
| Block Type | 43 |
| Block Length | 43 |
| Block Version High | 43 |
| Block Version Low | 43 |
| Alarm Type | 43 |
| API | 43 |
| Slot | 43 |
| Subslot | 44 |
| Module ID | 44 |
| Submodule ID | 44 |
| 10.3. AlarmSpecifier | 45 |
| Sequence Number | 45 |
| Channel Diagnostic | 45 |
| Manufacturer Specific Diagnosis | 45 |
| Submodule | 45 |

| | |
|--|-----------|
| Diagnostic State | 45 |
| ARDiagnosis State | 45 |
| User Structure Ident | 45 |
| 10.4. Channel Number | 46 |
| 10.5. Channel Properties | 47 |
| Type | 47 |
| Accumulative | 47 |
| Maintenance | 47 |
| Specifier | 47 |
| Direction | 47 |
| 10.6. Channel Error Type | 48 |
| 11 Use in safety applications | 49 |
| 11.1. Product description | 49 |
| 11.2. Safety function | 49 |
| 11.3. Example of an application description | 50 |
| 11.4. Inspections | 51 |
| 12 Appendix | 52 |
| 12.1. Scope of Delivery | 52 |
| 12.2. Order number | 52 |
| 12.3. Ordering information | 52 |

1 General

- 1.1. Structure of the guide** This guide is arranged so that one chapter builds upon the other.
Chapter 1: General
Chapter 2: Basic safety instructions
.....
- 1.2. Typographical Conventions** The following typographical conventions are used in this manual.
- Enumerations** Enumeration is shown in the form of bulleted lists.
- Entry 1
 - Entry 2
- Actions** Action instructions are indicated by a preceding triangle. The result of an action is indicated by an arrow.
- Action instruction 1
 - ↗ Result of action
 - Action instruction 2
- Actions can also be indicated as numbers in parentheses.
- (1) Step 1
 - (2) Step 2
 - (3)
- Syntax** Numbers:
Decimal numbers are shown without additional information (e.g. 123),
Hexadecimal numbers are shown with the additional indicator hex (e.g., 00_{hex}) or the prefix "0x" (e.g., 0x00).
- Cross-references** Cross-references indicate where additional information on the topic is located.
-
- 1.3. Symbols**
-  **Note**
This symbol indicates general notes.
-
-  **Attention!**
This symbol indicates a security notice which must be observed.
-
- 1.4. Abbreviations**
- | | |
|-----|-------------------------------|
| BNI | Balluff Network Interface |
| I | Standard input port |
| PNT | ProfiNet™ |
| EMC | Electromagnetic Compatibility |
| FE | Function earth |
| O | Standard output port |
| US | Sensor supply undervoltage |
| UA | Actuator supply undervoltage |
- 1.5. Deviating views** Product views and illustrations in this manual may differ from the actual product. They are intended only as illustrative material.

2 Safety

2.1. Intended use

The BNI PNT-... is a decentral IO-Link, input module for connecting to a ProfiNet™ network.

2.2. Installation and Startup



Attention!

Installation and startup are to be performed by trained technical personnel only. Skilled specialists are people who are familiar with the work such as installation and the operation of the product and have the necessary qualifications for these tasks. Any damage resulting from unauthorized tampering or improper use shall void warranty and liability claims against the manufacturer. The operator is responsible for ensuring that the valid safety and accident prevention regulations are observed in specific individual cases.

2.3. General Safety Notes

Commissioning and inspection

Before commissioning, carefully read the User's Guide.

The system must not be used in applications in which the safety of persons depends on the function of the device.

Intended use

Warranty and liability claims against the manufacturer shall be rendered void by damage from:

- Unauthorized tampering
- Improper use
- Use, installation or handling contrary to the instructions provided in this User's Guide.

Obligations of the owner/operator

The device is a piece of equipment in accordance with EMC Class A. This device can produce RF noise. The owner/operator must take appropriate precautionary measures against this for its use. The device may be used only with a power supply approved for this. Only approved cables may be connected.

Malfunctions

In the event of defects and device malfunctions that cannot be rectified, the device must be taken out of operation and protected against unauthorized use.

Approved use is ensured only when the housing is fully installed.

2.4. Resistance to Aggressive Substances



Attention!

The BNI modules always have good chemical and oil resistance. When used in aggressive media (such as chemicals, oils, lubricants and coolants, each in a high concentration (i.e. too little water content)), the material must first be checked for resistance in the particular application. No defect claims may be asserted in the event of a failure or damage to the BNI modules caused by such aggressive media.

Dangerous Voltage



Attention!

Before working on the device, switch off its power supply.



Note

In the interest of continuous improvement of the product, Balluff GmbH reserves the right to change the technical data of the product and the content of these instructions at any time without notice.

3.1. Module overview




Figure 1 – Overview BNI PNT-538-105-Z063

- | | | | |
|----|-----------------------------|----|---------------------|
| 1 | Mounting hole | 11 | Port 6 |
| 2 | PROFINET™ Port 2 | 12 | Port 4 |
| 3 | Display | 13 | Port 2 |
| 4 | Power supply, output | 14 | Port 0 |
| 5 | Status LED | 15 | Power supply, input |
| 6 | Port 1 | 16 | Information sign |
| 7 | Pin/port LED: signal status | 17 | PROFINET™ Port 1 |
| 8 | Port 3 | 18 | Function earth |
| 9 | Port 5 | | |
| 10 | Port 7 | | |

3 First Steps


3.2. Mechanical Connection

The module is secured by means of two M6 screws and two washers. Insulation support is available separately.

3.3. Electrical Connection


Power supply

Voltage supply IN, M12 T-coded, 4 Pin, male connector



| Pin | Function | Description |
|-----|-----------------------------|-------------|
| 1 | Module / sensor supply | +24 V |
| 2 | Separate voltage supply (-) | N24 |
| 3 | GND module / sensor supply | 0 V |
| 4 | Separate voltage supply (+) | P24 |

Voltage supply OUT, M12 T-coded, 4 Pin, female connector




| Pin | Function | Description |
|-----|-----------------------------|-------------|
| 1 | Module / sensor supply | +24 V |
| 2 | Separate voltage supply (-) | N24 |
| 3 | GND module / sensor supply | 0 V |
| 4 | Separate voltage supply (+) | P24 |

Note



Where possible, use separate power supplies for sensor/bus and actuator. Total current < 12 A The total current of all modules must not exceed 12 A even in the case of series connection of the actuator supply.

Grounding




Note

The functional ground connection between housing and machine must have a low impedance and be as short as possible.

PROFINET interface

M12, D-coded, female



| Pin | Function | |
|-----|----------|-----------------|
| 1 | Tx+ | Transmit Data + |
| 2 | Rx+ | Receive Data + |
| 3 | Tx- | Transmit Data - |
| 4 | Rx- | Receive Data - |




Note

Unused I/O ports must be provided with cover caps to comply with degree of protection IP67.

3 First Steps

IO-Link Port

M12, A-coded, female



| Pin | Function | |
|-----|--------------------------|-----------------|
| | Class A | Class B |
| 1 | +24 V, 1.6 A | +24 V, 1.6 A |
| 2 | Input/ Output 2A | P24 |
| 3 | GND | GND |
| 4 | Input / Output / IO-Link | Input / IO-Link |
| 5 | n.a. | N24 |



Note

For the digital sensor inputs, refer to guideline on inputs EN61131-2, Type 3.



Note

All outputs are powered via the sensor power supply.



Note

Unused ports must be provided with cover caps in order to ensure enclosure rating IP67.



Attention!


If the power supply UA is disabled, the Class A outputs (port 0 to port 3) are also switched off.

Port

| | Port | |
|----------------------|---------|---------|
| | 0-3 | 4-7 |
| BNI PNT-538-105-Z063 | Class A | Class B |

4 Technical Data

4.1. Dimensions



4.2. Mechanical Data

| | |
|--------------------------------|---|
| Housing material | Die-cast zinc, matte nickel-plated |
| Enclosure rating per IEC 60529 | IP 67 (only in plugged-in and screwed-down state) |
| Supply voltage | M12-T-coded, connector male / female |
| Input ports / output ports | M12, A-coded (8x female) |
| Dimensions (W x H x D in mm) | 68 x 224 x 31.7 |
| Type of mounting | Screw mounting with 2 mounting holes |
| Ground strap installation | M4 |
| Weight | Approx. 670 g |

4.3. Operating conditions

| | |
|---------------------|----------------|
| Ambient temperature | -5°C ... 70°C |
| Storage temperature | -25°C ... 70°C |


4.4. Electrical Data

| | |
|--------------------------------------|---|
| Supply voltage | 18...30.2 V DC, in accordance with EN 61131-2 |
| Ripple | < 1% |
| No-load current consumption for 24 V | 160 mA |
| Output current | 2 A |

4.5. PROFINET

| | |
|---|---|
| PROFINET port | 100Base-Tx |
| Connection for PROFINET port | M12, D-coded, female |
| Cable types in accordance with IEEE 802.3 | Shielded, twisted pair min. STP CAT 5/ STP CAT 5e |
| Data transmission rate | 100 Mbps |
| Max. cable length | 100 m |
| Flow control | Full-duplex (IEEE 802.3x pause) |
| Profinet Conformance Class | B |
| Net Load Class | 3 |

4.6. Function indicators



Module Status

| LED | Indicator | Function |
|-----|---------------|--|
| US | Green | Input voltage OK |
| | Red, flashing | Input voltage low (< 18 V) |
| UA | Green | Output voltage OK |
| | Red | Output voltage low (< 18 V) |
| SF | Off | No error |
| | Red | Watchdog timeout; channel, general or advanced diagnosis present; system error |
| | Red, flashing | Service DCP signal started via bus |
| BF | Off | No error |
| | Red | Low speed of physical link; or no physical link |
| | Red, flashing | No data exchange or no configuration |
| 100 | Off | Transmission rate: 10 Mbit/s |
| | Yellow | Transmission rate: 100 Mbit/s |
| LK | Green | Data transfer |
| | Red | Grounds interchanged |

4 Technical Data

Port

Standard port

| Status | Function |
|------------------------|---|
| Off | Status of Input Pin is 0 |
| Yellow | Status of Input Pin is 1 |
| Both LEDs flashing red | Sensor power supply short circuit between Pin 1 and Pin 3 |
| Red | Short circuit at the output on Pin 2 / 4 to Pin 3 |
| Red | No high signal at diagnostic input |

IO-Link port

| Status | Function |
|------------------------|--|
| Green | IO-Link – connection active |
| Green, flashing | No IO-Link – connection or wrong IO-Link device |
| Flashing green rapidly | IO-Link pre-operate during data storage |
| Flashing red rapidly | Validation failed / incorrect configuration of the IO-Link data length |
| Flashing red rapidly | Data storage failed / incorrect device for data storage |
| Red | IO-Link short circuit Pin 4 to Pin 3 |

5 Integration

5.1. Configuration

When planning Profibus devices, a device is depicted as a modular system with a header module and several data modules. The screenshots shown here have been taken from the configuration software of the Siemens HW config.


GSDML file

The device data required for project planning is saved in GSDML files (**Generic Station Description Markup Language**). The GSDML files are available in two languages as an Internet download (www.balluff.com). The data modules of an IO-Link block are displayed in the project planning software according to the slot.

The GSDML file makes the possible data modules available (input or output of different data ranges). For configuration of the IO-Link blocks, the corresponding data modules are assigned to a slot.

Integration of the module

The device can be found by searching in the catalog and inserted in the Profinet section by drag & drop.



The BNIPNT538105Z063 module with submodules PN-IO, port 1-M12, port 2-M12 are used for Profinet communication.

In X1 PN-IO, functions such as prioritized run-up or the domains for the ring topology can be selected.

The port function (input, output, diagnosis input) or diagnosis messages can be defined at Slot 0.


The remaining slots (2-5) pre-assigned in the default configuration are placeholders for the IO-Link modules. Slot 2 is for the first IO-Link port / standard I/O port Slot 5 for the last.

If IO-Link communication is planned for a given port, the standard I/O module must be deleted and replaced with an IO-Link module, e.g., IOL_E_2byte.

5 Integration

Parameterizing the header module

Double-click on the header module to open its properties. Click on the "Parameter" tab to open a menu selection for defining the port functions and diagnostic functions.



Note IO-Link configuration:



If the connected IO-Link device makes outputs available, Pin 2 must be configured to output on the corresponding port.

Standard input and output:

For each port, the function (N.C., N.O., diagnostic input (pin 2)) can be arbitrarily selected for each port at pin 2 and pin 4.

Hardware configuration

The IO-Link / standard I/O modules must now be configured appropriately for the configuration of the header module.

If necessary, these can be taken over into the configuration table from the hardware catalog by means of drag & drop.

By default, all ports are set to Standard I/O.

If the port is to be configured as an IO-Link port, the module must be deleted and replaced with an IO-Link module.

Slots 1..8 are reserved for the IO-Link ports/standard I/O ports.

Module addressing:

Double-click on the IO-Link modules and the remaining addressable modules to change the addressing in the "Addresses" window.

Configuring the IO-Link module:

A suitable IO-Link module that corresponds to the process data length of the IO-Link device must be selected in the catalog and dragged to the appropriate slot by means of drag & drop.


The process data length required by the device in each case can be obtained from the manual of the IO-Link device.

Configuring a standard input / output:

If one of the possible port pins (pin 4) is to be configured with a standard function (input, output), the "Standard I/O" placeholder module must be used for the corresponding slot. To address the inputs and outputs, input pin 2 / 4 and output 2 / 4 must be taken over from the catalog and used in the configuration according to the given modules.

For the SIO function, integrate the "IO-Link input with SIO mode" module.


With the remaining modules, the various functions are mapped into the process data areas.



5 Integration

IO-Link configuration

The IO-Link parameters of the respective port can be changed in the IO-Link module properties.



IO-Link functions

Explanation of the possible settings in the properties of the IO-Link port.

Cycle Settings

Use this parameter to reduce the IO-Link communication speed by increasing the IO-Link cycle time. The cycle time can be adjusted via the scroll down menu.

Data selection

The start byte of the process data can be defined with the data section offset. For the max. input data length, the actual process data length of the IO-Link device is entered. These settings are only for the input data. The visible data window for the input data can now be adjusted via an IO-Link module with appropriate process data length.

Validation


No validation: validation deactivated, every device is accepted
Compatibility: manufacturer ID and device ID are compared to the module data. The IO-Link communication is only started if there is a match. Manufacturer ID and device ID are entered in decimal format.
Identity: manufacturer ID and device ID and serial number are compared to the module data. The IO-Link communication is only started if there is a match. Manufacturer ID and device ID are entered in decimal format, the serial number is entered in ASCII code.

5 Integration

Device name, Profinet address

Double-click on the module in the Profinet line to view the communication parameters of the module.


The device name and the Profinet address (IP) are configured here.



5 Integration

Establishing device relationship


"Device view" → right click on module → "Assign device name".



Assigning device name

Select the desired name and use "Assign name" to assign the marked device that you found. The device name must be the same as that previously configured under device properties (see previous page).

Identification takes place via the MAC address (on the rear of the device) or via the Blink Test.



Concluding the configuration

Download the configuration into HW config.

At this point, the bus error on the module should disappear.
There could still be an active system error, particularly if an IO-Link is used.

Possible causes:

- Line break (no IO-Link device connected)
- IO-Link device fault (e.g., external voltage supply not connected)
- Validation failed

If the module still reports a bus error, there could be a problem in one of the following areas:

- Device relationship not established.
Scan the network and check whether the device is signaling under the correct device name and correct IP address.
Adapt the Ethernet address or device name if necessary, assign the device name to the device once again and download the configuration.

5 Integration

5.2. Functions in module properties

Description of the functions in module properties

Module settings

Global diagnostics:

This function can be used to permit / suppress all diagnostics messages of the module. (optical diagnostics signals and diagnostics in configured diagnostics modules are not affected)

Sensor supply undervoltage:

This function can be used to permit / suppress the diagnostics message Sensor supply undervoltage. (optical diagnostics and diagnostics in configured diagnostics modules are not affected)

Actuator supply undervoltage:

This function can be used to permit / suppress the diagnostics message Actuator supply undervoltage. (optical diagnostics signals and diagnostics in configured diagnostics modules are not affected)

Sensor short circuit at output:

This function is used to permit/suppress the sensor short circuit diagnostics message at the module output. (Optical diagnosis and diagnosis in configured diagnosis modules is not affected). Function only applies to channels/pins that are configured as outputs. Channels/pins configured as inputs are not affected.

Port functions

The function for every individual port pin can be defined here:

Make contact = input as normally open contact

Break contact = input as normally closed contact

Output = output function

IO-Link input with SIO mode = SIO mode; An IO-Link device can be parameterized via IO-Link and then set to a SIO mode in which the IO-Link port pin functions as a simple switch input Pin function depending on configuration.

Safe state

This function is a supplement to an output configuration of the respective port pin.

For each port pin, a safe status can be predefined which is assumed in the event of a failure in bus communication.

5.3. Bit mapping and function

Bit mapping and function of the configurable modules

**Inputs pin 4
Inputs pin 2
Outputs pin 4
Outputs pin 2**

Signal from configured inputs or outputs are depicted in the modules inputs pin 4 / inputs pin 2 and outputs pin 4, outputs pin 2.

The "inputs pin 2" module also depicts the diagnostic inputs of the diagnostic input function. Depending on configuration.

IO-Link modules

The IO-Link modules always have the same structure:

IOL_I/O_x/xBytes

Number of process data items used (should be equal to or greater than the process data length of the IO-Link device)
I = Input data
O = Output data
I/O = Both input and output data

Actuator shutdown Pin 4 / Pin 2

Depicts a short circuit between a set output to ground at the respective port pin.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| Port 7 | Port 6 | Port 5 | Port 4 | Port 3 | Port 2 | Port 1 | Port 0 |

Actuator warning Pin 4 / Pin 2

Feedback if a voltage is being supplied at an output that is not set.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| Port 7 | Port 6 | Port 5 | Port 4 | Port 3 | Port 2 | Port 1 | Port 0 |

Restart Pin 4 / Pin 2

If this function is configured, after an actuator short-circuit there is no automatic restart, but rather the port must be activated by inserting the corresponding bit.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| Port 7 | Port 6 | Port 5 | Port 4 | Port 3 | Port 2 | Port 1 | Port 0 |

5 Integration

Switching IO-Link diagnostics on / off

If this function is configured, the IO-Link diagnostics is deactivated for all ports and can be reactivated for the desired ports.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| Port 7 | Port 6 | Port 5 | Port 4 | Port 3 | Port 2 | Port 1 | Port 0 |

IO-Link communication

Bit status for each IO-Link port; feedback indicating whether communication is established.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| Port 7 | Port 6 | Port 5 | Port 4 | Port 3 | Port 2 | Port 1 | Port 0 |

Peripheral error, socket

Feedback indicating the port at which an error occurred.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| Port 7 | Port 6 | Port 5 | Port 4 | Port 3 | Port 2 | Port 1 | Port 0 |

Sensor supply Short circuit

Feedback indicating the port at which there is a sensor supply short circuit.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| Port 7 | Port 6 | Port 5 | Port 4 | Port 3 | Port 2 | Port 1 | Port 0 |

Station diagnostics

Feedback indicating which fault occurred.

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------------------|------------------|------------------------|------------------------------|----------------|-------|-------------|-----------|
| IO-Link short circuit | Actuator Warning | Actuator Short circuit | Sensor voltage Short circuit | External error | No UA | US actuator | US sensor |

IO-Link PD Valid

| Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| Port 7 | Port 6 | Port 5 | Port 4 | Port 3 | Port 2 | Port 1 | Port 0 |

Parameter server

Switched off:

data management functions disabled, saved data are retained.

Delete:

data management functions disabled, saved data are deleted.

Restore:

Only a parameter data download to the IO-Link device is performed.

As soon as the saved parameter data in the port parameter differ from the connected IO-Link device, a download is performed.

Sole exception: The parameter server is empty. A one-off upload is then performed.

Save/restore:

A parameter data up- and download to the IO-Link device is performed.

As soon as the saved parameter data in the port parameter differ from the connected IO-Link device and there are no upload requirements from the IO-Link device, a download is performed.

As soon as a device requests an upload (upload flag set) or if no data are saved in the master port (e.g. after data deletion or before the first data upload) the master launches an upload of the parameter data from the device.

Note

After the upload of the parameter data, the vendor ID and device ID of the connected IO-Link device are also still saved until the data records are deleted. When the connected IO-Link device is started, a validation takes place. Thus, only an IO-Link device of the same type can be used for the data management.

6 Configuration of IO-Link devices

General IO-Link devices can be configured via the web server, function modules and the IO-Link device tool.

When using the device tool and web server, the write and read accesses are adopted by the software.

Function module The "IOL_Call" function module creates a telegram, which is sent to the master via DPV1 functions. The following settings are required in this case:

| | |
|-------------------|---|
| Diagnosis address | The diagnosis address of Slot 1 is used |
| CAP access | 255 |

The sample project with the IO_Call function module from Siemens AG can be downloaded on the Balluff homepage.

The telegram structure is described in the following table:

| Area | Size in bytes | Value | Definition |
|----------------|---------------|-------------------------|---|
| Call header | 1 | 08h | 08h for "CALL", fixed |
| | 1 | 0 1...63 64...255 | IOL master Port number Reserved |
| | 2 | 65098 | FI_Index, IO-Link header is following |
| IO-Link header | 1 | 0...255 | Task 2 = write 3 = read |
| | 2 | 0...3276 7 65535 | IO-Link index Port function |
| | 1 | 0...255 | IO-Link subindex |
| Data range | 232 | | Range of the data to be written or read |

Read To read out data, the master must be given a reading task for the corresponding slot/index/subindex.

The telegram must be adapted accordingly for this purpose (slot, index), and 0x03 for reading must be entered under "Task".
The telegram can then be sent by write instruction to the corresponding module.

The module reads the data from the IO-Link device.
The data can be retrieved by reading with the same telegram.

Write To write data, the master must be given a writing task for the corresponding slot/index/subindex.

The telegram must be adapted accordingly for this purpose (slot, index), and 0x02 for writing must be entered under "Task".
The telegram can then be sent by write instruction to the corresponding module.

7.1. General

The field bus module offers several diagnosis interfaces, which are described below:

- Device diagnosis via the web interface
- Network diagnosis via SNMP
- Field bus-specific diagnosis via the PLC

The web interface and field bus-specific diagnosis interfaces are respectively described in a separate chapter.

Access to the device monitoring and diagnosis interfaces is performed via the IP-based management interface over the Ethernet network. As an alternative to the procedure described in the "Integration" chapter, the necessary setting of the IP access can be performed by means of other dedicated configuration tools using the PROFINET DCP protocol. The following parameters must be set for this purpose:

- IP address (IP)
- Subnet mask (SN)
- Gateway address (GW)
- Device name

The configuration settings can be reset to the default settings (delivery condition) via the web interface.

Configuration settings are only possible when the module has no active connection to a control unit.

7.2. SNMP MIBs

Device network interface monitoring and diagnosis can be performed over the network with the help of the SNMPv1 protocol. Access to the latter is easy via a so-called SNMP browser or common network management applications.

The following MIBs are supported:

- MIB-2 (RFC 1213)
- LLDP-MIB (IEEE 802.1AB)

Field bus module information is supplied in the MIB-2 module-related information:

| MIB Variable | Description |
|--------------------|--|
| sysDescr | A textual description of the entity. This value should include the full name and version identification of the system's hardware type, software operating-system, and networking software. |
| sysObjectID | {1.3.6.1.4.1.44233.1.2.1} For Balluff products with Product enterprise Number (PEN) = 44233, the product list is defined in BALLUFF-PRODUCTS-MIB |
| sysUpTime | The time (in hundredths of a second) since the network management portion of the system was last re-initialized. |
| sysContact | The textual identification of the contact person for this managed node, together with information on how to contact this person. ("BALLUFF") |
| sysName | An administratively-assigned name for this managed node. By convention, this is the node's fully-qualified domain name. ("BNI PNT") |
| sysLocation | The physical location of this node (e.g. "73765 Neuhausen a.d.F, Germany") |

7 Monitoring & Diagnosis

The MIB-2 port-related information diagnosis data on the network connections, including the IO-Link ports, is displayed:

| MIB Variable | Ethernet port | IO-Link Port |
|----------------------|---|---|
| ifIndex | A unique value, contiguously starting from 1. | |
| ifDescr | A textual string containing information about the interface, i.e. "Ethernet X" | "IO-Link X" / "IO-IN X" / "IO-OUT X" |
| ifType | IANAifType = 6 (ethernetCsmaCd) when Ethernet | IANAifType = 280 (sdci) when IO-Link-Port = 0 (other) when I/O-Port |
| ifMTU | length of Ethernet MTU | length of IO-Link process data (typically max. 32 Byte) or 1, when IO-port |
| ifSpeed | actual Ethernet speed | IO-Link speed (no device = 0 bit/s, Com1 Mode = 4800 bit/s, Com2 Mode 38400 bit/s, Com3 Mode = 230400 bit/s) |
| ifPhysAddress | MAC address assigned to this port | This object may contain an octet string of zero length, since IO-Link is a serial P2P protocol with no specific addressing. |
| ifAdminStatus | Up(1), Down(2), depending | Up(1), Down(2), depending if IO-Link capability is configured. |
| ifOperStatus | Up(1), Down(2), depending if an IO-Link device is connected and operable. | |
| ifLastChange | The value of sysUpTime at the time the interface entered its current operational state. If the current state was entered prior to the last re-initialization of the local network management subsystem, then this object contains a zero value. | n/a |
| ifInOctets | The total number of octets received on the interface, including framing characters. | |
| ifInErrors | n/a | Number of received frames that were rejected as invalid by the IO-Link-Master (Abort). |
| ifOutOctets | The total number of octets transmitted out of the interface, including framing characters. | |
| ifOutErrors | n/a | Number of retries by the IO-Link-Master, indicating unsuccessful packet transmissions. |

8.1. General

The display of the BNI IOF-538-105--Z063 consists of two LEDs, two keys and a LCD display. Background illumination is built-in to ensure readability even under weak ambient light. Background illumination is also activated as soon as the menu is started. The station name can be displayed. In delivery condition "no name" is displayed. This means that the module has not yet been assigned a name. The IP settings are represented by the following points and reflect the current module configuration.


- IP address (IP)
- Subnet mask (SN)
- Gateway address (GW)

Every address consists of four octets.

In addition, the display shows information about the device name, hardware and software version and MAC ID.

The address settings can also be reset to the default settings via the display.

8.2. Control and Display



- | | |
|----------------|-----------------------|
| 1 Display | 4 Address type cursor |
| 2 Arrow key | 5 Set button |
| 3 Octet cursor | 6 LEDs |

Arrow key: This key is used to scroll through the menu entries and is a short-time pushbutton. The display shows the standard screen after 10 seconds of inactivity.

Octet cursor: The octet cursor default position is Position 0, equivalent to the lowest-value octet.

Address type cursor: The address type cursor default setting is the IP position.


Set key: This key is used to launch edit mode and save or confirm a configuration.

LEDs: The two LEDs can be controlled via the module process data.

The "Display LEDs" module must be selected for this purpose.


8 Display

8.3. Display Information




8.4. Design and Symbols


In the following flow charts, some symbols are used to describe the display functions:



8.5. Startup




8.6. Main Menu



- Press the Set key briefly to scroll through the main menu.
- Press the arrow key to open the menu.

8.7. Factory Reset




- Press the arrow key briefly to access the "Network Config" menu.
- Hold down the S-key at the "Factory Reset" entry to reset the module.
- The arrow key need only be pressed briefly to reject the reset.
- Press the S-key again briefly to confirm the reset. The module reboots automatically after the reset.



Note

A factory reset can only be performed after a voltage reset with a connected network cable.

8.8. Module information



- Press the arrow key briefly to scroll through the "Module information" menu.
- The product name, module updates and Mac-ID are displayed as information.


9 Web Server

9.1. General information

The BNI fieldbus module contains an integrated web server for retrieving detailed device information and for configuring the device.

To use the web interface you must first ensure that the module has been correctly integrated into your network. In addition the IP subnet of the BNI module must be accessible from the PC on which the browser is running. For the supported web browsers, please refer to the corresponding data sheet.

For open a connection with the web server, enter the IP address of the module in the address line of the browser. The homepage then appears with the essential device information.



The screenshot displays the web interface for the Balluff BNI PNT-508-105-Z015 module. The interface includes a navigation bar with icons for Home, Ports, TODD, Login, Config, Log, and Info. The main content area is titled "Module Information" and lists the following details:


| | |
|--------------------|----------------------|
| Product Name: | BNI PNT-508-105-Z015 |
| Order Code: | BNI005H |
| Name: | unknown name |
| Location: | unknown location |
| Contact: | unknown contact |
| Firmware Revision: | 3.2 |
| Hardware Revision: | 6 |
| Station name: | mydevice |
| IP Address: | 192.168.0.3 |
| Subnet Mask: | 255.255.255.0 |
| Gateway Address: | 0.0.0.0 |
| MAC Address: | 00:19:31:3F:FF:32 |
| Link Speed Port 1: | 100 Mbit/s FULL |
| Link Speed Port 2: | No Link |
| PLC Lock: | No |

To the right of the text is a photograph of the physical module, which features four RJ45 ports and two green LEDs at the top. Below the image is a link labeled "> LED Legend".

9.2. Navigation / Info

The navigation bar is located in the upper area of the window, which allows you to switch between the various dialogs of the web interface. To do this click on the corresponding icon.

When the "Info" tab is selected the following overview appears:



The "BALLUFF" logo at upper right links to the international Balluff homepage.


9.3. Login/Logout

To make configuration settings on the fieldbus module using the web interface, you must first log in. Functionalities which cannot be used without logging in are indicated by the grayed out buttons.


The default password is:

| | |
|----------------------|----------|
| BNI PNT-XXX-XXX-XXXX | "BNIPNT" |
| BNI EIP-XXX-XXX-XXXX | "BNIEIP" |
| BNI ECT-XXX-XXX-XXXX | "BNIECT" |

The password cannot be changed!



After successfully logging in the dialogs are shown as follows:



Use the "Logout" button to log out again. After 5 minutes of no interaction with the Webserver the user is automatically logged out.



Note


For security reasons the fieldbus module shows only one login at a time with configuration access. Reading (without logging in) is however possible from multiple PCs at the same time on the fieldbus module.

9.4. "Home" dialog

Under "Home" you are given the essential information about the fieldbus itself and its network activity. You are also shown whether the configuration block was enabled by the controller (PLC).

Information is also shown about the current process data and the status of the module via the corresponding LEDs. After selecting "LED Legend" a Help dialog appears which explains the meaning of the LEDs.

If an IO-Link device is connected to one of the configured IO-Link terminals, some of the device data will be displayed in addition to the module data in the form of a link. After selecting one of these links the corresponding device dialog is opened.



9 Web Server

PNT:

Module LED Functions

| LED | Green | Red | Yellow |
|-----|---------------|---------------------|--------|
| US | OK | Low | |
| UA | OK | Low | Error |
| SF | No link | Link signal service | |
| BF | No Link | No data exchange | |
| 100 | 100 Mbit/s | 10 Mbit/s | |
| LK | Link activity | No link activity | |

Port LED Functions

| IO | 0 | 1 |
|---------|---------|---------|
| IO-Link | IO-Link | IO-Link |
| IO-Link | IO-Link | IO-Link |
| IO-Link | IO-Link | IO-Link |

EIP:

Module LED Functions

| LED | Green | Red | Yellow |
|-----|---------------|------------------|---------------------|
| US | OK | Low | |
| UA | OK | Low | Error |
| Mod | No error | Config Error | |
| Net | No config | No data exchange | Connected / Timeout |
| 100 | 100 Mbit/s | 10 Mbit/s | |
| LK | Link activity | No link activity | |

Port LED Functions

| IO | 0 | 1 |
|---------|---------|---------|
| IO-Link | IO-Link | IO-Link |
| IO-Link | IO-Link | IO-Link |
| IO-Link | IO-Link | IO-Link |

9.5. "Ports" dialog

The "Ports" dialog displays information and process data for the connected IO-Link devices. Select the desired IO-Link Port in the image of the fieldbus module on the right side to see the device data.



Note

The IO-Link device data are only displayed if the port is also configured as an IO-Link port!

No appropriate IODD uploaded

It is possible to read and write the configuration parameters of the IO-Link device via the "Parameters" option. The parameter indexes and subindexes of the IO-Link device are described in the corresponding separate user's guide (and follow the IO-Link conventions).

Under "Events" you can see whether a diagnostic event from the IO-Link device exists.

Under "Parameter Server Content" you can view the content of the parameter server if parameter data is stored on the parameter server.

BALLUFF BNI PNT-508-105-Z015 Home Ports IODD Logout Config Log Info

IO-Link Device Properties (Port 0)

Identification Data

Vendor ID:
 Device ID: 0x050D20
 Vendor Name: BALLUFF
 Vendor Text: www.balluff.com
 Product Name: BNI IOL-302-002-Z046
 Product ID: BNI00AU
 Product Text: Sensor/Actor hub M8
 Serial Number: 7A 69 68 67 6A 68 73 6C 66 61 6A 6B F6 64 6C 75
 Hardware Revision: 1
 Firmware Revision: 1.0 2016/03/08 09:05:24 R2920
 Application specific tag:

Process Data

Inputs (hex): 20 00
 Outputs (hex): 00 00

Parameters

Index:
 Subindex:
 Data (hex):
 Result:
 Read Write

Events

Current Event: Secondary supply voltage fault (Port Class B) - Check tolerance

Parameter server content

Vendor ID (hex): 00 00
 Device ID (hex): 00 00 00
 Checksum (hex): 00 00 00 00
 Content (hex): (none)

"Ports" dialog with direct parameter access

9 Web Server

Appropriate IODD uploaded

If an IODD appropriate to the IO-Link device connected to the currently selected port has been uploaded (see "Dialog "IODD"), the normal dialog for "Process Data" and "Parameters" is not displayed, but rather an expanded dialog. Information from the IODD of the device is used so that the data can be better understood.

Thus in the following screenshot not only are the input data of the distance sensor displayed as a hex number, but also interpreted and labeled under "Input". Since the sensor has no parameters, none are displayed.

BALLUFF BNI PNT-508-105-Z015 Home Ports IODD Logout Config Log Info

IO-Link Device Properties (Port 2)

Identification Data

Vendor ID: 0x0378
 Device ID: 0x020101
 Vendor Name: BALLUFF
 Vendor Text: www.balluff.com
 Product Name: BAW M18MI-BLC50B-S04G
 Product ID: 153938
 Product Text: Inductive distance sensor, 1...5mm
 Serial Number:
 Hardware Revision: 1.00
 Firmware Revision: 1.01
 Application specific tag:

Process Data

Inputs (hex): 00 03 FF
 Outputs (hex): no outputs

Input

| | |
|-------------------|------|
| Distance absolute | 1023 |
| Reserved bits | 0 |

Events

Current Event: no Event

Parameter server content

Vendor ID (hex): 00 00
 Device ID (hex): 00 00 00
 Checksum (hex): 00 00 00 00
 Content (hex): (none)

Dialog "Ports": IODD interpretation and device image

If the IODD of the IO-Link device on the currently selected port has parameters, these are shown in table format (see following screenshot). In this example the parameters for the Balluff Smart Light are shown.

The Smart Light is a signal light which can be used in three different modes. These modes can be set using an IO-Link parameter. The parameter values and associated texts are stored in the IODD.

This means "Operation Mode" can be read out and displayed ("Read" and "Read All" buttons) or written to the device ("Write" button).

If subindexes have no buttons they cannot be individually processed but rather only the entire index at once.



Note

Each changed value must be individually written by clicking on the "Write" button!

| Parameters | | | Read All | |
|------------|------------------------------------|--|----------|------|
| 64 (0) | Operating mode (rw) | Segment mode ▾ | Write | Read |
| 65 (0) | Number of segments (rw) | One segment ▾ | Write | Read |
| 66 (0) | Type of level indicator (rw) | Bottom-up ▾ | Write | Read |
| 67 (0) | Resolution of level indicator (rw) | 8 bit ▾ | Write | Read |
| 68 (0) | Level mode, segment 1 (rw) | See child elements | | |
| 68 (1) | Level mode, segment 1 color | Off ▾ | Write | Read |
| 68 (2) | Level mode, segment 1 dominance | <input type="radio"/> Color is not dominant <input checked="" type="radio"/> Color is dominant | Write | Read |
| 69 (0) | Level mode, segment 2 (rw) | See child elements | | |
| 69 (1) | Level mode, segment 2 color | Off ▾ | Write | Read |
| 69 (2) | Level mode, segment 2 dominance | <input type="radio"/> Color is not dominant <input checked="" type="radio"/> Color is dominant | Write | Read |
| 70 (0) | Level mode, segment 3 (rw) | See child elements | | |
| 70 (1) | Level mode, segment 3 color | Off ▾ | Write | Read |
| 70 (2) | Level mode, segment 3 dominance | <input type="radio"/> Color is not dominant <input checked="" type="radio"/> Color is dominant | Write | Read |
| 71 (0) | Level mode, segment 4 (rw) | See child elements | | |
| 71 (1) | Level mode, segment 4 color | Off ▾ | Write | Read |
| 71 (2) | Level mode, segment 4 dominance | <input type="radio"/> Color is not dominant <input checked="" type="radio"/> Color is dominant | Write | Read |

"Ports" dialog: Parameter list of an IO-Link device with uploaded IODD

9.6. "IODD" Dialog

Using this dialog you can transfer IODDs (device description files for IO-Link devices) and the associated device images to the fieldbus module, so that a detailed representation of the connected IO-Link devices in the "Ports" dialog is possible.

When IO-Link devices are connected and IO-Link ports are activated, the dialog shows a table with information about the IO-Link devices.

The fieldbus module file system supports only device names in "8+3" format, i.e. with a restricted name length. Since IODD files are generally published with a long file name, these must be renamed and given a shorter naming scheme on the PC before uploading to the fieldbus module.

For this a help setting is provided in the dialog, with the associated required IODD file name for the currently connected IO-Link devices shown in the bottom section of the list (column IODD Filename).

Image files without IODD can also be uploaded; the images are still displayed in the "Ports" dialog.

IODD Management

| Device | Picture | |
|--------------|---------|--------|
| BA050A01.xml | X | Delete |
| BA020101.xml | X | Delete |
| BA050D20.xml | X | Delete |

Choose the IODD to upload:

Durchsuchen... BA020101.png

Upload

Information

This module has a FAT12 file system, which means it supports only file names in 8.3 convention. **Please rename your IODDs according to the suggested filename in the table below.**

The suggested filename is generated according to following rule:


- The first two characters of the file name are the first two letters of the IODD Vendor Name. If the device has no vendor name, those characters are substituted by underscores.
- The remaining 6 characters must encode the DeviceID in hexadecimal representation (padded with zeros if necessary).

Note that the filename must contain the DeviceID that is in the IODD file!

Currently connected IO - Link Devices:

| Vendor Name | Product Name | Product ID | Vendor ID | Device ID | IODD Filename |
|-------------|-----------------------|------------|-----------|-----------|---------------|
| BALLUFF | BNI IOL-302-002-Z046 | BNI00AU | 0000 | 050D20 | BA050D20.xml |
| BALLUFF | BNI IOL-802-000-Z036 | BNI0072 | 0378 | 050A01 | BA050A01.xml |
| BALLUFF | BAW M18MI-BLC50B-S04G | 153938 | 0378 | 020101 | BA020101.xml |

Use the "Delete" button to delete IODDs and device images from the field bus module as required.

Note
 Before selecting the IODD it must be renamed on the PC to the file name which is shown in the table in the "IODD Filename" column!

9.7. "Config" dialog

The configuration page enables configuration of the module. You can change both the module information texts and the port configuration. The "Set Ports" action is not permanently stored in the device and is lost after the next reboot or reset.

PNT / ECT:



EIP:

The screenshot displays the Balluff web interface for the BNI EIP-508-105-Z015 module. The interface is divided into two main sections: Module Configuration and Port Configuration.

Module Configuration:

- Name:** Balluff GmbH
- Location:** Schurwaldstraße 9
- Contact:** +49 (0) 7158 173
- IP Configuration:**
 - DHCP Client
 - Static IP
 - IP Address: 192.168.0.159
 - Subnet Mask: 255.255.255.0
 - Gateway Address: 192.168.0.1
 - Factory IP
 - IP Address: 192.168.1.1
 - Subnet Mask: 255.255.255.0
 - Gateway Address: 192.168.1.1

Port Configuration:

The Port Configuration section shows a central image of the module's port panel with 15 ports. Each port has a dropdown menu for its mode. The modes are: IO Link, Digital Input/Output, and Digital Input/Output.

Buttons:

- Save Configuration
- Reboot
- Factory Reset
- Set Ports

The parameter set "Module Configuration" on the left side is used by clicking "Save Configuration" and permanently stored in the device.

The "Reboot" button reboots the device as if the power to the module had been turned off and on again.

Clicking on "Factory Reset" deletes the configuration and log files saved in the device and then performs a reboot, so that the device is restored to the default factory configuration as on delivery.

9.8. "Log" dialog

This dialog provides general service information about the device as well as a logging function.

The upper table (see screenshot below) contains important information for all service inquiries.



Note

If you have a detailed question about a specific situation, send us a screenshot of this Web site or print the site as a PDF.

Logging shows events which have occurred in chronological order. This provides a tool for detailed troubleshooting in equipment.

BALLUFF
BNI PNT-508-105-Z015

Home
Ports
IODD
Logout
Config
Log
Info

Information

| | | | |
|--------------------|----------------------|-------------------|-------------------------|
| Product name: | BNI PNT-508-105-Z015 | Browser time: | 2016-12-16 10:26:29.495 |
| Firmware revision: | 3.2 | System uptime: | 50 secs 291 msecs |
| MAC address: | 00:19:31:3F:FF:02 | Free flash space: | 1720 KB |
| IP address: | 192.168.0.10 | Web version: | 2.0.113 |
| Browser version: | Firefox 50.0 | | |

Log

| No. | Severity | Date | Origin | Message |
|-----|---------------|-------------------------|------------|---|
| 0 | Notice | 2000-01-01 00:00:00.404 | SYS | System startup (Oct 6 2016, 11:54:01) |
| 1 | Notice | 2000-01-01 00:00:00.437 | SYS | Set MAC address: 00:19:31:3F:FF:02 |
| 2 | Notice | 2000-01-01 00:00:00.493 | IOL_MASTER | IO-Link Master started |
| 3 | Informational | 2000-01-01 00:00:00.501 | IOL_MASTER | FW version 1.2.8 |
| 4 | Notice | 2000-01-01 00:00:01.999 | ETH | Port 1: Link Up (100 MBit/s, full duplex) |
| 5 | Notice | 2000-01-01 00:00:37.926 | WEB_IF | Login successful, IP address: 192.168.0.50 |
| 6 | Error | 2000-01-01 00:00:41.902 | IOL_MASTER | Port 0: Device disconnected |
| 7 | Error | 2000-01-01 00:00:42.272 | IOL_MASTER | Port 1: Device disconnected |
| 8 | Error | 2000-01-01 00:00:42.981 | IOL_MASTER | Port 3: Device disconnected |
| 9 | Notice | 2000-01-01 00:00:43.169 | IOL_MASTER | Port 2: ISDU read error: Error code 80 Additional Code 11 |
| 10 | Notice | 2000-01-01 00:00:43.347 | IOL_MASTER | Port 2: ISDU read error: Error code 80 Additional Code 11 |
| 11 | Warning | 2000-01-01 00:00:43.347 | IOL_MASTER | Port 2: BNI IOL-101-S01-K018 connected |
| 12 | Notice | 2000-01-01 00:00:44.145 | IOL_MASTER | Port 4: ISDU read error: Error code 80 Additional Code 11 |
| 13 | Error | 2000-01-01 00:00:44.183 | IOL_MASTER | Port 5: Device disconnected |
| 14 | Warning | 2000-01-01 00:00:44.499 | IOL_MASTER | Port 4: BNI IOL-801-000-Z036 connected |
| 15 | Error | 2000-01-01 00:00:44.830 | IOL_MASTER | Port 6: Device disconnected |
| 16 | Error | 2000-01-01 00:00:45.200 | IOL_MASTER | Port 7: Device disconnected |

Events are classified using the "**Severity**" column:

Internal Error (Emergency, Alert, Critical)

→ The fieldbus module has detected a fault in itself (hardware or software) which should not occur during normal operation. If this happens, the module must be serviced or replaced.

External Error (Error, Warning)

→ The fieldbus module has detected what may be a non-permissible event which is affecting the module from the outside. The system may require troubleshooting.

Event (Informational, Notice)

The fieldbus module has detected an important normal operating event and reports it. These may include for example configuration actions over the web interface and other configuration interfaces which are also recorded.

Clicking on "Set Module Time" sends the current browser time to the fieldbus module but does not permanently store it. After a reset, reboot or loss of power the time begins to run again from the year 2000.

Clicking on "Update Log" refreshes the display, and "Clear Log" deletes all entries. The log entries are stored in a ring buffer.

10 Diagnostics

10.1. Diagnostics message

The diagnostics message that is generated by the module in the event of an error is usually read out by the PLC and processed. It is also possible to read out the diagnosis from the module by means of function modules and evaluate it.

The diagnostics message is 34 bytes long and divided into 3 blocks:
Block Header, Alarm Specifier, Channel Properties

| Byte | Value | Meaning | Block |
|------|-------|----------------------|-------------------|
| 0 | 00 | Block Type | BlockHeader |
| 1 | 02 | | |
| 2 | 00 | Block Length | |
| 3 | 1E | | |
| 4 | 01 | Block Version High | |
| 5 | 00 | Block Version Low | |
| 6 | 00 | Alarmtype | |
| 7 | 01 | | |
| 8 | 00 | API | |
| 9 | 00 | | |
| 10 | 00 | | |
| 11 | 00 | | |
| 12 | 00 | Slotnumber | |
| 13 | 01 | Subslotnumber | |
| 14 | 00 | | |
| 15 | 01 | Module Ident | |
| 16 | 00 | | |
| 17 | 00 | | |
| 18 | 00 | | |
| 19 | 17 | | |
| 20 | 00 | Submodule Ident | |
| 21 | 00 | | |
| 22 | 00 | | |
| 23 | 01 | | |
| 24 | A8 | AlarmSpecifier | AlarmSpecifier |
| 25 | 36 | | |
| 26 | 80 | User Structure Ident | |
| 27 | 00 | Channelnumber | |
| 28 | 00 | | |
| 29 | 08 | ChannelProperties | ChannelProperties |
| 30 | 08 | | |
| 31 | 00 | ChannelErrorType | |
| 32 | 00 | | |
| 33 | 1A | | |

10 Diagnostics

10.2. Block Header The first part of the diagnosis is the so-called Block Header, which is 24 bytes long.

Block Type The first 2 bytes of the Block Header are described by the Block Type to define the data type.

| Possible values | Meaning |
|-----------------|------------------------|
| 0x0002 | Alarm Notification Low |

Block Length 2 bytes of data that define the length of the following diagnostics message. (for the complete diagnostics message, the 2 bytes from the Block Type and the 2 bytes from the Block Length must be added).

Block Version High 1 byte, preset to 0x01

Block Version Low 1 byte, preset to 0x00

Alarm Type 2 bytes; the information on the type of alarm is provided here

| Possible values | Meaning |
|-----------------|-------------|
| 0x0001 | Diagnostics |

API 4 bytes, default is 0.

| Possible values | Meaning |
|-----------------|---------------|
| 0x00000000 | Default value |

Slot 2 bytes of data that describe which slot of the module reports an error

BNI PNT-538-105-Z063

| Possible values | Meaning |
|-----------------|----------------------------------|
| 0x0001 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0002 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0003 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0004 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0005 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0006 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0007 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0008 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0009 | Slot 1 - 8 (IO-Link Ports 0 - 7) |
| 0x0010 | Slot 9-24 (Standard IO Modules) |
| 0x0011 | Slot 9-24 (Standard IO Modules) |
| 0x0012 | Slot 9-24 (Standard IO Modules) |
| 0x0013 | Slot 9-24 (Standard IO Modules) |
| 0x0014 | Slot 9-24 (Standard IO Modules) |
| 0x0015 | Slot 9-24 (Standard IO Modules) |
| 0x0016 | Slot 9-24 (Standard IO Modules) |
| 0x0017 | Slot 9-24 (Standard IO Modules) |
| 0x0018 | Slot 9-24 (Standard IO Modules) |

10 Diagnostics

Subslot 2 bytes of data that describe which subslot of the slot reports an error

| Possible values | Meaning |
|-----------------|-----------|
| 0x0001 | Subslot 1 |

Module ID 4 bytes of data that describe which module is inserted in the respective slot.
(The module ID is saved in the GSDML)

| Possible values | Meaning |
|-----------------|------------------|
| 0x00000025 | IOL IN 1 OUT 0 |
| 0x00000026 | IOL IN 2 OUT 0 |
| 0x0000003A | IOL IN 4 OUT 0 |
| 0x0000003B | IOL IN 6 OUT 0 |
| 0x00000027 | IOL IN 8 OUT 0 |
| 0x00000035 | IOL IN 10 OUT 0 |
| 0x00000037 | IOL IN 16 OUT 0 |
| 0x0000003C | IOL IN 24 OUT 0 |
| 0x00000028 | IOL IN 32 OUT 0 |
| 0x00000029 | IOL IN 0 OUT 1 |
| 0x0000002A | IOL IN 0 OUT 2 |
| 0x0000003D | IOL IN 0 OUT 4 |
| 0x0000003E | IOL IN 0 OUT 6 |
| 0x0000002B | IOL IN 0 OUT 8 |
| 0x00000036 | IOL IN 0 OUT 10 |
| 0x00000038 | IOL IN 0 OUT 16 |
| 0x0000003F | IOL IN 0 OUT 24 |
| 0x0000002C | IOL IN 0 OUT 32 |
| 0x0000002D | IOL IN 1 OUT 1 |
| 0x0000002E | IOL IN 2 OUT 2 |
| 0x00000040 | IOL IN 2 OUT 4 |
| 0x00000041 | IOL IN 4 OUT 2 |
| 0x00000042 | IOL IN 4 OUT 4 |
| 0x0000002F | IOL IN 2 OUT 8 |
| 0x00000043 | IOL IN 4 OUT 8 |
| 0x00000030 | IOL IN 8 OUT 2 |
| 0x00000044 | IOL IN 8 OUT 4 |
| 0x00000045 | IOL IN 8 OUT 8 |
| 0x00000031 | IOL IN 4 OUT 32 |
| 0x00000032 | IOL IN 32 OUT 4 |
| 0x00000039 | IOL IN 16 OUT 16 |
| 0x00000046 | IOL IN 24 OUT 24 |
| 0x00000033 | IOL IN 32 OUT 32 |
| 0x00000059 | Output Pin 4 |
| 0x0000005A | Output Pin 2 |
| 0x0000005B | Input Pin 4 |
| 0x0000005C | Input Pin 2 |

Submodule ID 4 bytes of data that describe which submodule is used with the respective module.
(The submodule ID is saved in the GSDML)

| Possible values | Meaning |
|-----------------|--------------------------------------|
| 0x00000001 | BNI PNT-538-105-Z063 (header module) |

10 Diagnostics

10.3. AlarmSpecifier 2 bytes, subdivided as follows:

Sequence Number Bit 0-10, this counter is incremented with every new diagnostic message.

Channel Diagnostic Bit 11

| Possible values | Meaning |
|-----------------|--|
| 0x00 | No diagnosis related to channel is pending |
| 0x01 | Diagnosis related to channel is pending |

Manufacturer Specific Diagnosis Bit 12

| Possible values | Meaning |
|-----------------|---|
| 0x00 | No diagnosis related to manufacturer is pending |
| 0x01 | Diagnosis related to channel is pending |

Submodule Diagnostic State Bit 13

| Possible values | Meaning |
|-----------------|---|
| 0x00 | No further diagnosis of submodule present |
| 0x01 | At least one further diagnosis of the submodule present |

Bit 14 reserved

ARDiagnosis State Bit 15

| Possible values | Meaning |
|-----------------|---|
| 0x00 | No further diagnosis of module is present |
| 0x01 | At least one further diagnosis of the module is present |

User Structure Ident 2 bytes, describes the type of diagnosis

| Possible values | Meaning |
|-----------------|---------------------------|
| 0x8000 | Channel-related diagnosis |

10.4.Channel Number Configuration as standard I/O

| Error Type | Channel Number |
|--------------------------------|----------------|
| Undervoltage US | 8000 |
| Undervoltage UA | 8000 |
| No UA | 8000 |
| Sensor Short circuit Pin 1 - 3 | 0.....n |
| Actor Short circuit Pin 2 - 3 | 0.....n |
| Actor Short circuit Pin 4 - 3 | 0.....n |

n = no. of IOL ports

Configuration as IO-Link

| Error Type | Channel Number |
|--------------------------------|----------------|
| Line break | 0 |
| Short circuit IOL Pin 4 - 3 | 0 |
| Sensor short circuit Pin 1 - 3 | 0 |
| IOL Device wrong configuration | 0 |

Diagnosis of IO-Link devices

| Error Type | Channel Number |
|---------------------------|----------------|
| Short circuit | 1 |
| Undervoltage | 1 |
| Upper threshold exceeded | 1 |
| Lower threshold undershot | 1 |

10 Diagnostics

10.5. Channel Properties

2 bytes, subdivided as follows:

Type

| Possible values | Meaning |
|-----------------|--|
| 0x00 | Used if the channel number is 0x8000 or none of the types defined below is relevant. |
| 0x01 | 1 Bit |
| 0x02 | 2 Bit |
| 0x03 | 4 bit |
| 0x04 | 8 bit |
| 0x05 | 16 Bit |
| 0x06 | 32 bit |
| 0x07 | 64 bit |
| 0x08 – 0xFF | Reserved |

Bit 0-7

Accumulative

Bit 8 not used, always 0.

Maintenance

| Possible values | | Meaning |
|-----------------|--------|-------------|
| Bit 9 | Bit 10 | |
| 0x00 | 0x00 | Diagnostics |

Bit 9-10

Specifier

| Possible values | Meaning |
|-----------------|---|
| 0x00 | Not used |
| 0x01 | Diagnosis appeared |
| 0x02 | Diagnosis left |
| 0x03 | Diagnosis left, but another is still active |

Bit 11-12

Direction

| Possible values | Meaning |
|-----------------|----------------------------------|
| 0x00 | Manufacturer-specific |
| 0x01 | Channel used as input |
| 0x02 | Channel used as output |
| 0x03 | Channel used as input and output |

Bit 13-15

10.6.Channel Error
Type



| Error code in hex | Description |
|-------------------|---|
| 0x0000 | Unknown error |
| 0x0001 | Short circuit |
| 0x0002 | Undervoltage |
| 0x0003 | Overvoltage |
| 0x0004 | Overload |
| 0x0005 | Temperature limit exceeded |
| 0x0006 | Cable break |
| 0x0007w | Upper threshold exceeded |
| 0x0008 | Lower threshold undershot |
| 0x0009 | Error |
| 0x001A | External error |
| 0x001B | Sensor has incorrect configuration (IO-Link device) |
| 0x0101 | Actuator warning |
| 0x0105 | Actuator supply undervoltage |
| 0x0104 | No actuator power supply |

11 Use in safety applications

11.1. Product description

This product is a remote IP67 IO-Link Profinet™ fieldbus module with four Class A ports and four Class B ports (per IEC 61131-9).

| Description | Class A Ports | Class B Ports |
|----------------------|---------------|---------------|
| BNI PNT-538-105-Z063 | 4 | 4 |

| Port type | Connector diagram | Pinning | Remarks |
|------------------------|--|---|---|
| Class A (Ports 0-4) |  | <ol style="list-style-type: none"> +24 V/DC In-/output GND In-/output/IO-Link n.c. | In this type the functions of Pins 2 and 5 are not specified. Pin 2 is usually connected to another digital channel. |
| Class B (Ports 5-7) |  | <ol style="list-style-type: none"> +24 V/DC P24 GND In-/output/IO-Link N24 | This type provides an additional supply voltage and is suitable for connecting devices which have a higher current requirement. Here pins 2 and 5 provide an additional (galvanically isolated) supply voltage. |

By maintaining all the specifications in the corresponding user's guide and safety instructions Pins 2 and 5 of the Class B port on these modules can be safety switched off using a higher level safety logic (e.g. safety relay). The devices are therefore suitable for turning off actuators which are powered solely by these pins for use in safety applications.



Attention!

The Class A ports and Pines 1,3 and 4 on the Class B ports are not suitable for use in safety applications.

11.2. Safety function

The safe state of the Class B ports is no voltage on Pins 2 and 5. Turn-off must be done by the higher level safety logic (externally).
The fieldbus modules are constructed internally so that because of fault exclusions (see DIN EN ISO 13849-2) no external voltages can reach the galvanically isolated Pins 2 and 5 on the Class B port. This applies both to the IO-Link interface communication and for the external voltage supplies. The modules do not have their own safety logic or safety diagnostics.



Attention!

- Turning off actuators over the IO-Link interface is not suitable for safety functions within the safety chain.
- The actuators must be suitable for this type of safe turn-off and must if appropriate also have galvanic isolation.

Accordingly the actuator-voltage supplies must be configured according to the principles of safe (potential-) isolation in order to prevent cross fault (per EN.IEC 60204-1, DIN EN ISO 13849-2).

Within the safety chain of the safety application both potentials (24 V and 0 V) of the actuator-voltage supplies must always be isolated using the higher level safety logic.



Attention!

The use of power supplies other than SELV/PELV can result in a hazard to the user and compromising of the functional safety.

11.3. Example of an application description

The safety function of the safe turn-off is implemented for example using the following signal chain: Safe switches/sensors (e.g. E-Stop) – safety logic (e.g. safety relay – fieldbus module with Class B ports – actuator(s)). All elements must be suitable for use in the implemented safety function.

- When the safe switch/sensor (e.g. E-Stop) is actuated, Pins 2 and 5 on the Class B ports are safely isolated from the supply voltage (two-pin) by the safety logic and switched potential-free.




Figure 1: Schematic diagram of safety chain

The voltage supplies US / UA provide power to the Class A and Class B ports of the module galvanically isolated and independent of each other:

| Description | Order code | | Class A | Class B |
|----------------------|------------|-----------------|-----------------------|-----------------|
| | | | Port 0, 1, 2, 3 | Port 4, 5, 6, 7 |
| BNI PNT-538-105-Z063 | BNI00AZ | US (24V/GND) | Pins 1,3 Pins 2,4* | Pins 1,3,4 |
| | | UA (P24/N24) | | Pins 2,5 |

Table 1: Segment assignment for the voltage supplies

* When UA is turned off the Class A outputs are also deactivated via software (not safe).

11 Use in safety applications

11.4. Inspections

The inspection interval for the function test of the safety function to be documented [turning off the actuator-voltage(s)] depends on the requirements for the safety function of the higher level system, but must be performed no later than every 12 months.

Note



It is recommended that the inspection be automatically carried out by the higher level system. If this is not possible, we recommend automatically providing the user with a reminder for the inspection. If this is not possible either, performance of the inspection must be specified in the process instructions for the higher level system.

12 Appendix

12.1. Scope of Delivery

The BNI PNT comprises the following elements:

- IO-Link block
- 4x M12 dummy plugs
- Ground strap
- M4x6 screw
- 20 informational signs

12.2. Order number

BNI PNT-538-105-Z063

Balluff Network Interface

ProfiNet

Functions

538 = IP 67 IO-Link module, 4 IO-Link ports Class A, 4 IO-Link ports Class B

Versions

105 = display version, 2-port switch

Mechanical version

Z063 = Die-cast zinc

Data transmission: 2 x M12x1 internal thread

Power connection: M12 T-coded external / internal thread

Sensor connections: 8 x M12x1 internal thread

12.3. Ordering information

| Product order code | Order code |
|----------------------|------------|
| BNI PNT-538-105-Z063 | BNI00AZ |

www.balluff.com

Balluff GmbH
Schurwaldstrasse 9
73765 Neuhausen a.d.F.
Germany
Tel. +49 7158 173-0
Fax +49 7158 5010
balluff@balluff.de