



Operating instructions
Remote I/O module 16 DI
ModbusTCP
IP65 / IP66 / IP67 / IP69K

GB

AL4143

Contents

1	Preliminary note	4
1.1	Legal and copyright information	4
1.2	Symbols used	4
1.3	Warnings used	4
1.4	Safety symbol on the device	4
1.5	Change history	5
2	Safety instructions	6
2.1	Cyber security	6
3	Intended use	7
4	Function	8
4.1	Visual indication	8
4.2	Parameter setting	8
4.3	Inputs	8
4.3.1	Sensor supply	8
4.4	Digital input filters	8
4.4.1	Debouncing	9
4.4.2	Stretching	9
4.4.3	Inverting	10
4.4.4	Filter combination	10
4.5	Counter	10
4.5.1	Counter mode CTU	10
4.5.2	Counter mode CTD	11
4.5.3	Counter mode CTUD	11
4.5.4	Counter mode CTDIR	12
4.6	Modbus TCP	12
5	Installation	14
5.1	Overview	14
5.2	Install device	14
6	Electrical connection	15
6.1	Overview	15
6.2	General wiring information	15
6.2.1	Connection technology	15
6.3	Ethernet	16
6.4	Process connections	16
6.5	Voltage supply	16
6.5.1	Derating behaviour	17
6.5.1.1	Derating without daisy chain	17
6.5.1.2	Derating with daisy chain	18
6.6	Voltage output	18
7	Operating and display elements	19
7.1	LEDs	19
7.1.1	Status	19
7.1.2	Ethernet	20
7.1.3	Voltage supply	20
7.1.4	Process connections	20
8	Set-up	21
9	Settings	22
9.1	Parameter setting software	22
9.1.1	Supported parameter setting software	22
9.1.2	Getting started	22
9.1.3	Fieldbus: Configuring a ModbusTCP interface	23
9.1.4	Fieldbus: Reading the connection status	23
9.1.5	Ports: Setting the arrangement of the digital inputs	24
9.1.6	Ports: Configuring input filters	25
9.1.7	Ports: Reading digital input data	25
9.1.8	Counter: Configuring counter modules	26

9.1.9	Counter: Controlling counter modules	27
9.1.10	Counter: Reading counter values	27
9.1.11	Gateway: Reading identification information	28
9.1.12	Gateway: Reading status and diagnostic information	28
9.1.13	Gateway: Setting the application tag	28
9.1.14	Firmware: Reading the firmware version	29
9.1.15	Firmware: Resetting the device	29
9.1.16	Firmware: Restarting the device	29
9.2	IoT-Core Visualizer	30
9.2.1	Starting the ifm IoT Core Visualizer	30
9.2.2	Searching elements of the IoT Core	31
9.2.3	Configuring the device	32
9.2.3.1	Configuring a ModbusTCP interface	32
9.2.3.2	Setting the arrangement of the digital inputs	33
9.2.3.3	Configuring input filters	34
9.2.3.4	Configuring counter modules	34
9.2.3.5	Reading device information	36
9.2.3.6	Reading the firmware version	36
9.2.3.7	Setting the application tag	36
9.2.4	Accessing process data	37
9.2.4.1	Reading digital input data	37
9.2.4.2	Reading counter values	38
9.2.4.3	Controlling counter modules	38
9.2.4.4	Reading status and diagnostic information	38
9.2.5	Update firmware	39
9.3	ModbusTCP	40
9.3.1	Integrating a device into a Modbus TCP project	40
9.3.1.1	Example: Integrating a device into a CODESYS project	40
9.3.2	Device-specific notes	41
9.3.2.1	Rules for accessing the Modbus register	41
9.3.2.2	Supported function codes	41
9.3.2.3	Exception codes	41
9.3.3	Configuring the device	42
9.3.4	Configuring digital inputs	42
9.3.5	Configuring counter modules	42
9.3.6	Reading process data	42
9.3.7	Controlling counter modules	43
9.3.8	Controlling the device	43
9.3.9	Reading diagnostic data	43
9.3.10	Reading identification information	43
10	Maintenance, repair and disposal	45
10.1	Cleaning	45
10.2	Update firmware	45
11	Appendix	46
11.1	ModbusTCP	46
11.1.1	Register	46
11.1.1.1	Input data (0 - 34)	46
11.1.1.2	Port Configuration - Digital Inputs (100 - 163)	48
11.1.1.3	Port Configuration - Counter (200 - 271)	50
11.1.1.4	Port Output - Counter (300 - 355)	52
11.1.1.5	Block Configuration (400 - 408)	54
11.1.1.6	Byte Swap (500)	55
11.1.1.7	Connection Timeout (510)	56
11.1.1.8	DI Channel Mapping (550)	57
11.1.1.9	System Command (600)	58
11.1.1.10	Diagnostic Data (2000 - 2002)	59

1 Preliminary note

You will find instructions, technical data, approvals and further information using the QR code on the unit / packaging or at documentation.ifm.com.

1.1 Legal and copyright information

© All rights reserved by ifm electronic gmbh. No part of these instructions may be reproduced and used without the consent of ifm electronic gmbh.

All product names, pictures, companies or other brands used on our pages are the property of the respective rights owners.

1.2 Symbols used

- ✓ Requirement
- Instructions
- ▷ Reaction, result
- [...] Designation of keys, buttons or indications
- Cross-reference
-  Important note
Non-compliance may result in malfunction or interference.
-  Information
Supplementary note

1.3 Warnings used

ATTENTION

Warning of damage to property



CAUTION

Warning of personal injury

▷ Slight reversible injuries may result.



WARNING

Warning of serious personal injury

▷ Death or serious irreversible injuries may result.

1.4 Safety symbol on the device



Safety symbol on the device:

► Adhere to the operating instructions for the safe operation of the unit.

1.5 Change history

Issue	Subject	Date
00	New creation of the document	11 / 2022
01	• Corrected: Chapter DI Channel Mapping (550) (→ 57)	04 / 2023

2 Safety instructions

- The unit described is a subcomponent for integration into a system.
 - The system architect is responsible for the safety of the system.
 - The system architect undertakes to perform a risk assessment and to create documentation in accordance with legal and normative requirements to be provided to the operator and user of the system. This documentation must contain all necessary information and safety instructions for the operator, the user and, if applicable, for any service personnel authorised by the architect of the system.
- Read this document before setting up the product and keep it during the entire service life.
- The product must be suitable for the corresponding applications and environmental conditions without any restrictions.
- Only use the product for its intended purpose (→ Intended use).
- If the operating instructions or the technical data are not adhered to, personal injury and/or damage to property may occur.
- The manufacturer assumes no liability or warranty for any consequences caused by tampering with the product or incorrect use by the operator.
- Installation, electrical connection, set-up, operation and maintenance of the product must be carried out by qualified personnel authorised by the machine operator.
- Protect units and cables against damage.
- Replace damaged units, otherwise the technical data and safety will be impaired.
- Observe applicable documents.

2.1 Cyber security

ATTENTION

Operating the machine in an unprotected network environment

- ▷ Unauthorised read or write access to data is possible.
- ▷ Unauthorised manipulation of the device function is possible.
- ▶ Check and restrict access options to the device.

3 Intended use

The device may only be used for the following purposes:

- Gateway between digital sensors and a higher-level control system

The device is designed for use without a control cabinet in the food industry.

4 Function

4.1 Visual indication

The device displays the following indications:

- Status and error indication of the gateway and the system
- Status and activity indication of the Ethernet connection
- Status display of the voltage supply
- Status, error and short circuit/overload indication of the sensor ports

4.2 Parameter setting

The device can be configured using the following options:

- Parameter setting software
 - ifm moneo
 - ifm moneo|configure SA
- ifm IoT Core
 - IoT-Core Visualizer
- ModbusTCP
 - Projection software

4.3 Inputs

The device has 8 ports. Each port has 2 digital inputs.


4.3.1 Sensor supply

The device has a total of 8 sensor supplies (1 sensor supply per port).

4.4 Digital input filters

The device pre-processes the digital input signals. The filter result is forwarded as a process value. The following filters can be applied to the input signals in the sequence specified.

1. Debouncing
2. Stretching
3. Inverting



Each filter can be configured separately.

The device detects signals of a length of min. 0.23 ms. Shorter signals are not detected.




Periodic signals are only detected reliably if the signal period is at least twice as long as the cycle time.

4.4.1 Debouncing

The filter suppresses noise signals. The filter provides the input signals at the filter output with a delay (debounce time). All signals shorter than the set debounce time are ignored by the filter.

Time diagram debounce filter:




4.4.2 Stretching


The filter stretches short input pulses. Level changes that occur during a stretching period are ignored. The filter is configured via the following parameters:

- Hold time: pulse duration to which short pulses are to be stretched. Pulses that are present for a longer time than the hold time are not stretched.
- Hold level: signal level to be stretched (HIGH or LOW)

Time diagram stretch filter (status HIGH):



Time diagram stretch filter (status LOW):



4.4.3 Inverting


The filter inverts signals.

4.4.4 Filter combination

The filters can be combined.

Example: All 3 filters are activated

Time diagram:




4.5 Counter

The device features one counter module per port.

A counter module consists of 2 separate counters:

- Main counter: The main counter counts the rising edges of the filtered digital input signals. The main counter has a value range that is defined by a threshold value. If the value range of the main counter is exceeded or not reached, an overflow or underflow signal is sent to the batch counter.
- Batch counter: The batch counter counts the overflow or underflow signals of the main counter.



A counter module can be operated in different operating modes. The following operating modes are available.


4.5.1 Counter mode CTU

In CTU (Count Up) mode, the counter module operates as an up counter with overflow detection and overflow counter.

Behaviour:

- The initial value of the main counter is $m = 0$. The initial value of the batch counter is $b = 0$. The main counter has a threshold value CT . The batch counter has a threshold value CT_b .

- If the counter module detects a positive edge at pin 4 of the port, the value of the main counter is incremented ($m = m+1$).
- If the main counter reaches the threshold value CT ($m = CT$), the counter value is reset ($m = 0$). Due to the overflow detection, the value of the batch counter is incremented ($b = b+1$).
- If the batch counter reaches the threshold value CTb ($b = CTb$), the counter value is reset ($b = 0$).




4.5.2 Counter mode CTD

In CTD (Count Down) mode, the counter module operates as a down counter with underflow detection and underflow counting.

Behaviour:

- The initial value of the main counter is $m = 0$. The initial value of the batch counter is $b = 0$. The main counter has a threshold value CT. The batch counter has a threshold value CTb.
- The first time a positive edge is detected at pin 4, the value of the main counter is set to the threshold value CT-1 ($m = CT-1$). At the same time, the value of the batch counter is set to the threshold value CTb-1 ($b = CTb-1$).
- If the counter module detects a positive edge at pin 4 of the port, the value of the main counter is decremented ($m = m-1$).
- If the main counter falls below 0, the counter value is reset to the threshold value ($m = CT-1$). Due to the underflow detection, the value of the batch counter is decremented ($b = b-1$).
- If the batch counter falls below 0, the counter value is reset to the threshold value ($b = CTb-1$).




4.5.3 Counter mode CTUD

In CTUD (Count Up Down) mode, the counter operates as a simultaneous up and down counter with overflow and underflow detection.

Behaviour:

- The initial value of the main counter is $m = 0$. The initial value of the batch counter is $b = 0$. The main counter has a threshold value CT. The batch counter has a threshold value CTb.
- If the counter module detects a positive edge at pin 4 of the port, the value of the main counter is incremented ($m = m+1$).
- If the counter module detects a positive edge at pin 2 of the port, the value of the main counter is decremented ($m = m-1$).

- If the counter module simultaneously detects a positive edge at pin 4 and pin 2 of the port, the counter value of the main counter does not change.
- If the main counter reaches the threshold value CT ($m = CT$), the counter value is reset ($m = 0$). Due to the overflow detection, the value of the batch counter is incremented ($b = b+1$).
- If the main counter falls below 0, the counter value is reset to the threshold value ($m = CT-1$). Due to the underflow detection, the value of the batch counter is decremented ($b = b-1$).
- If the batch counter reaches the threshold value CTb ($b = CTb$), the counter value is reset ($b = 0$).
- If the batch counter falls below 0, the counter value is reset to the threshold value ($b = CTb-1$).




4.5.4 Counter mode CTDIR

In CTDIR (Count Direction) mode, the counter module operates either as an up counter with overflow detection or as a down counter with underflow detection. The counting direction can be set.

Behaviour:

- The initial value of the main counter is $m = 0$. The initial value of the batch counter is $b = 0$. The main counter has a threshold value CT. The batch counter has a threshold value CTb.
- The user can determine the counting direction. The counter module initially operates as an up counter with overflow detection.
- If the counter module detects a positive edge at pin 4 of the port and the counting direction of the port is set to "up", the value of the main counter is incremented ($m = m+1$).
- If the main counter reaches the threshold value CT ($m = CT$), the counter value is reset ($m = 0$). Due to the overflow detection, the value of the batch counter is incremented ($b = b+1$).
- If the batch counter reaches the threshold value CTb ($b = CTb$), the counter value is reset ($b = 0$).
- If the counter module detects a positive edge at pin 4 of the port and the counting direction at pin 2 of the port is set to "down", the value of the main counter is decremented ($m = m-1$).
- If the main counter falls below 0, the counter value is reset to the threshold value ($m = CT-1$). Due to the underflow detection, the value of the batch counter is decremented ($b = b-1$).
- If the batch counter falls below 0, the counter value is reset to the threshold value ($b = CTb-1$).




4.6 Modbus TCP

The device offers the following Modbus TCP functions:

- Device profile: Modbus TCP Server (message mode)
- 2-port switch for access to Modbus TCP interface (XF1 / XF2)

5 Installation

5.1 Overview



- 1: Upper mounting lug
- 2: Lower mounting lugs lug

5.2 Install device




- ▶ Disconnect the power of the machine before installation.
- ▶ Use a flat mounting surface for installation.
- ▶ Please observe the maximum tightening torque.

Fasten the device onto the mounting surface using 2 M5 mounting screws and washers (tightening torque: 1.8 Nm).

6 Electrical connection

6.1 Overview



- XF1: Ethernet 1 (ModbusTCP)
- XF2: Ethernet 2 (ModbusTCP)
- XD1: Power IN
- XD2: Power OUT
- X1: Process connection 1 (sensor)
- X2: Process connection 2 (sensor)
- X3: Process connection 3 (sensor)
- X4: Process connection 4 (sensor)
- X5: Process connection 5 (sensor)
- X6: Process connection 6 (sensor)
- X7: Process connection 7 (sensor)
- X8: Process connection 8 (sensor)

6.2 General wiring information

The device must be connected by a qualified electrician.

- Observe the national and international regulations for the installation of electrical equipment.

The device is only suitable for operation using SELV/PELV voltages.

This device contains components that may be damaged or destroyed by electrostatic discharge (ESD).

- Please observe the required precautions against electrostatic discharge!

The circuits are insulated from each other and from touchable surfaces of the device with basic insulation according to EN 61010-1.

The communication interfaces are insulated from each other and from touchable surfaces of the device with basic insulation according to EN 61010-1.

6.2.1 Connection technology

The threaded connections in the device correspond to the M12 standard. To ensure compliance with the specified protection rating, only cables that comply with this standard may be used. In the case of self-assembled cables, the system manufacturer is responsible for the protection rating.

- Use connectors with gold-plated contacts.
- During installation, place the connectors vertically so that the coupling nut will not damage the thread.
- Observe the coding of the connectors during installation.
- Cover unused connections with protective covers. Tightening torque: 1.3 ± 0.1 Nm

6.3 Ethernet

The device is connected to the ModbusTCP network via the Ethernet ports XF1 / XF2 (e. g. ModbusTCP control, additional ModbusTCP device). In addition, the device can be connected to an IT network via the Ethernet ports. The user can access functions of the ifm IoT Core via the IT network (parameter setting software, IoT Core Visualizer).

- ▶ Connect the device to the ModbusTCP network via a free Ethernet port.
- ▶ Optional: Connect the device to the IT network via a free Ethernet port.
- ▶ For connection, use an M12 connector (with at least protection rating: IP65 / IP66 / IP67 / IP69K).
- ▶ Tighten the cable plug using 1.3 ± 0.1 Nm.

Wiring:



6.4 Process connections

The sensors are connected to the device via the process connections.

The total current supply of the ports X1...X8 is limited to 3.6 A.

The ports feature short-circuit / overload detection.

- ▶ Connect the sensors to ports X1...X8.
- ▶ For connection, use M12 connectors (with at least protection rating: IP65 / IP66 / IP67 / IP69K; max. cable length: 30 m).
- ▶ Tighten the cable plug using 1.3 ± 0.1 Nm.

Wiring:



6.5 Voltage supply

The device is connected to the supply voltage US via the power IN port.

The US supply voltage supplies the device and the sensors connected to the ports X1...X8 with voltage.

Optionally, an additional supply voltage UA can be fed to the device via the power IN port. US is looped through to the power OUT port. UA is used exclusively to supply additional devices via the power OUT port (daisy chain).

Port XD1 has overvoltage protection (US).

Port XD1 has reverse polarity protection (US).

The port XD1 has cross reverse polarity protection (US, UA).


**CAUTION**

Exceeding the maximum input current of 16 A

- ▷ Risk of fire
- ▶ I_U and I_A of the supply voltages US and UA accordingly, taking into account the derating behaviour of the device: [Derating behaviour \(→ 17\)](#)

- ▶ Disconnect power.
- ▶ Connect the device via port XD1 to the US supply voltage with 24 V DC (20...30 V SELV/PELV).
- ▶ Optional: Connect the device via port XD1 to the UA supply voltage with 24 V DC (20...30 V SELV/PELV).
- ▶ For connection, use an L-coded M12 connector (with at least protection rating: IP65 / IP66 / IP67 / IP69K).
- ▶ Tighten the cable sockets according to the torque specifications indicated by the cable manufacturer. Maximum permissible tightening torque: 0.8 Nm

Wiring:




- | | |
|----|---------------|
| 1: | +24 V DC (US) |
| 2: | GND (UA) |
| 3: | GND (US) |
| 4: | +24 V DC (UA) |
| 5: | FE |



6.5.1 Derating behaviour

The current I_{US} available at ports X1...X8 and the currents $I_{US\text{-daisy-chain}}$ and $I_{UA\text{-daisy-chain}}$ available at port XD2 depend on the ambient temperature of the device.

6.5.1.1 Derating without daisy chain



6.5.1.2 Derating with daisy chain



Example: derating (2000 m)

Temperature	$I_{UA\text{-daisy-chain}}(\text{XD2})$	$I_{US\text{max}}(\text{XD1})$	$I_{US}(\text{X1...X8})$	$I_{US\text{-daisy-chain}}(\text{XD2})$
30 °C	16 A	15.9 A	3.9 A	12 A
30 °C			0 A	15.9 A
30 °C			1.8 A	14.1 A
60 °C	8 A	8 A	2 A	6 A
60 °C			0 A	8 A
60 °C			1 A	7 A

Explanation: The current $I_{US\text{max}}$ at port XD1 is the sum of the currents I_{US} taken from ports X1...X8 and the current $I_{US\text{-daisy-chain}}$ taken from port XD2 for the supply of further devices.

Formula: $I_{US\text{max}}(\text{XD1}) = I_{US}(\text{X1...X8}) + I_{US\text{-daisy-chain}}(\text{XD2})$

The less current is consumed at ports X1...X8, the more current will be available to supply further devices via daisy chain through port XD2.

6.6 Voltage output

An additional device can be supplied via the power OUT port (daisy chain). The supply voltages US and UA are looped through from port XD1 to port XD2.

Max. current of US: 15.9 A

Max. current of UA: 16 A

- ▶ Optional: Connect an additional device to port XD2.
- ▶ For connection, use an L-coded M12 connector (with at least protection rating: IP65 / IP66 / IP67 / IP69K).
- ▶ Tighten the cable plug using $1.3 \pm 0.1 \text{ Nm}$.
- ▶ Observe the derating behaviour of the device ([→ Derating behaviour □ 17](#))!


Wiring:



- 1: +24 V DC (US)
- 2: GND (UA)
- 3: GND (US)
- 4: +24 V DC (UA)
- 5: FE

7 Operating and display elements

7.1 LEDs



- 1: status: RDY
- 2: status: ERR
- 3: status: RUN
- 4: Modbus TCP: LNK
- 5: Modbus TCP: ACT
- 6: Process connection: DI1
- 7: Process connection: DI2
- 8: Voltage supply: US

7.1.1 Status

LED	Description	Colour	State	Description
RDY	Gateway status	Green	-	Off
			Flashes 3 s (1 Hz)	DCP signalling service initiated via fieldbus
			Flashes (5 Hz)	Error
			Flashes (200 ms on, 800 ms off)	Firmware update running
			On	OK
		red	On	Error during firmware update (e.g. firmware not compatible)
ERR	Error indication	red	Off	No error
			Flashes (10 Hz)	Boot error
			flashes (200 ms on, 200 ms off, 200 ms on, 1000 ms off)	Watchdog error (Modbus TCP or process data)
			flashes (200 ms on, 1000 ms off)	local error
			Flashes (2.5 Hz)	invalid configuration
			On	Communication error
RUN	Modbus TCP state (state machine)	Green	Off	not ready
			Flashes (1 Hz)	ready, but not yet configured
			Flashes (5 Hz)	waiting for connection
			On	connection established

7.1.2 Ethernet

LED	Description	Colour	State	Description
LNK	Status of the connection	Green	Off	No Ethernet connection
			On	Ethernet connection established
ACT	Status of the data transmission	Yellow	Off	No data transmission
			flashes	Data transmission

7.1.3 Voltage supply

LED	Description	Colour	State	Description
US	Voltage supply status	-	Off	No supply voltage is applied or the applied supply voltage is too low
			Green	Supply voltage applied
			red	Overvoltage, undervoltage, short circuit at sensor supply

7.1.4 Process connections

LED	Description	Colour	State	Description
DI1	Digital input signal level (pin 4)	Yellow	Off	Digital input - pin 4: LOW
			On	Digital input - pin 4: HIGH
DI2	Digital input signal level (pin 2)	Yellow	Off	Digital input - pin 2: LOW
			On	Digital input - pin 2: HIGH

8 Set-up

- ▶ Install the unit correctly.
- ▶ Establish a correct electrical connection with the device.
- ▷ Once connected to the supply voltage, the unit will start.
- ▷ The LEDs show status and error conditions.
- ▷ The unit is ready for operation.
- ▷ The device can be configured.

9 Settings

9.1 Parameter setting software

9.1.1 Supported parameter setting software

The device can be configured with the following parameter setting software:

- ifm moneo
- ifm moneo|configure SA
- ▶ Install the desired parameter setting software.
- ▶ Activate the licences required for operation.
- ▷ Parameter setting software can be used for parameter setting of the device.

9.1.2 Getting started

Requirements:

- ✓ The parameter setting software is correctly installed on the laptop / PC.
- ✓ The laptop / PC is connected to a free Ethernet port of the device.
- ▶ Start the parameter setting software.
- ▶ Scan the network for devices.
 - ▷ The parameter setting software recognises the device.
- ▶ Optional:
- ▶ Establish a connection to the device.
- ▷ The parameter setting software can access the device parameters.

9.1.3 Fieldbus: Configuring a ModbusTCP interface

 Changes to the [byteswap] parameters will only take effect after the device has been restarted.

Available parameters:

Name	Description	Value range	Access
[dhcp]	Status of the DHCP client of the device	<ul style="list-style-type: none"> • Static IP: IP parameters are set by the user • DHCP: IP parameters are set by a DHCP server in the network (default) • BOOTP: IP parameters are set via the Bootstrap Protocol 	rw ¹
[ipaddress]	IP address of the ModbusTCP interface	e.g. 192.100.0.10 • 192.168.1.250 (default)	rw ¹
[subnetmask]	Subnet mask of the network segment	e.g. 255.255.255.0 • 255.255.255.0 (default)	rw ¹
[ipdefaultgateway]	IP address of the network gateway	e.g. 192.100.0.1 • 0.0.0.0 (default)	rw ¹
[macaddress]	MAC address of the Ethernet interface	e.g. 00:02:01:0E:10:7F	ro ²
[hostname]	Name of the device in the ModbusTCP network	e.g. al4x4x	ro ²
[connectiontimeout]	Set timeout for interruption of the fieldbus connection (value in milliseconds)	<ul style="list-style-type: none"> • 20: 20 ms ... • 31000: 31000 ms (default) ... • 60000: 60000 ms 	rw ¹
[byteswap]	Arrangement of the bytes in data WORD	<ul style="list-style-type: none"> • 0: Big Endian (default) • 65535: Little Endian 	rw ¹

¹ read and write

² read only

To configure the ModbusTCP interface:

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The connection to the device has been established.
- Select the [fieldbussetup] > [network] menu.
 - ▷ The menu page shows the current settings.
- Set IP parameters of the interface.
- Select [fieldbussetup] > [configuration] in the menu.
- Set fieldbus-specific parameters.
- Write the changed values to the device.
- Restart the device.
- ▷ The ModbusTCP interface is configured

9.1.4 Fieldbus: Reading the connection status

Available information:

Name	Description	Value range	Access
[connectionstatus]	Status of the ModbusTCP connection	<ul style="list-style-type: none"> Disconnected: Not connected Connected: Connected 	ro ¹
[disconnectioncounter]	Connection interruption counter	<ul style="list-style-type: none"> 0: no interruption ... 65535: 65535 interruptions 	ro ¹
[fieldbusfirmware]	Firmware version of the ModbusTCP stack	e.g. 5.4.0.3 (ModbusTCP Server)	ro ¹

¹ read only

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- ▶ Select the [fieldbussetup] menu.
- ▷ The menu page displays the status of the ModbusTCP connection.

9.1.5 Ports: Setting the arrangement of the digital inputs

The arrangement of the digital input channels in Modbus registers 0, 400 and 401 is adjustable.

Available options:

- Pin-based:

Word	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	X8 pin 2	X7 pin 2	X6 pin 2	X5 pin 2	X4 pin 2	X3 pin 2	X2 pin 2	X1 pin 2	X8 pin 4	X7 pin 4	X6 pin 4	X5 pin 4	X4 pin 4	X3 pin 4	X2 pin 4	X1 pin 4

- Port-based:

Word	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	X8 pin 2	X8 pin 4	X7 pin 2	X7 pin 4	X6 pin 2	X6 pin 4	X5 pin 2	X5 pin 4	X4 pin 2	X4 pin 4	X3 pin 2	X3 pin 4	X2 pin 2	X2 pin 4	X1 pin 2	X1 pin 4

Available parameters:

Name	Description	Value range	Access
[di_channel_mapping]	Setting the arrangement of the digital inputs in the process data	<ul style="list-style-type: none"> 0: Pin-based 1: Port-based 	rw ¹

¹ read and write

To set the arrangement of the digital inputs in the process data:

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The connection to the device has been established.
- ▶ Select [io] menu.
- ▷ The menu page shows the current settings.
- ▶ Set the parameters.
- ▶ Write the changed values to the device.
- ▷ Arrangement of the digital inputs in the process data is set.

9.1.6 Ports: Configuring input filters

-  ► Observe the notes on input filters: [Digital input filters \(→ 8\)](#)

Available parameters:

Name	Description	Value range	Access
[pin2]/[debounce_time]	Pin 2: debounce time (= value * 0.1 ms)	<ul style="list-style-type: none"> • 0: 0 ms (default) • 500: 50 ms 	rw ¹
[pin2]/[hold_time]	Pin 2: Hold time (= value * 0.1 ms)	<ul style="list-style-type: none"> • 0: 0 ms (default) • 60000: 6000 ms 	rw ¹
[pin2]/[hold_level]	Pin 2: Hold level	<ul style="list-style-type: none"> • 0: hold LOW • 1: hold HIGH (default) 	rw ¹
[pin2]/[invert]	Pin 2: Inversion	<ul style="list-style-type: none"> • 0: do not invert (default) • 1: invert 	rw ¹
[pin4]/[debounce_time]	Pin 4: debounce time (= value * 0.1 ms)	<ul style="list-style-type: none"> • 0: 0 ms • 500: 50 ms 	rw ¹
[pin4]/[hold_time]	Pin 4: Hold time (= value * 0.1 ms)	<ul style="list-style-type: none"> • 0: 0 ms (default) • 60000: 6000 ms 	rw ¹
[pin4]/[hold_level]	Pin 4: Hold level	<ul style="list-style-type: none"> • 0: hold LOW • 1: hold HIGH (default) 	rw ¹
[pin4]/[invert]	Pin 4: Inversion	<ul style="list-style-type: none"> • 0: do not invert (default) • 1: invert 	rw ¹

¹ The parameter can only be changed if no connection to the fieldbus controller is active

- Select the menu option [io] > [port[n]] (n: 1...8).
- ▷ The menu page displays the available parameters.
 - Set the parameters.
 - Write the changed parameter values to the device.
 - ▷ The digital input filters have been configured.

9.1.7 Ports: Reading digital input data

Available information:

Name	Description	Value range	Access
[pin2]/[digital]	Process value digital input - pin 2 (after filtering)	<ul style="list-style-type: none"> • LOW: Off • HIGH: On 	ro ¹
[pin4]/[digital]	Process value digital input - pin 4 (after filtering)	<ul style="list-style-type: none"> • LOW: Off • HIGH: On 	ro ¹

¹ read only

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- Select the menu option [io] > [port[n]] (n: 1...8).
- ▷ The menu page displays the current process values of the port's digital inputs.

 The displayed process values are the filtered input data.

9.1.8 Counter: Configuring counter modules

 ► Observe the notes on counter modules: [Counter \(→ □ 10\)](#)

 If the operating mode of a counter module is changed, the current counter values will be reset and any active events will be deleted.

For the parameters [pin2_function] and [count_direction_selection] all shown parameter values can be selected. It is not checked whether these make sense. For each counter operating mode (parameter [mode]), the table below indicates the valid value ranges (✓: valid setting; ✗: invalid setting):

[mode]	[pin2_function]					[count_direction_selection]	
	N/C	Counter Edge Input Pin2	Count Direction	Reset (Main & Batch Counter)	Disable (Main & Batch Counter)	Pin 2 Count Direction	IoT / PLC Count Direction
CTU	✓	✗	✗	✓	✓	✗	✗
CTD	✓	✗	✗	✓	✓	✗	✗
CTUD	✗	✓	✗	✗	✗	✗	✗
CTDIR	✗	✗	✓	✗	✗	✓	✗
CTDIR	✓	✗	✗	✓	✓	✗	✓

Available parameters:

Name	Description	Value range	Access
[mode]	Operating mode of the counter module	<ul style="list-style-type: none"> • CTU (up counter): up counter (default) • CTD (down counter): Down counter • CTUD (up counter / down counter): up and down counter • CTDIR (direction counter): up or down counter 	rw ¹
[pin2_function]	Pin 2 function of the port (→ Observe note!)	<ul style="list-style-type: none"> • N/C: no function (default) • Counter Edge Input 2: counting pulse (rising edge) • Count Direction: counting direction • Reset (Main & Batch Counter): reset main counter and batch counter • Disable (Main & Batch Counter): disable main counter and batch counter 	rw ¹
[count_direction_selection]	Control instance for selecting the counting direction (→ Observe note!)	<ul style="list-style-type: none"> • Pin 2 Count Direction: pin 2 of the port (default) • IoT / PLC Count Direction: Fieldbus PLC 	rw ¹
[main_threshold]	Main counter threshold (CT)	<ul style="list-style-type: none"> • 1 ... • 4294967295 (default) 	rw ¹
[batch_threshold]	Batch counter threshold (CTb)	<ul style="list-style-type: none"> • 1 ... • 65535 (default) 	rw ¹

¹ The parameter can only be changed if no connection to the fieldbus controller is active

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.

- ▶ Select menu [io] > [counter[n]] (n: 1...8).
 - ▷ The menu page displays the configuration options of the counter.
- ▶ Configure the counter module.
- ▶ Optional: Configure additional counter modules.
- ▶ Write the changed values to the device.
- ▷ The counter modules are configured.

9.1.9 Counter: Controlling counter modules

Available parameters:

Name	Description	Value range	Access
[disable]	Disable main counter and batch counter	<ul style="list-style-type: none"> • 0: counter module is active (default) • 1: counter module is not active 	rw ¹
[reset]	Reset main counter, batch counter and CT and CTb thresholds to initial values	<ul style="list-style-type: none"> • 0: no action (default) • 1: reset 	rw ¹
[direction] ²	Set the counting direction for the main counter and the batch counter	<ul style="list-style-type: none"> • 0: up (default) • 1: down 	rw ¹

¹ The parameter can only be changed if no connection to the fieldbus controller is active

² only effective if operating mode of counter module = CTDIR

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- ▶ Select menu [io] > [counter[n]] (n: 1...8).
 - ▷ The menu page displays the available parameters.
- ▶ Optional: disable counter module.
- ▶ Optional: reset counter module.
- ▶ Optional: set counting direction of counter module.
- ▶ Write the changed parameter values to the device.
- ▷ Selected actions are executed.

9.1.10 Counter: Reading counter values

Available parameters:

Name	Description	Value range	Access
[maincounter_value]	Main counter reading	0..4294967294	ro ¹
[batchcounter_value]	Batch counter value	0..65534	ro ¹

¹ read only

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- ▶ Select the menu option [io] > [port[n]] (n: 1...8).
 - ▷ The menu page displays the current counter values of the main and batch counter.

9.1.11 Gateway: Reading identification information

Available information:

Name	Description	Value range	Access
[productcode]	Article number	AL4143	ro ¹
[devicefamily]	Device family	Ethernet modules	ro ¹
[vendor]	Manufacturer	ifm electronic gmbh	ro ¹
[swrevision]	Firmware revision	e.g. AL4x4x_fw_md_1.4.0.142	ro ¹
[hwrevision]	Hardware revision (status)	e.g. AA	ro ¹
[bootloaderrevision]	Bootloader version	e.g. AL4xxx_bl_1.4.0.39	ro ¹
[serialnumber]	Serial number	e.g. 0002043100003	ro ¹
[fieldbusstype]	Fieldbus	ModbusTCP	ro ¹

¹ read only

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- Select the menu option [deviceinfo].
- ▷ The menu page displays the identification information of the device.

9.1.12 Gateway: Reading status and diagnostic information

Available information:

Parameter	Description	Value range	Access
[temperature]	Temperature of the device (value in °C)	-30...80	ro ¹
[voltage_us]	Present voltage value of the device supply US (value in mV)	0...40000	ro ¹
[supervisionstatus_us]	Status of the device supply US	<ul style="list-style-type: none"> • 0: No error • 1: Error 	ro ¹
[current_us]	Present current value of the device supply US (value in mA)	0...40000	ro ¹

¹ read only

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- Select [Processdatamaster] menu.
- ▷ The menu page displays the diagnostic and status information.

9.1.13 Gateway: Setting the application tag

Available parameters:

Parameter	Description	Value range	Access
[applicationtag]	Application-specific identifier of the device in moneo	e.g. plant 1 machine 3	rw ¹

¹ read and write

Requirements:

- ✓ The parameter setting software has been started.

- ✓ The detailed view of the device is active.
- Select [devicetag] menu.
- Enter the application identifier.
- Write the changed values to the device.
- ▷ The device can be identified by the selected application tag.

9.1.14 Firmware: Reading the firmware version

Available information:

Parameter	Description	Value range	Access
[version]	Firmware version	e.g. AL4x4x_fw_md_1.4.0.142	ro ¹

¹ read only

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- Select the [Firmware] menu.
- ▷ The menu page displays the firmware version of the device.

9.1.15 Firmware: Resetting the device

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- Select the [Firmware] menu.
- Click on [factoryreset].
- ▷ The device is reset to factory settings.
- ▷ All parameters are set to their default values.

9.1.16 Firmware: Restarting the device

Requirements:

- ✓ The parameter setting software has been started.
- ✓ The detailed view of the device is active.
- Select the [Firmware] menu.
- Click on [Reboot].
- ▷ The device will be restarted.
- ▷ All set parameter values will be retained.


9.2 IoT-Core Visualizer

The IoT Core Visualizer provides a graphical user interface to access the functions of the ifm IoT Core.

9.2.1 Starting the ifm IoT Core Visualizer

Requirements:

- ✓ The PC is connected to the Ethernet interface of the device.
- ✓ Ethernet interface has been configured correctly.
- Go to the following URL: `http://<ip-address>` (e.g. `http://192.168.0.10`)
- The web browser displays the start page of the IoT Core Visualiser.



The navigation menu gives the user access to the following functions:

- [Notification]: No function
- [Elements]: [Searching elements of the IoT Core \(→ 31\)](#)
- [Parameter]: [Configuring the device \(→ 32\)](#)
- [Processdata]: [Accessing process data \(→ 37\)](#)
- [Update]: [Update firmware \(→ 39\)](#)

9.2.2 Searching elements of the IoT Core

The [Elements] menu page allows you to search the IoT core tree for elements with specific properties and output the results.

The following properties can be searched for:

- [identifier]: Name of the element
- [profile]: Element profile
- [type]: Type of the element

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ Menu [Elements] is active.

Io	Processdatamaster	Deviceinfo	Fieldbussetup	Firmware	Devicetag
^ 00-02-01-66-c2-24					
getidentity	00-02-01-66-c2-24/getidentity	type: service profiles: undefined			Copy URL
gettree	00-02-01-66-c2-24/gettree	type: service profiles: undefined			Copy URL
querytree	00-02-01-66-c2-24/querytree	type: service profiles: undefined			Copy URL
getsubscriberlist	00-02-01-66-c2-24/getsubscriberlist	type: service profiles: undefined			Copy URL
getdatamulti	00-02-01-66-c2-24/getdatamulti	type: service profiles: undefined			Copy URL

- ▶ Select the search criteria for the required element in the selection lists [identifier], [profile] and [type].
- ▶ Click on [Search for...].
- ▷ IoT-Core Visualizer searches device description for elements with selected search criteria.
- ▷ The result list shows all elements found.


9.2.3 Configuring the device

The [Parameters] menu page provides access to the configuration options of the device.

! The configuration created via the IoT Core Visualizer is overwritten when a connection is established between the device and the ModbusTCP PLC.

Requirements:

- ✓ IoT Core Visualizer has been launched.
- Select the [Parameter] menu.
- ▷ The menu page displays the available parameters of the device.



9.2.3.1 Configuring a ModbusTCP interface

! Changes to the `byteswap` data point will only take effect after the device has been restarted.

Available parameters:

Name	Description	Value range	Access
[network] > [dhcp]	Status of the DHCP client	<ul style="list-style-type: none"> • Static IP: Static IP address • DHCP: DHCP (Dynamic Host Configuration protocol) • BOOTP: BOOTP (Bootstrap Protocol) 	rw ¹
[network] > [ipaddress]	IP address of the Ethernet interface	e.g. 192.200.0.100 • 192.168.1.250 (default)	rw ¹
[network] > [subnetmask]	Subnet mask of the network segment	e.g. 255.255.192.0 • 255.255.255.0 (default)	rw ¹
[network] > [ipdefaultgateway]	IP address of the network gateway	e.g. 192.200.63.1 • 0.0.0.0 (default)	rw ¹
[network] > [macaddress]	MAC address of the Ethernet interface	e.g. 00:02:01:0E:10:7C	ro ²

Name	Description	Value range	Access
[configuration] > [connection-timeout]	Set timeout for interruption of the fieldbus connection (value in milliseconds)	<ul style="list-style-type: none"> • 20: 2 ms ... • 31000: 31000 ms ... • 60000: 60000 ms 	rw ¹
[configuration] > [byteswap]	Arrangement of the bytes in a data word	<ul style="list-style-type: none"> • big-endian: Big-endian format • little-endian: Little-endian format 	rw ¹

¹ read and write² read only

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Parameter] menu is active.
- Select the [Fieldbussetup] submenu.
 - ▷ The menu page shows the current settings.
- Set the parameters.
- Click on to save the changes to the device.
- If necessary, restart the device.
- ▷ The ModbusTCP interface is configured.

9.2.3.2 Setting the arrangement of the digital inputs

The arrangement of the digital input channels in Modbus registers 0, 400 and 401 is adjustable.

Available options:

- Pin-based:

Word	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	X8 pin 2	X7 pin 2	X6 pin 2	X5 pin 2	X4 pin 2	X3 pin 2	X2 pin 2	X1 pin 2	X8 pin 4	X7 pin 4	X6 pin 4	X5 pin 4	X4 pin 4	X3 pin 4	X2 pin 4	X1 pin 4

- Port-based:

Word	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	X8 pin 2	X8 pin 4	X7 pin 2	X7 pin 4	X6 pin 2	X6 pin 4	X5 pin 2	X5 pin 4	X4 pin 2	X4 pin 4	X3 pin 2	X3 pin 4	X2 pin 2	X2 pin 4	X1 pin 2	X1 pin 4

Available parameters:

Name	Description	Value range	Access
[di_channel_mapping]	Setting the arrangement of the digital inputs in the process data	<ul style="list-style-type: none"> • 0: Pin-based • 1: Port-based 	rw ¹

¹ read and write

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Parameter] menu is active.
- Select the [io] submenu.
 - ▷ The menu page shows the current settings.
- Set the parameters.

- ▶ Click on  to save the changes to the device.
- ▷ The arrangement of the digital input channels is configured.

9.2.3.3 Configuring input filters

-  ▶ Observe the notes on input filters: [Digital input filters \(→ 8\)](#)

Available parameters:

Name	Description	Value range	Access
[pin2] > [debounce_time]	Pin 2: debounce time (= value * 0.1 milliseconds)	<ul style="list-style-type: none"> • 0: 0 ms (default) ... • 500: 50 ms 	rw ¹
[pin2] > [hold_time]	Pin 2: Hold time (= value * 0.1 milliseconds)	<ul style="list-style-type: none"> • 0: 0 ms (default) ... • 60000: 6000 ms 	rw ¹
[pin2] > [hold_level]	Pin 2: Hold level	<ul style="list-style-type: none"> • low: hold LOW • high: hold HIGH (default) 	rw ¹
[pin2] > [invert]	Pin 2: Inversion	<ul style="list-style-type: none"> • signal not inverted: do not invert (default) • signal inverted: invert 	rw ¹
[pin4] > [debounce_time]	Pin 4: debounce time (= value * 0.1 milliseconds)	<ul style="list-style-type: none"> • 0: 0 ms (default) ... • 500: 50 ms 	rw ¹
[pin4] > [hold_time]	Pin 4: Hold time (= value * 0.1 milliseconds)	<ul style="list-style-type: none"> • 0: 0 ms (default) ... • 60000: 6000 ms 	rw ¹
[pin4] > [hold_level]	Pin 4: Hold level	<ul style="list-style-type: none"> • low: hold LOW • high: hold HIGH (default) 	rw ¹
[pin4] > [invert]	Pin 4: Inversion	<ul style="list-style-type: none"> • signal not inverted: do not invert (default) • signal inverted: invert 	rw ¹

¹ The parameter can only be changed if no connection to the fieldbus controller is active

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Parameter] menu is active.
- ▶ Select the [io] > [port[n]] submenu (n: 1...8).
 - ▷ The menu page shows the current settings.
- ▶ Set the parameters.
- ▶ Click on  to save the changes to the device.
- ▷ The filters of the digital inputs are configured.

9.2.3.4 Configuring counter modules

-  ▶ Observe the notes on counter modules: [Counter \(→ 10\)](#)

-  If the operating mode of a counter module is changed, the current counter values will be reset and any active events will be deleted.

For the parameters [pin2_function] and [count_direction_selection] all shown parameter values can be selected. It is not checked whether these make sense. For each counter operating mode (parameter [mode]), the table below indicates the valid value ranges (✓: valid setting; ✗: invalid setting):

[mode]	[pin2_function]					[count_direction_selection]	
	No function	Counting pulse	Counting direction	Reset main counter and batch counter	Disable main counter and batch counter	Pin 2	IoT Core / Fieldbus PLC
CTU	✓	✗	✗	✓	✓	✗	✗
CTD	✓	✗	✗	✓	✓	✗	✗
CTUD	✗	✓	✗	✗	✗	✗	✗
CTDIR	✗	✗	✓	✗	✗	✓	✗
CTDIR	✓	✗	✗	✓	✓	✗	✓

Available parameters:

Name	Description	Value range	Access
[mode]	Operating mode of the counter module	<ul style="list-style-type: none"> • CTU (up counter): up counter (default) • CTD (down counter): Down counter • CTUD (up counter / down counter): Up and down counter • CTDIR (direction counter): Up and down counter with selectable counting direction 	rw ¹
[pin2_function]	Pin 2 function of the port (→ Observe note!)	<ul style="list-style-type: none"> • N/C: no function (default) • Counter Edge Input 2: counting pulse (rising edge) • Count Direction: counting direction • Reset (Main & Batch Counter): reset main counter and batch counter • Disable (Main & Batch Counter): disable main counter and batch counter 	rw ¹
[count_direction_selection]	Control instance for selecting the counting direction (→ Observe note!)	<ul style="list-style-type: none"> • Pin 2 Count Direction: Pin 2 (default) • IoT / PLC Count Direction: IoT Core / Fieldbus PLC 	rw ¹
[main_threshold]	Main counter threshold (CT)	<ul style="list-style-type: none"> • 1 ... • 4294967295 (default) 	rw ¹
[batch_threshold]	Batch counter threshold (CTb)	<ul style="list-style-type: none"> • 1 ... • 65535 (default) 	rw ¹

¹ The parameter can only be changed if no connection to the fieldbus controller is active

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Parameter] menu is active.
- Select the [io] > [counter[n]] submenu (n: 1...8).
 - ▷ The menu page shows the current settings.
- Set the parameters.
- Click on to save the changes.
- ▷ The counter modules are configured.

9.2.3.5 Reading device information

Available information:

Name	Description	Value range	Access
[productcode]	Article number	AL4143	ro ¹
[vendor]	Manufacturer	ifm electronic	ro ¹
[devicefamily]	Device family	Ethernet modules	ro ¹
[serialnumber]	Serial number (12 digits)	e.g. 000174210161	ro ¹
[hwrevision]	Hardware revision	e.g. AA	ro ¹
[swrevision]	Firmware version	e.g. AL4x4x_fw_md_1.4.0.142	ro ¹
[bootloaderrevision]	Bootloader version	e.g. AL4xxx_bl_1.4.0.39	ro ¹
[fieldbusstype]	Fieldbus	ModbusTCP	ro ¹

¹ read only

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Parameter] menu is active.
- Select the submenu [Deviceinfo].
- ▷ The menu page shows device information.

9.2.3.6 Reading the firmware version

Available information:

Name	Description	Value range	Access
[version]	Firmware version	AL4x4x_fw_md_1.4.0.142	ro ¹
[type]	Type	• firmware: Firmware type	ro ¹

¹ read only

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Parameter] menu is active.
- Select [Firmware] submenu.
- ▷ The menu page shows available information.

9.2.3.7 Setting the application tag

Available parameters:

Name	Description	Value range	Access
[applicationtag]	Designation of the unit in the monitoring software	e.g. "factory 2 plant 1"	rw ¹

¹ read and write

! 32 bytes are available on the device for storing the applicationtag parameter. If the memory range is exceeded, the device will abort the write process (diagnostic code 400).

- When writing the applicationtag parameter, observe the different memory requirements of the individual UTF-8 characters (characters 0-127: 1 byte per character; character >127: more than 1 byte per character).

Requirements:

- ✓ IoT Core Visualizer has been launched.

- ✓ The [Parameter] menu is active.
- Select the [Devicetag] submenu.
 - ▷ The menu page shows the current settings.
- Enter the application identifier.
- Click on to save the changes to the device.
- ▷ New application identifier is set.

9.2.4 Accessing process data

The [Process data] menu page provides access to the process data of the device.

Requirements:

- ✓ IoT Core Visualizer has been launched.
- Select the [Process data] menu.
 - ▷ The menu page shows the substructures of the device description containing process data.
 - ▷ The current process values are displayed.

- Optional: In the header, activate the option [Polling] and set the update interval.
 - ▷ The process values will be updated with the set interval.
- Optional: Click on next to an element to manually update the process value.

9.2.4.1 Reading digital input data

Available information:

Name	Description	Value range	Access
[pin2] > [digital_input]	Process value digital input - pin 2 (after filtering)	<ul style="list-style-type: none"> • Low: LOW • High: HIGH 	ro ¹
[pin4] > [digital_input]	Process value digital input - pin 4 (after filtering)	<ul style="list-style-type: none"> • Low: LOW • High: HIGH 	ro ¹

¹ read only

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Processdata] menu is active.
- Select the [io] > [port[n]] submenu (n: 1...8).
- ▷ Menu page shows the digital input data of the port.

9.2.4.2 Reading counter values

Available information:

Name	Description	Value range	Access
[maincounter_value]	Current main counter value	0...4294967295	ro ¹
[batchcounter_value]	Current batch counter value	0...65535	ro ¹

¹ read only

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Processdata] menu is active.
- Select the [io] > [counter[n]] submenu (n: 1...8).
- ▷ The menu page shows current counter values of the counter module.

9.2.4.3 Controlling counter modules

Available control signals:

Name	Description	Values	Access
[reset]	Reset counter module (reset counter and threshold values to default values)	<ul style="list-style-type: none"> • inactive: no action (default) • active: reset 	rw ¹
[disable]	Disable counter module	<ul style="list-style-type: none"> • inactive: enable counter (default) • active: disable counter 	rw ¹
[direction] ²	Set the counting direction for the main counter and the batch counter	<ul style="list-style-type: none"> • up: up (default) • down: down 	rw ¹

¹ The parameter can only be changed if no connection to the fieldbus controller is active

² only effective if operating mode of counter module = CTDIR

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ The [Processdata] menu is active.
- Select the [io] > [counter[n]] submenu (n: 1...8).
 - ▷ The menu page shows available services.
- Set control signals.
- Click on  to send the control signals to the device.
- ▷ Control signals are executed.

9.2.4.4 Reading status and diagnostic information

Available information:

Name	Description	Value range	Access
[temperature]	Temperature of the device (value un degrees Celsius)	e.g. 52: 52°C	ro ¹

Name	Description	Value range	Access
[voltage_us]	current voltage value of the device supply US (value in millivolts)	e.g. 25236: 25236 mV	ro ¹
[current_us]	current value of the device supply US (value in millamps)	e.g. 82: 82 mA	ro ¹
[supervisionstatus_us]	Status of the device supply US	<ul style="list-style-type: none"> OK: No error Fault: Error 	ro ¹
[uptime]	Time since the last start of the device (value in minutes)	<ul style="list-style-type: none"> 0x0000: 0 min ... 0xFFFF: 65535 min 	ro ¹

¹ read only

Requirements:


- ✓ IoT Core Visualizer has been launched.
- ✓ The [Processdata] menu is active.
- Select the submenu [Processdatamaster].
- ▷ Menu page shows status and diagnostic information.

9.2.5 Update firmware

The [Update] menu page allows you to update the firmware of the device:

Requirements:

- ✓ IoT Core Visualizer has been launched.
- ✓ New firmware has been downloaded: documentation.ifm.com
- Select the [Update] menu.
- ▷ Menu page shows information about the current firmware version.



- Click on [Load software file] and select a new firmware file (*.bin).
- Click on [Update] to start the update process.
- ▷ The firmware of the device is updated.
- ▷ Progress of the update process is displayed.
- ▷ After successful update: The device reboots automatically.

9.3 ModbusTCP

9.3.1 Integrating a device into a Modbus TCP project

The device offers the functionality of a Modbus TCP server (independent mode). The user can integrate the device into a Modbus TCP project via the profile of a generic Modbus TCP slave.

The device can be configured via the Modbus registers.

9.3.1.1 Example: Integrating a device into a CODESYS project



- ▶ Familiarise yourself with the Modbus Configurator function in the CODESYS help.

Task: Integrate the device into a CODESYS project.

Available hardware:

- SmartPLC AC14 DL (Modbus TCP Master)
- Device AL4143(Modbus TCP Slave)

Solution:


Create a Modbus TCP master

Requirements:

- ✓ CODESYS project with AC14 DL was created.
- ▶ In the device tree: Right click on the node [X8 (Ethernet)].
 - ▷ The context menu appears.
- ▶ Select the menu item [Add device...].
 - ▷ A dialogue window appears.
- ▶ Select the device profile [Modbus_TCP_Master].
- ▶ Click on [Add device].
- ▷ CODESYS adds the Modbus TCP master as a sub-node of the interface [X8 (Ethernet)] to the project.
- ▷ SmartPLC AC14 DL can be configured as TCP Master mode.

Add the device as a Modbus TCP slave

- ▶ In the device tree: Right click on the node [X8 (Ethernet)] > [Modbus_TCP_Master].
 - ▷ The context menu appears.
- ▶ Select the menu item [Add device...].
 - ▷ A dialogue window appears.
- ▶ Select the device profile [Modbus_TCP_Slave].
- ▶ Enter AL4143 as the name.
- ▶ Click on [Add device].
- ▷ CODESYS adds the device to the project as a sub-node of [Modbus TCP Master].
- ▷ The device can be configured as a Modbus TCP slave.



9.3.2 Device-specific notes

9.3.2.1 Rules for accessing the Modbus register

The following rules apply for access to the Modbus registers:

- To read or write Modbus registers, use only the valid Function Codes ([→ Supported function codes](#) [41](#)).

9.3.2.2 Supported function codes

The device supports the following function codes for accessing the Modbus registers:

Function code	Name	Description
FC2 (0x02)	Read Input Discretes	Read individual digital inputs
FC3 (0x03)	Read Multiple Registers	Read several contiguous registers
FC4 (0x04)	Read input register	Read input register
FC6 (0x06)	Write Single Register	Writing a single register
FC16 (0x10)	Write Multiple Registers	Writing several contiguous registers
FC23 (0x17)	Read / Write Multiple Registers	Read / write several contiguous registers
FC43 (0x2B)	Read Device Identification	Reading device information



Detailed information about the function codes: → Modbus TCP- specification

9.3.2.3 Exception codes

A Modbus TCP request has the following structure:

Function Code	Request Data
---------------	--------------

A Modbus TCP response has the following structure:

Function Code	Response Data
---------------	---------------

When a request is processed without errors, the response message contains the following information:

- Function code (1 byte): Function code of the request message
- Response data (n bytes): Requested data

If an error occurs during the processing of a request, the response message contains the following information:

- Function code (1 byte): Error Code (= Request Function Code + 0x80)
- Response data (1 byte): Exception codes

The following exception codes are available:

Exception code	Name	Description
0x1	ILLEGAL FUNCTION	Invalid Function Code (Modbus function not implemented)
0x2	ILLEGAL DATA ADDRESS	Invalid data address (invalid address or length)
0x3	ILLEGAL DATA VALUE	Invalid data value (invalid parameters; wrong number of registers)
0x4	SERVER DEVICE FAILURE	Unrecoverable error in the Modbus server during processing

9.3.3 Configuring the device

Registers 500, 510 and 550 provide access to the following basic settings of the device:

- Arrangement of the bytes in the data tables: [Byte Swap \(500\) \(→ □ 55\)](#)
- Max. connection time interruption: [Connection Timeout \(510\) \(→ □ 56\)](#)
- Arrangement of the process data in registers 0, 400 and 401: [DI Channel Mapping \(550\) \(→ □ 57\)](#)

9.3.4 Configuring digital inputs

The register range 100...163 provides access to the filter settings of the digital input channels at pin 2 and 4 of the ports: [Port Configuration - Digital Inputs \(100 - 163\) \(→ □ 48\)](#)

The following parameters can be configured for each digital input channel:

- Inversion
- Hold level
- Debounce time
- Hold time

9.3.5 Configuring counter modules

The register area 200...271 provides access to the settings of the counter modules of the ports: [Port Configuration - Counter \(200 - 271\) \(→ □ 50\)](#)

The following parameters can be configured for each counter module:

- Operating mode of the counter module
- Pin 2 function of the port
- Instance for selecting the counting direction
- threshold CT of the main counter
- threshold CTb of the batch counter
- Set counter value of the main counter
- Set the counter value of the batch counter

9.3.6 Reading process data

Registers 0...34 provide access to the unit's process data: [Input data \(0 - 34\) \(→ □ 46\)](#)

The register range 0..2 contains the following process data:

- Digital inputs of all ports
- Overflow and underflow events of the main counter and batch counter of all ports

The register area 3...34 contains the following process data for each port separately:

- Counter values of the Main Counter and Batch Counter

- Overflow and underflow events of the main counter and batch counter

9.3.7 Controlling counter modules

The register range 300...355 provides access to the control signals of the individual counter modules: [Port Output - Counter \(300 - 355\) \(→ □ 52\)](#)

There is a separate register area for each counter module. The following control signals are available in each register area:

- Disable counter module
- Set the direction
- Reset overflow/underflow event of the main counter
- Reset overflow/underflow event of the batch counter
- Counter and overflow/underflow events Reset counter events

The register range 400...408 provides compact access to the control signals of all counter modules: [Block Configuration \(400 - 408\) \(→ □ 54\)](#)

The following control signals are available for each counter module:

- Signal inversion (pin 2 / pin 4)
- Signal level (pin 2 / pin 4)
- Disable counter module
- Set the direction
- Reset overflow/underflow event of the main counter
- Reset overflow/underflow event of the batch counter
- Counter and overflow/underflow events Reset counter events

9.3.8 Controlling the device

Register 600 provides access to system commands for controlling the device: [System Command \(600\) \(→ □ 58\)](#)

The following system commands are available:

- Restarting the device
- Resetting the device

9.3.9 Reading diagnostic data

The registers 2000...2002 provide access to the diagnostic data of the device: [Diagnostic Data \(2000 - 2002\) \(→ □ 59\)](#)

The register area contains the following diagnostic data:

- Status of the voltage supply
- Time since last device start
- Connection interruption counter

9.3.10 Reading identification information

The user can read identification information of the device with the function code FC43.

The machine supports the following categories of the Read Device ID Code function:

- Basic Device Identification (0x01):

Object ID	Name	Data type	Value range
0x00	Vendor name	ASCII string	ifm electronic
0x01	Product Code	ASCII string	AL4143
0x02	Major Minor Revision	ASCII string	e.g. 1,001

- Regular Device Identification (0x02):

Object ID	Name	Data type	Value range
0x00	Vendor name	ASCII string	ifm electronic
0x01	Product Code	ASCII string	AL4143
0x02	Major Minor Revision	ASCII string	e.g. 1,001
0x03	Vendor Url	ASCII string	www.ifm.com
0x04	Product Name	ASCII string	ETH Module PFL MB 16DI IP69K
0x05	Model Name	ASCII string	AL4143
0x06	User Application Name	ASCII string	Ethernet Module 16DI

10 Maintenance, repair and disposal

The operation of the unit is maintenance-free.

- Dispose of the device in an environmentally friendly way in accordance with the applicable national regulations when it is no longer used.

10.1 Cleaning

- Disconnect the unit from the voltage supply.
- Clean the device from dirt using a soft, chemically untreated and dry cloth.
- In case of severe soiling, use a damp cloth.



- Do not use any caustic cleaning agents for this!

10.2 Update firmware

The system software of the device can be updated using the following options:

IoT Core Visualizer:

11 Appendix

11.1 ModbusTCP

11.1.1 Register

11.1.1.1 Input data (0 - 34)

Register	Bit																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
0	X8: DI2	X8: DI 1	X7: DI2	X7: DI 1	X6: DI2	X6: DI 1	X5: DI2	X5: DI 1	X4: DI2	X4: DI 1	X3: DI2	X3: DI 1	X2: DI2	X2: DI 1	X1: DI2	X1: DI 1	
1	X8: MCT OV	X7: MCT OV	X6: MCT OV	X5: MCT OV	X4: MCT OV	X3: MCT OV	X2: MCT OV	X1: MCT OV	X8: MCT UV	X7: MCT UV	X6: MCT UV	X5: MCT UV	X4: MCT UV	X3: MCT UV	X2: MCT UV	X1: MCT UV	
2	X8: BCT OV	X7: BCT OV	X6: BCT OV	X5: BCT OV	X4: BCT OV	X3: BCT OV	X2: BCT OV	X1: BCT OV	X8: BCT UV	X7: BCT UV	X6: BCT UV	X5: BCT UV	X4: BCT UV	X3: BCT UV	X2: BCT UV	X1: BCT UV	
3...6	Port X1: Mapping: Counter Data and Status (→ 47)																
7...10	Port X2: Mapping: Counter Data and Status (→ 47)																
11...14	Port X3: Mapping: Counter Data and Status (→ 47)																
15...18	Port X4: Mapping: Counter Data and Status (→ 47)																
19...22	Port X5: Mapping: Counter Data and Status (→ 47)																
23...26	Port X6: Mapping: Counter Data and Status (→ 47)																
27...30	Port X7: Mapping: Counter Data and Status (→ 47)																
31...34	Port X8: Mapping: Counter Data and Status (→ 47)																

Legend:

- DI1 Signal level digital input at pin 4 of the port (after filtering) 1 BIT • 0x0: LOW
 • 0x1: HIGH
- DI2 Signal level digital input at pin 2 of the port (after filtering) 1 BIT • 0x0: LOW
 • 0x1: HIGH
- MCT OV Overflow at the main counter 1 BIT • 0x0: no event
 • 0x1: Event overflow
- MCT UV Underflow at the main counter 1 BIT • 0x0: no event
 • 0x1: Event underflow
- BCT OV Overflow at the batch counter 1 BIT • 0x0: no event
 • 0x1: Event overflow
- BCT UV Underflow at the batch counter 1 BIT • 0x0: no event
 • 0x1: Event underflow

Mapping: Counter Data and Status

Register	Bit																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
n	Main Counter Value (Word 0)																
n+1	Main Counter Value (Word 1)																
n+2	Batch Counter Value																
n+3	res.	res.	res.	res.	res.	res.	MCT OV	MCT UV	res.	res.	res.	res.	res.	BCT OV	BCT UV		

Legend:

- Main Counter Value Current main counter value of the port 2 WORD • 0x0000 0000: 0
...
• 0xFFFF FFFE: 4294967294
- Batch Counter Value Current batch counter value of the port 1 WORD • 0x0000: 0
...
• 0xFFE: 65534
- MCT OV Overflow at the main counter 1 BIT • 0x0: no event
• 0x1: Event overflow
- MCT UV Underflow at the main counter 1 BIT • 0x0: no event
• 0x1: Event underflow
- BCT OV Overflow at the batch counter 1 BIT • 0x0: no event
• 0x1: Event overflow
- BCT UV Underflow at the batch counter 1 BIT • 0x0: no event
• 0x1: Event underflow

11.1.1.2 Port Configuration - Digital Inputs (100 - 163)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
100...103	Port X1 - DI1: Filter Settings (→ Mapping: Filter Settings 49)															
104...107	Port X1 - DI2: Filter Settings (→ Mapping: Filter Settings 49)															
108...111	Port X2 - DI1: Filter Settings (→ Mapping: Filter Settings 49)															
112...115	Port X2 - DI2: Filter Settings (→ Mapping: Filter Settings 49)															
116...119	Port X3 - DI1: Filter Settings (→ Mapping: Filter Settings 49)															
120...123	Port X3 - DI2: Filter Settings (→ Mapping: Filter Settings 49)															
124...127	Port X4 - DI1: Filter Settings (→ Mapping: Filter Settings 49)															
128...131	Port X4 - DI2: Filter Settings (→ Mapping: Filter Settings 49)															
132...135	Port X5 - DI1: Filter Settings (→ Mapping: Filter Settings 49)															
136...139	Port X5 - DI2: Filter Settings (→ Mapping: Filter Settings 49)															
140...143	Port X6 - DI1: Filter Settings (→ Mapping: Filter Settings 49)															
144...147	Port X6 - DI2: Filter Settings (→ Mapping: Filter Settings 49)															
148...151	Port X7 - DI1: Filter Settings (→ Mapping: Filter Settings 49)															
152...155	Port X7 - DI2: Filter Settings (→ Mapping: Filter Settings 49)															
156...159	Port X8 - DI1: Filter Settings (→ Mapping: Filter Settings 49)															
160...163	Port X8 - DI2: Filter Settings (→ Mapping: Filter Settings 49)															

Mapping: Filter Settings

Word (Offset)	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	reserved								res.	INV						
n+1	reserved								res.	HL						
n+2	Debounce Time															
n+3	Hold Time															

Legend:

- INV Invert: signal inversion 1 BIT • 0x0: do not invert (default)
 • 0x1: invert
- HL Hold Level: Signal level to be maintained 1 BIT • 0x0: LOW
 • 0x1: HIGH (default)
- Debounce Time Debounce time (value in *0.1 milliseconds) 1 WORD • 0x0000: 0 ms (default)
 ...
 • 0x01F4: 50 ms
- Hold Time Hold time (value in *0.1 milliseconds) 1 WORD • 0x0000: 0 ms (default)
 ...
 • 0xEA60: 600 ms

11.1.1.3 Port Configuration - Counter (200 - 271)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
200...208	Port X1 : Counter Configuration (→ Mapping: Counter Configuration 51)															
209...217	Port X2 : Counter Configuration (→ Mapping: Counter Configuration 51)															
218...226	Port X3 : Counter Configuration (→ Mapping: Counter Configuration 51)															
227...235	Port X4 : Counter Configuration (→ Mapping: Counter Configuration 51)															
236...244	Port X5 : Counter Configuration (→ Mapping: Counter Configuration 51)															
245...253	Port X6 : Counter Configuration (→ Mapping: Counter Configuration 51)															
254...262	Port X7 : Counter Configuration (→ Mapping: Counter Configuration 51)															
263...271	Port X8 : Counter Configuration (→ Mapping: Counter Configuration 51)															

Mapping: Counter Configuration

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	Counter Mode															
n+1	Pin 2 Function															
n+2	Counter Direction Select															
n+3	Main Threshold (Word 0)															
n+4	Main Threshold (Word 1)															
n+5	Batch Threshold															
n+6	Force Main Counter (Word 0)															
n+7	Force Main Counter (Word 1)															
n+8	Force Batch Counter															

Legend:

- Counter Mode Operating mode of the counter module 1 WORD
 - 0x0000: CTU – up counter (default)
 - 0x0001: CTD – down counter
 - 0x0002: CTUD – up and down counter
 - 0x0003: CTDIR – up or down counter
- Pin 2 Function Pin 2 function of the port 1 WORD
 - 0x0000: N/C – no function (default)
 - 0x0001: counter Edge Input 2 – counting input
 - 0x0002: Count direction – select counting direction
 - 0x0003: Reset Main + Batch Counter – reset counter module
 - 0x0004: Disable Main + Batch Counter – disable counter module
- Counter Direction Select Instance for selecting the counting direction 1 WORD
 - 0x0000: Pin 2 (default)
 - 0x0001: PLC
- Main Threshold Threshold CT of the main counter
MainThreshold = 0x01234567 2 WORD
 - MainThreshold[0] = 0x0123
 - MainThreshold[1] = 0x4567
 - 0x0000 0001: 1
 - ...
 - 0xFFFF FFFF: 4294967295 (default)
- Batch Threshold Threshold CTb of the batch counter 1 WORD
 - 0x0001: 1
 - ...
 - 0xFFFF: 65535 (default)
- Force Main Counter Set counter value of the main counter
ForceMainCounter = 0x01234567 2 WORD
 - 0x0000 0000: 0
 - ...
 - 0xFFFF FFFE: 4294967294 (default)
- Force Batch Counter Set counter value of the batch counter 1 WORD
 - 0x0000: 0
 - ...
 - 0xFFFF: 65534 (default)

11.1.1.4 Port Output - Counter (300 - 355)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
300...306	Port X1: Output Counter (→ Mapping: Output Counter 53)															
307...313	Port X2: Output Counter (→ Mapping: Output Counter 53)															
314...320	Port X3: Output Counter (→ Mapping: Output Counter 53)															
321...327	Port X4: Output Counter (→ Mapping: Output Counter 53)															
328...334	Port X5: Output Counter (→ Mapping: Output Counter 53)															
335...341	Port X6: Output Counter (→ Mapping: Output Counter 53)															
342...348	Port X7: Output Counter (→ Mapping: Output Counter 53)															
349...355	Port X8: Output Counter (→ Mapping: Output Counter 53)															

Mapping: Output Counter

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	reserved							res.	DIS							
n+1	reserved							res.	DIR							
n+2	reserved							res.	RST MC OV							
n+3	reserved							res.	RST MC UV							
n+4	reserved							res.	RST BC OV							
n+5	reserved							res.	RST BC UV							
n+6	reserved							res.	RST CT							

Legend:

- DIS Disable Counter: disable main counter + batch counter 1 BIT • 0x0: no action
 • 0x1: disable main and batch counter
- DIR Counter Direction: Set counting direction (valid only for counter mode CTDIR) 1 BIT • 0x0: up
 • 0x1: down
- RST MC OV Reset Main Counter Overflow: Reset counter event overflow of the main counter 1 BIT • 0x0: no action
 • 0x1: Rest overflow event
- RST MC UV Reset Main Counter Underflow: Reset counter event underflow of the main counter 1 BIT • 0x0: no action
 • 0x1: Reset underflow event
- RST BC OV Reset Batch Counter Overflow: Reset counter event overflow of the batch counter 1 BIT • 0x0: no action
 • 0x1: Rest overflow event
- RST BC UV Reset Batch Counter Underflow: Reset counter event underflow of the batch counter 1 BIT • 0x0: no action
 • 0x1: Reset underflow event
- RST CT Reset main counter and batch counter to initial value 1 BIT • 0x0: no action
 • 0x1: reset main + batch counter and counter events to overflow/underflow

11.1.1.5 Block Configuration (400 - 408)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
400	X8: DI2 INV	X8: DI1 INV	X7: DI2 INV	X7: DI1 INV	X6: DI2 INV	X6: DI1 INV	X5: DI2 INV	X5: DI1 INV	X4: DI2 INV	X4: DI1 INV	X3: DI2 INV	X3: DI1 INV	X2: DI2 INV	X2: DI1 INV	X1: DI2 INV	X1: DI1 INV
401	X8: DI2 HL	X8: DI1 HL	X7: DI2 HL	X7: DI1 HL	X6: DI2 HL	X6: DI1 HL	X5: DI2 HL	X5: DI1 HL	X4: DI2 HL	X4: DI1 HL	X3: DI2 HL	X3: DI1 HL	X2: DI2 HL	X2: DI1 HL	X1: DI2 HL	X1: DI1 HL
402	reserved								X8: DIS	X7: DIS	X6: DIS	X5: DIS	X4: DIS	X3: DIS	X2: DIS	X1: DIS
403	reserved								X8: DIR	X7: DIR	X6: DIR	X5: DIR	X4: DIR	X3: DIR	X2: DIR	X1: DIR
404	reserved								X8: RST MC OV	X7: RST MC OV	X6: RST MC OV	X5: RST MC OV	X4: RST MC OV	X3: RST MC OV	X2: RST MC OV	X1: RST MC OV
405	reserved								X8: RST MC UV	X7: RST MC UV	X6: RST MC UV	X5: RST MC UV	X4: RST MC UV	X3: RST MC UV	X2: RST MC UV	X1: RST MC UV
406	reserved								X8: RST BC OV	X7: RST BC OV	X6: RST BC OV	X5: RST BC OV	X4: RST BC OV	X3: RST BC OV	X2: RST BC OV	X1: RST BC OV
407	reserved								X8: RST BC UV	X7: RST BC UV	X6: RST BC UV	X5: RST BC UV	X4: RST BC UV	X3: RST BC UV	X2: RST BC UV	X1: RST BC UV
408	reserved								X8: RST CT	X7: RST CT	X6: RST CT	X5: RST CT	X4: RST CT	X3: RST CT	X2: RST CT	X1: RST CT

Legend:

- DI1 INV Pin 4: signal inversion 1 BIT • 0x0: do not invert (default)
• 0x1: invert
- DI2 INV Pin 2: signal inversion 1 BIT • 0x0: do not invert (default)
• 0x1: invert
- DI1 HL Pin 4: Signal level to be maintained 1 BIT • 0x0: LOW
• 0x1: HIGH (default)
- DI2 HL Pin 2: Signal level to be maintained 1 BIT • 0x0: LOW
• 0x1: HIGH (default)
- DIS Disable Counter: disable main counter + batch counter 1 BIT • 0x0: no action (default)
• 0x1: disable main and batch counter
- DIR Counter Direction: Set counting direction (valid only for counter mode CTDIR) 1 BIT • 0x0: up (default)
• 0x1: down
- RST MC OV Reset Main Counter Overflow: Reset counter event overflow of the main counter 1 BIT • 0x0: no action (default)
• 0x1: Rest overflow event
- RST MC UV Reset Main Counter Underflow: Reset counter event underflow of the main counter 1 BIT • 0x0: no action (default)
• 0x1: Reset underflow event
- RST BC OV Reset Batch Counter Overflow: Reset counter event overflow of the batch counter 1 BIT • 0x0: no action (default)
• 0x1: Rest overflow event
- RST BC UV Reset Batch Counter Underflow: Reset counter event underflow of the batch counter 1 BIT • 0x0: no action (default)
• 0x1: Reset underflow event
- RST CT Reset main counter and batch counter to initial value 1 BIT • 0x0: no action (default)
• 0x1: reset main + batch counter and counter events to overflow/underflow

11.1.1.6 Byte Swap (500)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
500	Byte Swap															

Legend:

- Byte Swap Arrangement of the bytes in the data tables 1 WORD • 0x0000: Big Endian (default)
• 0xFFFF: Little Endian

11.1.1.7 Connection Timeout (510)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
510	Connection Timeout															

Legend:

- Connection Timeout Max. value for connection timeouts
(value in milliseconds) 1 WORD • 20: 20 ms
...
• 30000: 30 s (default)
...
• 60000: 60 s

11.1.1.8 DI Channel Mapping (550)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
550	reserved								res.	DI-CO						

Legend:

- DICO

DI Channel Order: Arrangement of the process data in registers 0, 400 and 401

1 BIT

- 0x0: Pin-based (default)
- 0x1: Port-based

Mapping: pin-based

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	X8: Pin 2	X7: Pin 2	X6: Pin 2	X5: Pin 2	X4: Pin 2	X3: Pin 2	X2: Pin 2	X1: Pin 2	X8: Pin 4	X7: Pin 4	X6: Pin 4	X5: Pin 4	X4: Pin 4	X3: Pin 4	X2: Pin 4	X1: Pin 4

Mapping: port-based

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
n	X8: Pin 2	X8: Pin 4	X7: Pin 2	X7: Pin 4	X6: Pin 2	X6: Pin 4	X5: Pin 2	X5: Pin 4	X4: Pin 2	X4: Pin 4	X3: Pin 2	X3: Pin 4	X2: Pin 2	X2: Pin 4	X1: Pin 2	X1: Pin 4

11.1.1.9 System Command (600)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
600	Command ID															

Legend:

- Command ID Identifier of the command 1 WORD
- 0x0040: Restarting the device
- 0x0050: Resetting the device

11.1.1.10 Diagnostic Data (2000 - 2002)

Register	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
2000	reserved								res.	PSE						
2001	Uptime															
2002	Disconnection Counter															

Legend:

- PSE Power Status Error: Status of the voltage supply 1 BIT
 - 0x0: No error
 - 0x1: Error
- Uptime Time since the last start of the device (value in minutes) 1 WORD
 - 0x0000: 0 min
 - ...
 - 0xFFFF: 65535 min
- Disconnection Counter The counter for connection interruptions (by user or by connection timeout) since the last start of the device; The counter is reset when the device is restarted 1 WORD
 - 0x0000: 0 interruptions
 - ...
 - 0xFFFF: 65535 interruptions