# BVLLAL

# BNI PBS-502-101-Z001 Profibus IO-Link Master User's Guide



### Contents

1	Notes for the user 1.1 Structure of the manual	<b>4</b> 4
	1.2 Typographical conventions Enumerations	4
	Actions	4
	Syntax Cross-references	4
	1.3 Symbols	4
	1.4 Abbreviations	4
	1.5 Divergent views	4
2	Safety 2.1 Intended use	5
	1.1. Installation and Startup	5
	2.2 General safety notes	5
	1.2. Resistance to Aggressive Substances Dangerous Voltage	5
3	Connection overview	6
	3.1 Connection overview BNI PBS-502-101	6
4	Basic knowledge	7
	4.2 Profibus	7
	4.3 IO-Link	7
	4.4 Communication mode Standard	8
	IO mode	8
	(SIO mode)	8
F		0
5	5.1 Dimensions	<b>9</b>
	5.2 Mechanical data	9
	5.3 Electrical data 5.4 IO-Link data	9
	5.5 Operating conditions	9
6	Installation	10
	6.1 Mechanical connection	10
	Function ground	10
	Supply voltage	11
	6.3 Bus connection 6.4 Ports	12
	I/O ports	13
	IO-Link port	13
_	6.5 Replacing BNI PBS modules	13
7	Startup 7.1. Profibus address	<b>14</b>
	Addressing	14
	Menu structure	14
	7.2 Integration in project planning software	14 15
	Installing the GSD file	15
	Specifying the properties	16
	Port functions	16
	Safe state	16

		Configuring the slots	17
		Auxiliary modules	17
		IO-Link configuration	18
	70	Parameter server	19
	7.3	Configuration via nex string	20
	7.4	Hey parameters for the modules	20
		Hex parameters for the modules	22
	7.5	Parameterizing the modules	23
		DPV1 statuses	23
	7.6	Header module	24
		Diagnostics	24
		Port configuration	24
		Sale state	25
		IO-I ink port x	27
	7.7	Bit mapping and function	29
		Inputs pin 4	29
		Inputs pin 2	29
		Outputs pin 4	29
		Outputs pin 2	29
		IU-LINK Modules	25
		Actuator deactivate pin 4	20
		Actuator warning pin 4	29
		Actuator warning pin 2	29
		Restart pin 4	29
		Restart pin 2	29
		Switching IO-Link diagnostics on / off	30
		IO-LINK communication Perinheral error, socket	30
		Sensor supply	30
		Short circuit	30
		Station diagnostics	30
		Display LED	30
	7.8	IO-Link functions	31
		Cycle settings	3
		Dala Section	
		Validation	31
		Validation Parameter server	31 31 31
Q	C	Validation Parameter server	31 31 31
8	C	Validation Parameter server configuration of IO-Link devices Telegram structure	31 31 31 32 32
8	C	Validation Parameter server configuration of IO-Link devices Telegram structure	31 31 32 32 32
8 9	<b>C</b> Di 9.1	Validation Parameter server configuration of IO-Link devices Telegram structure Diagnostics Function Indicators	31 31 31 32 32 33 33
8 9	<b>C</b> d <b>D</b> i 9.1	Validation Parameter server configuration of IO-Link devices Telegram structure Diagnostics Function Indicators LED indicators	31 31 32 32 33 33 33 33 33
8 9	<b>C</b> d Di 9.1	Validation Parameter server Configuration of IO-Link devices Telegram structure Diagnostics Function Indicators LED indicators Module LEDs	31 31 32 32 33 33 33 33 33 33 33
8 9	<b>C</b> d Di 9.1	Validation Parameter server Configuration of IO-Link devices Telegram structure Diagnostics Function Indicators LED indicators Module LEDs I/O port LEDs	31 31 32 32 33 33 33 33 33 33 33 33
8 9	<b>D</b> i 9.1	Validation Parameter server Configuration of IO-Link devices Telegram structure Viagnostics Function Indicators LED indicators Module LEDs I/O port LEDs IO-Link port LEDs Parameter insert	31 31 32 32 33 33 33 33 33 33 33 33 33
8 9	<b>C</b> Di 9.1	Validation Parameter server Configuration of IO-Link devices Telegram structure Diagnostics Function Indicators LED indicators Module LEDs I/O port LEDs IO-Link port LEDs Diagnostics input	31 31 32 32 33 33 33 33 33 33 33 33 33 33 33
8	<b>D</b> i 9.1 9.2 9.3	Validation Parameter server Configuration of IO-Link devices Telegram structure Diagnostics Function Indicators LED indicators Module LEDs I/O port LEDs IO-Link port LEDs Diagnostics input Diagnostics telegram Norm diagnostics	31 31 32 32 33 33 33 33 33 33 33 34 34 34
8	<b>C</b> Di 9.1 9.2 9.3	Validation Parameter server Configuration of IO-Link devices Telegram structure Diagnostics Function Indicators LED indicators Module LEDs I/O port LEDs I/O port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding	31 31 32 32 33 33 33 33 33 33 34 34 34 34
8	<b>C</b> Di 9.1 9.2 9.3	Validation Parameter server Sonfiguration of IO-Link devices Telegram structure Viagnostics Function Indicators LED indicators Module LEDs I/O port LEDs I/O port LEDs IO-Link port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding Status 1	31 31 32 32 33 33 33 33 33 33 34 34 34 34 34 34
8	<b>C</b> Di 9.1 9.2 9.3	Validation Parameter server Configuration of IO-Link devices Telegram structure Viagnostics Function Indicators LED indicators Module LEDs I/O port LEDs I/O port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding Status 1 Status 2	31 31 32 32 33 33 33 33 33 33 34 34 34 34 34 34 34
8	<b>D</b> i 9.1 9.2 9.3	Validation Parameter server Configuration of IO-Link devices Telegram structure Diagnostics Function Indicators LED indicators Module LEDs I/O port LEDs IO-Link port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding Status 1 Status 2 Status 3	31 31 32 32 33 33 33 33 33 33 33 33 34 34 34 34 34
8	<b>D</b> i 9.1 9.2 9.3	Validation Parameter server Configuration of IO-Link devices Telegram structure Diagnostics Function Indicators LED indicators Module LEDs I/O port LEDs IO-Link port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding Status 1 Status 2 Status 3 Address Ident Number	31 31 32 32 33 33 33 33 33 33 33 34 34 34 34 34 34
8	<b>C</b> <b>D</b> 9.1 9.2 9.3	Validation Parameter server <b>Sonfiguration of IO-Link devices</b> Telegram structure <b>Diagnostics</b> Function Indicators LED indicators Module LEDs I/O port LEDs I/O port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding Status 1 Status 2 Status 3 Address Ident_Number_ High Bute	31 31 32 32 33 33 33 33 33 33 34 34 34 34 34 34 34
8	<b>C</b> i Di 9.1 9.2 9.3	Validation Parameter server <b>Sonfiguration of IO-Link devices</b> Telegram structure <b>Diagnostics</b> Function Indicators LED indicators Module LEDs I/O port LEDs I/O port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding Status 1 Status 2 Status 3 Address Ident_Number_ High_Byte Ident Number	31 31 32 32 33 33 33 33 34 34 34 34 34 34 34 34 35 35 35 35 35
8	<b>C</b> Di 9.1 9.2 9.3	Validation Parameter server <b>configuration of IO-Link devices</b> Telegram structure <b>biagnostics</b> Function Indicators LED indicators Module LEDs I/O port LEDs I/O port LEDs IO-Link port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding Status 1 Status 2 Status 3 Address Ident_Number_ High_Byte Ident_Number_ Low Byte	31 31 32 32 33 33 33 33 33 34 34 34 34 34 34 34 34
8	<b>C</b> Di 9.1 9.2 9.3 9.3	Validation Parameter server <b>configuration of IO-Link devices</b> Telegram structure <b>biagnostics</b> Function Indicators LED indicators Module LEDs I/O port LEDs I/O port LEDs IO-Link port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics coding Status 1 Status 2 Status 3 Address Ident_Number_ High_Byte Ident_Number_ Low_Byte Device-specific diagnostics	31 31 31 32 32 33 33 33 33 34 34 34 34 34 34 34 34 34
8	<b>C</b> Di 9.1 9.2 9.3	Validation Parameter server <b>Sonfiguration of IO-Link devices</b> Telegram structure <b>Diagnostics</b> Function Indicators LED indicators Module LEDs I/O port LEDs I/O port LEDs Diagnostics input Diagnostics telegram Norm diagnostics Norm diagnostics Norm diagnostics coding Status 1 Status 2 Status 3 Address Ident_Number_ High_Byte Ident_Number_ Low_Byte Device-specific diagnostics Coding for devicespecific diagnostics	31 31 32 32 33 33 33 33 33 33 34 34 34 34 34 34 34

Status type	36
Slot number	36
Status specifier	36
Status message 1	36
Status message 2	36
9.5 ID-specific diagnostics	37
Coding for identifierspecific diagnostics	37
Header	37
Modules	37
9.6 Channel-dependent diagnostics	38
Coding for devicespecific diagnostics	38
Header	38
Channel	38
Error	38
10 Appendix	39
10.1 Scope of delivery	39
10.2 Order code	39
10.3 Ordering information	39
10.4 ASCII table	40

### 1 Notes for the user

1.1	Structure of the manual	The manual is Section 2: Basi	organized so that the sections build on each other. ic safety information.
1.2	Typographical conventions	The following t	ypographical conventions are used in this guide
	Enumerations	Enumerations Entry Entry	are shown in list form with bullet points 1 2
	Actions	Action instructi by an arrow. ▷ Action ▷ Action	ons are indicated by a preceding triangle. The result of an action is indicated instruction 1, on result. i instruction 2.
	Syntax	Numbers: Decimal number Hexadecimal n Menu comman Menu comman menu comman Buttons: Buttons are she	ers are shown without additional indicators (e.g. 123), umbers are shown with the additional indicator hex (e.g. 00hex). <b>nds:</b> ds are separated by a vertical line. "Tools   Install new GSD" refers to the d "Install new GSD" from the "Tools" menu. own in brackets, e.g. [Install].
	Cross-references	Cross-referenc	es indicate where additional information on the topic can be found.
1.3	Symbols	i Note This	e symbol indicates general notes.
		Atte This exce	ntion! symbol indicates a safety instruction that must be followed without aption.
1.4	Abbreviations	BCD BNI EMC FE GSD file I-port LSB MSB O-port PELV PLC Profibus-DP SELV	Binary coded switch Balluff Network Interface Electromagnetic Compatibility Function ground Generic Station Description Digital input port Least Significant Bit Most Significant Bit Digital output port Protective Extra Low Voltage Programmable Logic Controller Profibus Decentralized Periphery Safety Extra Low Voltage
1.5	Divergent views	Product views only as an illus	and images can differ from the specified product in this manual. They serve tration.

2.1 Intended use	The BNI PBS serves as a decentralized input and output module for connecting to a Profibus-DP network. The integrated IO-Link ports enable simple linking of IO-Link capable sensors and actuators. The module may be used only for this purpose in an industrial environment corresponding to Class A of the EMC Law.
1.1. Installation and Startup	Attention! Installation and startup are to be performed by trained technical personnel only. Skilled specialists are people who are familiar with the work such as installation and the operation of the product and have the necessary qualifications for these tasks. Any damage resulting from unauthorized tampering or improper use shall void warranty and liability claims against the manufacturer. The operator is responsible for ensuring that the valid safety and accident prevention regulations are observed in specific individual cases.
2.2 General safety notes	<ul> <li>Commissioning and inspection Before commissioning, carefully read the User's Guide. The system must not be used in applications in which the safety of persons depends on the function of the device. Intended use Warranty and liability claims against the manufacturer shall be rendered void by damage from: <ul> <li>Unauthorized tampering</li> <li>Improper use</li> <li>Use, installation or handling contrary to the instructions provided in this User's Guide.</li> </ul> </li> <li>Obligations of the owner/operator!</li> <li>The device is a piece of equipment in accordance with EMC Class A. This device can produce RF noise. The owner/operator must take appropriate precautionary measures against this for its use. The device may be used only with a power supply approved for this. Only approved cables may be connected. Malfunctions In the event of defects and device malfunctions that cannot be rectified, the device must be taken out of operation and protected against unauthorized use. Approved use is ensured only when the housing is fully installed.</li></ul>
1.2. Resistance to Aggressive Substances	Attention! The BNI modules always have good chemical and oil resistance. When used in aggressive media (such as chemicals, oils, lubricants and coolants, each in a high concentration (i.e. too little water content)), the material must first be checked for resistance in the particular application. No defect claims may be asserted in the event of a failure or damage to the BNI modules caused by such aggressive media.
Dangerous Voltage	Attention! Before working on the device, switch off its power supply.
	<b>Note</b> In the interest of continuous improvement of the product, Balluff GmbH reserves the right to change the technical data of the product and the content of these instructions at any time without notice.

#### 3 **Connection overview**

3.1 Connection overview BNI PBS-502-101...



- Mounting hole 1
- Profibus input 2
- Power input 3
- Port 1 (standard I/O) 4
- Port 3 (standard I/O) 5
- Port 5 (IO-Link/standard I/O) 6
- Port 7 (IO-Link/standard I/O) Port 6 (IO-Link/standard I/O) 7
- 8
- Port 4 (IO-Link/standard I/O) 9
- 10 Designation IO-Link port

- Port 2 (standard I/O) 11
- Port LEDs 12
- Port 0 (standard I/O) 13
- 14 Module LEDs
- 15 Power output
- 16 Part label
- 17 Display18 Profibus output
- 19 Ground

## 4 Basic knowledge

4.1	Product description	Balluff Network Interface BNI PBS: Used for connecting sensors/actuators to a Profibus-DP network. Sensors/actuators can be connected through 8 standard I/O ports. Connection to Profibus using 2 × M12×1 round connectors. Electrical power 24 V DC using 7/8" round connector.
		Connection options: A total of 8 ports that can be freely configured are available, each with 2 switching contacts.
		<ul> <li>The main areas of application are:</li> <li>In the industrial area as an interface between sensors/actuators and a Profibus.</li> <li>When using "intelligent" sensors and actuators which process information in addition to the actual process signal (e.g. diagnostics information).</li> </ul>
4.2	Profibus	Open bus system for process and field communication in cell networks with a low number of stations as well as for data communication per IEC 61158/EN 50170. Automation devices such as PLCs, PCs, control and monitoring devices, sensors or actuators can communicate over this bus system.
		<ul> <li>Variants:</li> <li>Profibus DP for fast, cyclical data exchange with field devices,</li> <li>Profibus PA for applications in process automation in the intrinsically safe area,</li> <li>Profibus FMS for data communication between automation devices and field devices.</li> </ul>
4.3	IO-Link	IO-Link is defined as a standardized point-to-point connection between sensors/actuators and the I/O module. An IO-Link sensor/actuator can send additional communication data (e.g. diagnostics signals) in addition to the binary process signals over the IO-Link interface.
		<ul> <li>Compatibility with standard I/O: <ul> <li>IO-Link sensors can be connected to existing I/O modules.</li> <li>Sensors/actuators which are not IO-Link capable can be connected to an IO-Link module.</li> <li>Standard sensor/actuator cable can be used.</li> </ul> </li> </ul>
		<ul> <li>Key technical data:</li> <li>Serial point-to-point connection,</li> <li>Communication as add-on to standard I/O.</li> <li>Standard I/O connection technique, unshielded, 20 m cable length.</li> <li>Communication using 24V pulse modulation, standard UART protocol.</li> <li>Maximum current draw: per sensor 200 mA/per actuator 1.6 A.</li> </ul>
		Module developed according to IO-Link specification 1.1

### 4 Basic knowledge

4.4	Communication mode	<ul> <li>Process data (cyclical):</li> <li>The GSD file provides different data modules for representing the sensor map: <ul> <li>Inputs: 1 byte – 32 bytes</li> <li>Outputs: 1 byte – 32 bytes</li> <li>or combined input/output modules</li> </ul> </li> </ul>
		<ul> <li>Deterministic time behavior:</li> <li>Typically 2 ms cycle time for 16 bits of process data and 38.4 Kbaud transmission rate.</li> </ul>
		Service data (diagnostics, parameters): • Parallel and reactionless process data
	Standard IO mode (SIO mode)	<ul> <li>Startup parameter setting possible using communication, then</li> <li>binary switching signal</li> </ul>
4.5	Replacing modules	The BNI PBS modules are upward compatible. A defective module can be replaced with a module which has a greater or at least the same functionality.

### 5 Technical data

### 5.1 Dimensions



5.2	Mechanical data	Housing material	Die-case zinc, matte nickel plated
		Fieldbus	Profibus: M12, B-coded (male and female)
		Power supply	5-pin, 7/8" (male and female)
		I/O ports	M12, A-coded (8x female)
		Enclosure rating	IP67 (only when plugged-in and screwed-in)
		Weight	approx. 735 g
5.3	Electrical data	Operating voltage	18 30 V DC
		Ripple	< 1 %
		Current draw without load	≤ 200 mA
		Service interface	Balluff
5.4	IO-Link data	Baudr rate	COM 1, 2, 3
		Frame type	1, 2.x, 3
		Minimum cycle time	2.3 ms
5.5	Operating conditions	Operating temperature Storage temperature range	-5 C 70°C -25 C 70°C

6.1 Mechanical connection



The BNI PBS-... module can be connected directly to a mounting wall or to a machine. Be sure that the mounting base is flat to prevent any mechanical stress on the device housing.

Two M6 screws and two washers are required for mounting. The tightening torque is 9 Nm.

#### Installation:

- Attach module using two M6 screws and 2 washers.
- Keep a distance of at least 3 mm between two modules.

The BNI PBS-... is attached using two max. M6 screws and two washers.

### Note Reco

**Recommended hole dimension:** 210.5 ±0.2 mm (when using M6 screws!). All IP67 Profibus/Profinet splitter boxes can be mounted when this hole diameter is used.

**6.2 Electrical** The ground connection for the BNI PBS-... modules is located at upper left next to the mounting hole.

Ground straps are preferred for the ground connection. Alternately a fine-strand PE wire with large cross-section may be used.

#### **Function ground**





Note

The FE connection from the housing to the machine must be low-impedance and kept as short as possible.

Supply voltage

## Profibus modules require a DC voltage of 24 V DC (SELF/PELF) for power. The power can be provided by regulated and unregulated power supplies. Regulated power supplies allow the output voltage to be increased above the nominal voltage to compensate for line losses.

Attention! The use of a Profibus hybrid cable is not permitted.

#### Power IN (7/8", 5-pin, male) Power OUT (7/8", 5-pin, female)



- 24 V DC.
- Use different power sources for the sensor/bus and for the actuator if possible to minimize noise susceptibility.
- Total current < 9 A. The total current of all modules may not exceed 9 A even when daisy chaining the actuator supply.



Module and connected sensors are powered by the "module and sensor supply", while the "actuator supply" powers all outputs. The only exception is pin 4 on all IO Link ports. Here the outputs are powered by the sensor supply.



### Note

The sensor supply and actuator supply should be powered from different electricity sources wherever possible.

0 V

FE

+24V

+24V

#### 6.3 Bus connection

The bus connection is made using the M12 sockets Profibus IN and Profibus OUT. The address is set on the address switch.

	Profibus OUT (M12, B-coded, female)	Profibus IN (M12, B-coded, male)	PIN	Function
ſ	$\bigcirc$		1	VP(+5V)
		4	2	RxD/TxD-N, A line (green)
			3	DGND
	6501/		4	RxD/TxD-P, B line (red)
	3 2 2	2 3	5	n.c.
			Thread	Shield/FE

#### **Connection information**



Connect protective ground to FE

Connect the incoming Profibus line to Profibus IN
 Connect the secondary Profibus line to Profibus OUT and connect to downstream device or use terminating resistor.

#### Note Each

Each Profibus segment must be terminated with a bus terminator. The termination resistor requires no external voltage. Unused sockets must be fitted with cover caps to ensure IP 67 protection rating.



#### Attention!

Pin 1 on the male connector (VP) is only required for the terminating resistor and is coupled via the Profibus. Any voltages connected directly to the pin may damage the module.

6.4 Ports

# Eight I/O ports (standard I/O and/or IO-Link) are provided for connecting the actuators/sensors.

I/O ports

#### Standard I/O port M12, A-coded, female

1 2	PIN	Function
	1	+ 24 V, max. 200mA
(""")	2	Input / output max. 2A / diagnostics input
\@50/	3	0 V / GND
4 3	4	Input / output max. 2A
	5	FE

#### Note For th

For the digital sensor inputs, read the input guideline specified in EN 61131-2, Type 2.

#### **IO-Link port**

### IO-Link port M12, A-coded, female

1 2	PIN	Function
	1	+24 V DC, 1.6A
("@")	2	Input / output max. 2A / diagnostics input
\@5@/	3	0 V / GND
4 3	4	IO-Link / input / output max. 1.6A
- <b>v</b>	5	n.c.



### Note

Due to limited CPU resources, only a maximum of three IO-Link-devices with COM3 speed can be reliably handled. It is therefore recommended not to use all 4 IO-Link-Ports for COM3 IO-Link Devices simultaneously.

- 6.5 Replacing BNI PBS modules
- Turn off power to the Profibus module,
- remove the mounting screws,
- replace the unit.

7.1 Profibus address

The Profibus address is set directly on the BNI PBS-... using two buttons on the display. Permissible address range 0...125.

Addressing



Each Profibus node must have a unique address assigned to it. The address is loaded once from the hard disk after the power is turned on. Any change to the address is saved immediately but does not become effective until power is reset on the module.

**Menu structure** The display on the BNI PBS-xxx-101-Z001 has the following menu structure. You can navigate between the different menu items using the buttons.



#### Address setting

The bus address is set on the display. Editing mode is activated when the "S" button is pressed for longer than 3s. A flashing status value indicates that editing mode is active. In this case, pressing the " $\uparrow$ " button increases the value by one. When the required value is reached, the next status value can be selected by pressing the "S" button again. The value is changed by pressing the " $\uparrow$ " button.

Pressing the "S" button in editing mode for more than approx. 10s saves the address currently selected. Although this address is saved, it is not yet active. The display LEDs and address flash to indicate that this status is active. The new address is only adopted after the power is reset.

If no buttons are pressed in editing mode within 10 seconds, the module exits editing mode without saving the address.

The display buttons can be locked by the PLC. A key symbol on the display indicates that this status is active.

7.2 Integration in project planning software

> Installing the GSD file

The example shows the connection of the BNI PBS modules to a Siemens S7 controller with "SIMATIC Manager". The exact procedure depends on the project planning software used

To perform project planning on the PC, the GSD file for the module must be installed:

- Open a new project.
- ≻ Open hardware configurator.
- Select menu command "Tools | Install new GSD ... ". ≻
- ₿ The window "Install new GSD" opens.
- Select directory and GSD file. ≻
- ₿ The [Install] button only becomes active if a GSD file is selected.
- ≻ Click on [Install].
- ₿ The GSD file is installed.
- When the process is finished, a message appears. P
- Confirm the message and close the window.  $\triangleright$
- ► ₽ Select the menu command "Tools | Update catalog".
- The modules are displayed in the product tree and can be integrated in a Profibus network.

·	Bearbeiten Einfügen	Ansicht Egtras Eenste	a Huge				
20) UR 2 2 3 3 3 3 7 1 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	CPU 319-3 PN/DI MBP/DP DP PN/D PN/D Por 1		PROFIBUS(1): DI	naster system	x (1)	< <u> </u>	Suchen Profit 9 ET 2005P 9 ET 2005P 9 ET 2006 9 ET
						-	B Chatgeräte
(2)	BNI PBS 502-101-2001		1	1	1	,	B SIMADYN B SIMATIC B SIMODRIVE B SIMOREG
(2) sckplalz	BNI PBS 502-101-2001	Bestelmunner / Bezeichnung	E-Adresse	AAdesse	Kommentar	,	B SMADYN B SMATIC B SMATIC SMORE SMOREG B SMOVENT
nte (2) eckplatz	III BNI PBS 502-101-2001	Bestelhummer / Bezeichnung BNI PBS 502-101-2001 Standard V/D	E-Adresse	AAdresse	Kommentar	,	B SIMADYN B SIMADYN B SIMATIC B SIMOPRIYE B SIMOPRIYE B SIMOYERT B SINAMICS B SINAMICS
international (2) International (2)	III BNI PBS-502-101-2001 DP-Kennung 0 0 0 0	Bestelhummer / Beseichnung BNI PBS 502-101-2001 Standerd I/O Standerd I/O	E-Adresse	AAdesse	Kommentas	,	Simagram     SMADYN     SMADYN     SMADTC     SMADRVE     SMOREG     SMOREG     SMAMCS     SMAMCS     SMAMCS     SMASH     SMASH
itz) ekplatz	III BNI PB5-502-101-2001 DP-Kennung 0 0 0 0 0 0 0	Bestelmunner / Bezeichnung BNI PES 502-101-2001 Standard I/O Standard I/O Standard I/O	E-Adesse	Addesse	Kommentas	•	SAADYN     SAADYN     SAADYN     SMODRIVE     SMODRIVE     SMODRIVE     SMOVER1     SMAMICS     SMAMICS     SMAMICS     SMAMICS     Weiter FELDGERÄTE     SMAMICS     Weiter
nter (2) rek platz	" BNI PBS 502101-2001 DP-Kennung 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Bestelnummer / Bezeichnung BNI PBS 502-101 2001 Standard I/O Standard I/O Standard I/O Standard I/O	E-Adesse	A-Adresse	Kommentar	•	SAMATIC     S
ing [2] ckplatz	" BNI PB5 502-101-2001 DP-Kennung 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Bestellinumeer / Beseichnung BNI PRS 502-101-2001 Standard I/O Standard I/O Standard I/O Standard I/O	E-Adresse	Addesse	Kommeniae	•	SAMADYN     SAMADYN     SAMATIC     S
ili) ckplatz	**************************************	Bestelnummer / Beosichnung BNI PSS 502-107-2007 Standard I/O Standard I/O Standard I/O Standard I/O	E-Adresse	Addesse	Kommerilas	,	SSM40YN SSM00RVE SSM00RVE SSM00RVE SSM0VERT SSM
ili) ckplatz	"     "	Bestellhummer / Besondraung BNI PES 502-101-2001 Standard I/O Standard I/O Standard I/O Standard I/O	E-Adresse	Adesse	Kommentas	,	SAMATYN     SAMATYN     SAMATYC     S
nte la	BNI PBS 502-101 2001     DP-Kennung     0     0     0     0     0     0     0     0     0	Bestelhummer / Begenchung Bini 1955 500: 100 2001 Standard I/D Standard I/D Standard I/D	E-Adresse	Adesse	Kommentar	,	SH40YN SHATC SHAT
nte platz	BNI P85 502-101-2001     DP-Kennung     0     0     0     0     0     0     0	Bestelhummer / Bezenkruung BNI PES-502-107-2001 Standerl // 0 Standerl // 0 Standerl // 0 Standerl // 0	E-Adresse	Addesse	Konmentar	,	S SMADYN     SMADYN     SMADTC     SMADTC     SMADR×E     SMADR×E     SMADR×E     SMADR×E     SMAREG     SMADR×E     SMANES     SPOS
ckplatz	"      "      "	Bestelhummer / Bezenhrung BNI 1955-502-103-2001 Standed I/O Standed I/O Standed I/O	E-Adresse	Addresse	Kommentar	,	SIMADYN     SIMADYN     SIMADROV     S
(2) sckplatz	""     BNI P65-502-101-2001     DP⊀errung     0	Bestelhummer / Besenchrung Bini PES 502-107 2001 Standard I/10 Standard I/10 Standard I/10	E-Adresse	A-Aubesse	Kommentas	, 	S SM40/W     SM00RVE     SM00RVE     SM00RVE     SM00RVE     SM00RVE     SM0VERT
(2) eckplatz	" BNI P65 502-101 2001  DPKenning  0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Bestelhummer / Becenchrung BNI PES-500:100 2001 Standoel // O Standoel // O Standoel // O Standoel // O	E-Adresse	AAdesse	Kommentar	, 	S SM40/W     SMATC
eckplatz	BN PR5 502-101 2001     D     P&enning     0	Bestelhummer / Becenchrung BNI 1955 502:101 Stardael I/O Stardael I/O Stardael I/O Stardael I/O	E-Adresse	Addesse	Konmenta	, 	S SM40/W     SM00RVE     SM00RVE     SM00RVE     SM00RVE     SM00RVE     SM00REG     SM0VERT
() eckplatz ) 1 2 3 4 5 5 3	ENI PR5 502 (101 2001     O	Bestelhummer / Becenchrung BNI PES-502-103-2001 Standoel-1/0 Standoel-1/0 Standoel-1/0 Standoel-1/0	E-Adresse	A-Adresse	Konmentar	, 	S SM40/W     SMATC     SMATC     SMOREG     SMORE
(III) eckplatz	BN PR5 502-101 2001     D     O	Bestelhummer / Beceschrung Bint PBS 505:207 Starded I/O Starded I/O Starded I/O Starded I/O	E-Adesse	A-Adesse	Konsentar	• 	S SM40/W     SM00Rev
eckplatz	ENI PR5 502 (10 2001     0	Bestelhummer / Becenchrung BNI PES-502-103-2001 Standoot I/O Standoot I/O Standoot I/O Standoot I/O	E-Adresse	A-Adlesse	Komenta	·	SAMAYN     SAMAYN     SAMATIC     SAM
sck.platz	BN P65-502-101-2001     D	Bestelhummer / Bezenchrung BNI 1955-502-107-2001 Stranded I/O Stranded I/O Stranded I/O Stranded I/O	E Adresse	AAukesse	Konsentar	·	SIMADYN     SIMADYN     SIMADYN     SIMADRES     SIM

The header module (BNI PBS-502-101-Z001) must always be assigned to slot 1. In the default configuration, the placeholder "Module standard I/O" is assigned to slots 2 to 5. The structure shown here [header module + 4x standard I/O] must always be maintained, whereby standard I/O can be replaced with IO-Link\_X/X.

Specifying the properties

- > Double-click the module in slot 1 (header module)
- ♥ The "Properties PROFIBUS Interface DP" window opens.
- > The functions of the respective pin can be configured under "Parameterize".

Parameter	Wert	<u> </u>
🖃 🚔 Stationsparameter		
🖃 🔄 Gerätespezifische Parameter		
—≝ Global diagnostic	enable	
————————————————————————————————————	enable	=
— Low voltage bus/sensor supply	Report	
— Low voltage actuator supply	Report	
—	disable	
- Function Port 0 Pin 4 (Ch00)	NO input	
– I Function Port 1 Pin 4 (Ch01)	NO input	
- Function Port 2 Pin 4 (Ch02)	NO input	
- Function Port 3 Pin 4 (Ch03)	NO input	
- Function Port 4 Pin 4 (Ch04)	IO-Link	
- Function Port 5 Pin 4 (Ch05)	NO input	
- Function Port 6 Pin 4 (Ch06)	NO input	
- Function Port 7 Pin 4 (Ch07)	NO input	
- Function Port 0 Pin 2 (Ch08)	NO input	
- Function Port 1 Pin 2 (Ch09)	NO input	
-III Function Port 2 Pin 2 (Ch10)	NO input	

Module settings

Global diagnostics:

- This function can be used to permit / suppress all diagnostics messages of the module. (optical diagnostics signals / diagnostic modules are not affected)
  Sensor supply under oftage:
- Sensor supply undervoltage:
- This function can be used to permit / suppress the diagnostics message Sensor supply undervoltage. (optical diagnostics signals / diagnostics modules are not affected)
- > Actuator supply undervoltage:
- This function can be used to permit / suppress the diagnostics message Actuator supply undervoltage. (optical diagnostics signals / diagnostics modules are not affected)
- > Display lock:
- > The address in the display can be locked to prevent manual access.

Port functions	NO contact	Input as NO contact
	NC contact	Input as NC contact
	Outputs	Output
	Diagnostics input	Desina function
	IO-Link	IO-Link function
	NO contact after	Parameterization via IO-Link,
	parameterization	followed by standard I/O function (NO contact)
	NC contact after	Parameterization via IO-Link,
	parameterization	followed by standard I/O function (NC contact)
Safe state	> This function	n is a supplement to an output configuration of the respective

For each port pin, a safe status can be predefined which is assumed in the event of a failure in bus communication.

#### **Configuring the** slots When an IO- Link interface is activated, the IO-Link module from the catalog, which corresponds to the process data of the IO-Link device must be integrated in the slots (2...5).

For example, IO-Link is the function selected for port 4 pin 4 in the header module on the previous page. Now the placeholder module (slot 2) related to the port must be deleted and an IO-Link module integrated. In this example, the IO-Link module IOL\_I\_2byte was selected, which is suitable for an IO-

Link device with a maximum of 2 bytes of input process data.

🖳 HW Konfig	g - [SIMATIC 300(1) (Konfigu	ration) CPU319_PBS_PNT WAND	]						
un <u>Station</u>	<u>Bearbeiten Einfügen Zie</u>	elsystem <u>A</u> nsicht E <u>x</u> tras <u>F</u> enst				- 5 ×			
🗋 🚔 🔓	8 🧞 🔿 I 🗞 🗈 I I	🛍 🋍 📳 📼 😤 🕅							
									. minut
500 LIR						Â.			
			PROFIE	3US(1)	): DP master system (1)		Suchen:	د	nt ni
1						-			
2	CPU 319-3 PN/DP				THE (2) BNI PBS		Profil:	Standard	-
×2	I DR	=						IOL 1/0 4/ 2 Byte	<u> </u>
83	PNUO							- IOL 1/0 2/ 8 Byte	
X3P1	Port 1							IOL_1/04/_8 Byte	
3								IOL_1/08/_2 byte	
4								0 IOL_1/08/_4 byte	
<u> </u>	-								
								🚺 IOL_1/04/32 byte	
								🚺 IOL_1/0_32/_4 byte	
								0 IOL_I/O_16/16 byte	
								II IOL_1/0_32/32 byte	
								🚺 IOL_1/0_24/24 byte	
								🚺 Standard I/O	
								- J Input Pin 4	
								Input Pin 2	
								Output Pin 4	
						Ψ.		Dutput Pin 2	
1	III				4			Communication State	
								IO-Link Diagnosis Enable/Disable	
(2)	BNI PBS-502-101-Z001							Station diagnostic	
0		In the second	1 m	1.	1 v .	1		Periphery error on Port	
Steckplatz	DP-Kennung	Bestellnummer / Bezeichnung	E	A	Kommentar	_		Sensor supply short circuit	
1	0	BNI PBS-502-101-2001	050	-		^		Actuator shutdown Pin 4	
2	64	IUL_I_2 byte	256	-				Actuator shutdown Pin 2	
3	0	Standard I/U	_	<u> </u>				Actuator warning Fin 4	
4	0	Standard I/O	_	-				Restart Din 4	=
	905	Station diagnostic	0	-				Bestat Pin 2	
7	9DE	Perinheru error on Port	1	-	L			Display Lede	
1	8DE	Input Pin 4	2	-		=		H	
9	804	Output Pin 2	1	0				E - B BNI PBS-504-001-K008	
10		prosport III 6		9				□	
11								H - A BNI PBS-507-000-2011	
12								BNI PBS 507 001 Z011	
13								🗄 🧰 🐻 Special Device	
14							<u> </u>	RNI Standard I/O	Ψ.
15									ŧ۲
16									
17						Ŧ			
Drücken Sie F1	, um Hilfe zu erhalten.								Änd //

Auxiliary modules

Finally, additional modules such as input pin 4, output pin 2 (for process data) or the "Station diagnostics" module (for simplified diagnostics evaluation) can be configured

IO-Link configuration

Double-click on the IO-Link module to change the IO-Link parameters of the respective port pins.

Parameter	Wert	
🖃 🔄 Stationsparameter		
🖨 🗃 Gerätespezifische Parameter		
—	Multiplier*0,1ms	
—	0	
—	0	=
—	2	
—	no validation	
– Vendor ID 0	0	
– Vendor ID 1	0	
—	0	
—	0	
—	0	
—	0	
—	0	
—	0	
—	0	
– Serial number 4	0	
– Serial number 5	0	

Parameter server

#### Parameter server switched on:

Switched on: Data management functions active, data is saved remanently Switched off: Data management functions deactivated, saved data is deleted.

#### Enable upload:

Select whether an upload of parameter data to the data management of the IO-Link master is to be carried out or not.

An upload is carried out:

if the configuration allows and a compatible device with an active upload request flag is connected.

If a device requests an upload and the configuration prevents it, a download (if activated) will be started if the parameter checksum is different.



#### Note

If no data or no valid data is stored on the parameter server and uploading is activated, an upload always starts when communication is established.

#### Enable download:

.

Select whether a download of parameter data to the data management of the IO-Link devices is to be carried out or not.

A download is carried out when:

- different parameter data is available (device data compared with data management data for this port)
- no uploads are requested
- downloads are permitted.

### Balluff Network Interface Profibus IO-Link Master, BNI PBS-502-101-Z001

#### Startup 7

7.3	Configuration via	Normally the configuration is carried out via a graphic interface that compiles the
	hex string	configuration string automatically. The module is configured in 2 steps: configuration and
		then parameterization.

7.4 Example

Sample configuration for

- Port 4-6 to the IO-Link (device with 2 bytes of input process data) -\_
- The remaining switching contacts are configured to the input (NO contact).

BNI PBS-502-101-Z001	Header module	0x0
IOL_I_2 bytes	Port 4	0x40, 0x81
IOL_I_2 bytes	Port 5	0x40, 0x81
IOL_I_2 bytes	Port 6	0x40, 0x81
IOL_I_2 bytes	Port 7	0x40, 0x81

(Ports 4-7 are configured specially as modules because if an IO-Link configuration is made, the process data must be displayed. The switching contacts are configured in the parameters of the header module.)

The required hex parameters are arranged one after the other in a configuration string (all values in HEX)

00, 0x40, 0x81, 0x40, 0x81, 0x40, 0x81, 0x40, 0x81.

If modules such as input pin 4 / input pin 2 (0x10) are configured, the corresponding hex parameters must be attached 00, 0x40, 0x81, 0x40, 0x81, 0x40, 0x81, 0x40, 0x81, 10, 10



#### Note

If modules such as input pin 4 / input pin 2 (0x10) are configured, the corresponding hex parameters must be attached, e.g. 00, 0x40, 0x81, 0x40, 0x81, 0x40, 0x81, 0x40, 0x81, 10, 10

The following hex parameters are required to parameterize the modules:

C0 00 00	DPV1 statuses
2F 00 44 44 00 00 00 00 00 00 00 00	Header module
10 00 00 02 00 00 00 00 00 00 00 00 00 00	IO-Link port 4
10 00 00 02 00 00 00 00 00 00 00 00 00 00	IO-Link port 5
10 00 00 02 00 00 00 00 00 00 00 00 00 00	IO-Link port 6
10 00 00 02 00 00 00 00 00 00 00 00 00 00	IO-Link port 7

Hex parameters for the modules

BNI PBS-502-101-Z001	0x0	0x00* , 0x00, 0x00
Standard I/O	0x0	0xE0
SIO mode after param	0x0	0x20
IOL_I_1 byte	0x40, 0x80	0x10
IOL_I_2 bytes	0x40, 0x81	0x10
IOL_I_4 bytes	0x40, 0x83	0x10
IOL_I6 bytes	0x40, 0x85	0x10
IOL_I8 bytes	0x40, 0x87	0x10
IOL_I10 bytes	0x40, 0x89	0x10
IOL_I16 bytes	0x40, 0x8f	0x10
IOL_I_24 bytes	0x40, 0x97	0x10
IOL_I32 bytes	0x40, 0x9F	0x10
IOL_O1 byte	0x80, 0x80	0x10
IOL_O2 bytes	0x80, 0x81	0x10
IOL_O4 bytes	0x80, 0x83	0x10
IOL_O6 bytes	0x80, 0x85	0x10
IOL_O8 bytes	0x80, 0x87	0x10
IOL_O10 bytes	0x80, 0x89	0x10
IOL_O16 bytes	0x80, 0x8F	0x10
IOL_O24 bytes	0x80, 0x97	0x10
IOL_O32 bytes	0x80, 0x9F	0x10
IOL_I/O1/_1 byte	0xC0, 0x80, 0x80	0x10
IOL_I/O_2/2 bytes	0xC0, 0x81, 0x81	0x10
IOL_I/O2/_4 bytes	0xC0, 0x83, 0x81	0x10
IOL_I/O4/_4 bytes	0xC0, 0x83, 0x83	0x10
IOL_I/O4/_2 bytes	0xC0, 0x81, 0x83	0x10
IOL_I/O2/_8 bytes	0xC0, 0x87, 0x81	0x10
IOL_I/O4/_8 bytes	0xC0, 0x87, 0x83	0x10
IOL_I/O8/_2 bytes	0xC0, 0x81, 0x87	0x10
IOL_I/O8/_4 bytes	0xC0, 0x83, 0x87	0x10
IOL_I/O8/_8 bytes	0xC0, 0x87, 0x87	0x10
IOL_I/O4/32 bytes	0xC0, 0x9F, 0x83	0x10
IOL_I/O_32/_4 bytes	0xC0, 0x83, 0x9F	0x10
IOL_I/O_16/16 bytes	0xC0, 0x8F, 0x8F	0x10
IOL_I/O_32/32 bytes	0xC0, 0x9F, 0x9F	0x10
IOL I/O 24/24 bytes	0xC0, 0x97, 0x97	0x10

Hex	parameter	s
for t	he module	s

Input pin 4	0x10	0xE1
Input pin 2	0x10	0xE2
Output pin 4	0x20	0xE3
Output pin 2	0x20	0xE4
Communication state	0x10	0x30
IO-Link diagnosis enable/disable	0x20	0x40
Station diagnostic	0x10	0x50
Periphery error on port	0x10	0x60
Sensor supply short circuit	0x10	0x70
Actuator shutdown pin 4	0x10	0x80
Actuator shutdown pin 2	0x10	0x90
Actuator warning pin 4	0x10	0xA0
Actuator warning pin 2	0x10	0xB0
Restart pin 4	0x20	0xC0
Restart pin 2	0x20	0xD0
Display LEDs	0x20	0xE5

A string is generated, similar to when the modules are configured. The string consists of the following blocks: DPV1 status 1, DPV1 status 2, DPV1 status 3, header module, IO-Link port 4, IO-Link port 5, IO-Link port 6, IO-Link port 7 7.5 Parameterizing the modules

#### **DPV1 statuses**

	DPV1 status 1							
7	6	5	4	3	2	1	0	
								reserved
								reserved
								Time base of the watchdog is 1ms
								reserved
								reserved
								The slave operates as a publisher
								E The slave operates in Fail_Safe mode
								E The slave opens the MS1 channel (DPV1)

								DPV1 status 2
7	6	5	4	3	2	1	0	
								Reduced configuration control
								reserved
								Switch on update alarm
								Switch on status alarm
								Switch on manufacturer-specific alarm
								Switch on diagnostics alarm
								Switch on process alarm
								Switch on insert alarm (pull-plug)

								DPV1 status 2
7	6	5	4	3	2	1	0	
							0	1 Every type of alarm possible
							1	2 Every type of alarm possible
							2	4 Every type of alarm possible
							3	8 Every type of alarm possible
							4	12 Every type of alarm possible
							5	16 Every type of alarm possible
							6	24 Every type of alarm possible
							7	32 Every type of alarm possible
								Isochronous mode supported
								Structured parameters possible
								reserved
								reserved
								Parameter command switched on

7.6	Header module										Byte 0
	Diagnostics	7	6	5	4	3	2	1	0		
										ΕA	ctivate global diagnostics
										ΕA	ctivate channel-dependent diagnostics
										ΕA	ctivate undervoltage diagnostics US
										ΕA	ctivate undervoltage diagnostics UA
										A	ctivate display lock
										ES	ensor short circuit evaluation for outputs
										re	served
										re	served
	Port configuration										Byte 1
		7	6	5	4	3	2	1	0		
							•			F	unction(1) port 0 pin 4
										F	unction(1) port 1 pin 4
										F	unction(1) port 2 pin 4
										F	unction(1) port 3 pin 4
											Puto 2
		7	6	5	4	2	2	1	0		
		1 '	0	12	4	5	2	1	0	 Fi	unction(2) port 4 pin 4
										E	unction(2) port 5 pin 4
						1	1			1	Byte 3
		7	6	5	4	3	2	1	0		
									_	F	unction(2) port 6 pin 4
										F	unction(2) port 7 pin 4
											Byte 4
		7	6	5	4	3	2	1	0		
										F	unction(3) port 0 pin 2
										F	unction(3) port 1 pin 2
										F	unction(3) port 2 pin 2
										F	unction(3) port 3 pin 2
											Byte 5
		7	6	5	4	3	2	1	0		
										F	unction(3) port 4 pin 2
										F	unction(3) port 5 pin 2
										F	unction(3) port 6 pin 2
										F	unction(3) port 7 pin 2

	Byte 6
7 6 5 4 3 2 1 0	
	Function(4) port 0 pin 4
	Function(4) port 1 pin 4
	Function(4) port 2 pin 4
	Function(4) port 3 pin 4
	<b>-</b>
	Byte 7
7 6 5 4 3 2 1 0	
	Function(4) port 4 pin 4
	Function(4) port 5 pin 4
	Function(4) port 6 pin 4
	Function(4) port 7 pin 4
	Byte 8
7 6 5 4 3 2 1 0	Byte 8
7 6 5 4 3 2 1 0	Byte 8 Function(4) port 0 pin 2
7 6 5 4 3 2 1 0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2
7 6 5 4 3 2 1 0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2 Function(4) port 2 pin 2
7 6 5 4 3 2 1 0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2 Function(4) port 2 pin 2 Function(4) port 3 pin 2
7 6 5 4 3 2 1 0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2 Function(4) port 2 pin 2 Function(4) port 3 pin 2
7 6 5 4 3 2 1 0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2 Function(4) port 2 pin 2 Function(4) port 3 pin 2 Byte 9
7 6 5 4 3 2 1 0 7 6 5 4 3 2 1 0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2 Function(4) port 2 pin 2 Function(4) port 3 pin 2 Byte 9
7       6       5       4       3       2       1       0         7       6       5       4       3       2       1       0         7       6       5       4       3       2       1       0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2 Function(4) port 2 pin 2 Function(4) port 3 pin 2 Byte 9 Function(4) port 4 pin 2
7       6       5       4       3       2       1       0         7       6       5       4       3       2       1       0         7       6       5       4       3       2       1       0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2 Function(4) port 2 pin 2 Function(4) port 3 pin 2 Byte 9 Function(4) port 4 pin 2 Function(4) port 5 pin 2
7       6       5       4       3       2       1       0         7       6       5       4       3       2       1       0	Byte 8 Function(4) port 0 pin 2 Function(4) port 1 pin 2 Function(4) port 2 pin 2 Function(4) port 3 pin 2 Byte 9 Function(4) port 4 pin 2 Function(4) port 5 pin 2 Function(4) port 6 pin 2

Safe state

Bit mapping functions

	Function (1)
0	Input (NO contact)
1	Input (NC contact)
2	reserved
3	Output

	Function (2)
0	Input (NO contact)
1	Input (NC contact)
2	reserved
3	Output
4	IO-Link
5	IO-Link mode (NO contact)
6	IO-Link mode (NC contact)
7 - 16	reserved

	Function (3)
0	Input (NO contact)
1	Input (NC contact)
2	Diagnostics input
3	Output

	Function (4) in event of fault
0	Output inactive
1	Output active
2	Maintain last status
3	reserved

IO-Link port x

### The same parameters are always required to parameterize the IO-Link module

		Byte 0	
7 6 5 4 3 2 1 0 10 bex	F	Identifier for IO-Link modules	
TOTICX	-		
		Byte 1	
7 6 5 4 3 2 1 0			
0 3F hex		Multiplier	
		Time base (1)	
		Byte 2	
7 6 5 4 3 2 1 0			
0 1F hex		Offset	
		Byte 3	
7 6 5 4 3 2 1 0			
0 20hex	Е	Data window length	
		Byte 4	
7   6   5   4   3   2   1   0			
0 hex			
40 hex			
80 hex		Validation identity	
		Byte 5	
0 FF hex		Vendor ID 0	
		Byte 6	
0 FF hex		Vendor ID 1	
		Byte 7	
0 FF hex		Device ID 0	
		Byte 8	
0 FF hex		Device ID 1	
		Byte 9	
0 FF hex		Device ID 2	

	Byte 10
0 FF hex	Serial number byte 1
	Byte 11
0 FF hex	Serial number byte 2
	Byte 12
0 FF hex	Serial number byte 3
	Byte 13
0 FF hex	Serial number byte 4
	Byte 14
0 FF hex	Serial number byte 5
	Byte 15
0 FF hex	Serial number byte 6
	Byte 16
0 FF hex	Serial number byte 7
	Byte 17
0 FF hex	Serial number byte 8
	Byte 18
0 FF hex	Serial number byte 9
	Byte 19
0 FF hex	Serial number byte 10
	Byte 20
0 FF hex	Serial number byte 11
	Byte 21
0 FF hex	Serial number byte 12
	Byte 22
0 FF hex	Serial number byte 13
	Byte 23
0 FF hex	Serial number byte 14
	Byte 24
0 FF hex	Serial number byte 15
	Byte 25
0 FF hex	Serial number byte 16

	Byte 26								
7	6	5	4	3	2	1	0		
							1		Allow upload
						1			Allow download
	1	1	1	1	1				reserved
1									Activate parameter server

Bit mapping and 7.7 Bit mapping and function of the configurable modules in the catalog function

Inputs pin 4 Inputs pin 2 Outputs pin 4 Outputs pin 2 Signal from configured inputs or outputs are depicted in the modules inputs pin 4 / inputs pin 2 and outputs pin 4, outputs pin 2.

The module "Inputs pin 2" also depicts the diagnostics inputs of the Desina function.

Bit mapping is the same for all 4 module types:

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

**IO-Link modules** 

The IO-Link modules always have the same structure:

IOL\_I/O\_x/xbytes

number of process data items used (should be equal to or greater than the process data length of the IO-Link device)
I = Input data
O = Output data
I/O = Both input and output data

Actuator deactivate pin 4 Actuator deactivate pin 2

Depicts a short circuit between a set output to ground at the respective port pin.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

Actuator warning pin 4 Actuator warning

Feedback if a voltage is being fed at an output that is not set.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

If this function is configured, after an actuator short-circuit no automatic restart is carried out, but rather the port must be activated by inserting the corresponding bit.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

pin 2

**Restart pin 4** Restart pin 2

Switching IO-Link diagnostics on / off If this function is configured, the IO-Link diagnostics are deactivated for all ports and can be reactivated for the desired ports.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

IO-Link communication Bit status for each IO-Link port; feedback as to whether communication is established.

nmunication	
	В

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

Peripheral error, socket

Feedback as to at which port an error occurred.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

Sensor supply Short circuit Feedback as to at which port a sensor supply short circuit is pending.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

Station diagnostics

Feedback as to which fault occurred.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Res.	Actuator Warning	Actuator Short circuit	Sensor voltage Short circuit	External error	Res.	US actuator	US sensor

Display LED

#### Display functions

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Res.	Res.	Res.	Res.	Res.	Res.	Green LED	Red LED

#### 7.8 IO-Link functions Explanation of the possible settings in the properties of the IO-Link port

**Cycle settings** This parameter can be used to influence the IO-Link communication speed The basic cycle time can be adjusted via the scroll-down menu; the multiplicator can be adjusted decimally from 0..63.

Ti	me base	Calculation	Cycle time
00	0.1ms	Multiplier * time base	0.4ms 6.4 ms
01	0.4ms	6.4 ms + Multiplier * time base	6.4ms 31.6ms
10	1.6 ms	32.0 ms + Multiplier * time base	32.0 ms 132.8 ms
11	reserved	reserved	reserved

**Data section** The Offset can be used by the start byte with length to define the end byte of the process data. This setting is only for the input data, has no influence on the actual process data length and is for visual purposes only.

ValidationNo validation: Validation deactivated, IO-Link devices not tested<br/>Compatibility: Manufacturer ID and device ID are compared to the module data.<br/>IO-Link communication only starts if there is a match.<br/>Identity: Check the manufacturer ID, device ID and serial number and compare with the<br/>IO-Link device data. IO-Link communication only starts if there is a match.

Read the operating manual accompanying the device to locate the vendor ID, device ID and the serial numbers. This information must be entered decimally and byte by byte.

Parameter server Parameter server switched on:

Switched on: Data management functions active, data is saved remanently Switched off: Data management functions deactivated, saved data is deleted.

#### Enable upload:

Select whether an upload of parameter data to the data management of the IO-Link master is to be carried out or not.

An upload starts as soon as it is allowed in the configuration and requested by the device via the upload request flag.

If the upload is disabled, no data upload will be started. If a device requests an upload, as an upload is not permitted but there is a different parameter checksum, a download (if activated) will be started.

#### Enable download:

Select whether a download of parameter data to the data management of the IO-Link devices is to be carried out or not.

If the download is activated, as soon as there is different parameter data (device in comparison to the saved data in the master) and an upload is not requested or permitted, a download of the parameter data is carried out.

### 8 Configuration of IO-Link devices

Telegram structure

In order to parameterize an IO-Link device, a telegram must be compiled and sent to the IO-Link master via Profibus.

The following structure must be maintained:

IOL\_Call

DP-V1	Function	1Byte	5F hex	Fix "Write"
header	number		5E hex	Fix "Read"
neader	reserved	1Byte	00 hex	
	CAP	1Byte	FF hex	CAP for Balluff IO-Link master
	Length	1Byte	0F1	Length of the following header + number of
	-		hex	data records to be written

Call	Extend function number	1Byte	08 hex	Fix "Call"
neauer	Port	1Byte	0508 hex	Master port +1 (e.g. Port 4 = "5")
	FI_Index	2Byte	FE 4A	I&M Index
			hex	

IOL header	Control byte	1Byte	0003hex	00 = Reserved 01 = Reserved 02 = write 03 = read
	IOL Index	2Byte	00 00	IO-Link index
			-	See also manual of the IO-Link device
			гггг	
	IOL subindex	1Byte	00FF	Subindex of the IO-Link device
Object	Data	232 bytes Max.		Data

A sample project with the IO\_Call function module from Siemens AG can be downloaded on the Balluff homepage.

**9.1 Function** The status of the supply voltages is indicated by the Status LEDs 1 to 5. Indicators

LED indicators

#### Module LEDs

LED	Display	Function
US	Green, illuminated	US "sensors" power supply on
	and stays on	
UA	Green, static	UA "actuators" power supply on
US	Red, static	US "sensors" power supply undervoltage
UA	Red, static	UA "actuators" power supply undervoltage
Bus	Green, static	BUS, data transmission with master active
	Green, flashing	BUS, data transmission with master inactive

I/O port LEDs

Channel-dependent diagnostics are indicated by the Port LEDs. Each M12 port (I/O interface) is assigned two 2-color LEDs which indicate the configuration or operating states.

#### LED "0" - PIN 4, LED "1" - PIN 2

Dicplay		Function									
Display	Output	Input	Diagnostics input								
Off	Signal = 0	Signal = 0	Diagnostics 0								
Yellow	Signal = 1	Signal = 1									
Red	I Output > Imax	SS*	Diagnostics = 1 or SC								
*SS- Short (	vircuit on PIN 1. In this	case both LEDs	are red								

\*SS= Short circuit on PIN 1. In this case both LEDs are red.

IO-Link port LEDs

#### Two LEDs are assigned to each IO-Link port to display the operating states.

### <u>LED "0" - PIN 4, LED "1</u>" - PIN 2

Display	Function									
Display	IO-Link	Output	Input	Diagnostics input						
Off	-	Signal = 0	Signal = 0	Diagnostics 0						
Yellow	-	Signal = 1	Signal = 1							
Red	-	I Output > Imax	SS*	Diagnostics = 1 or SC						
Green	IO-Link communication active	-	-	-						
Green, flashing	No IO-Link communication	-	-	-						

\*SS= Short circuit detection on Pin 1. In this case both LEDs are red.

Diagnostics input

Pin 2 of the I/O port can be configured as a diagnostics channel. It behaves like an inverted input. The 0 V signal is interpreted as 1, the corresponding Port LED comes n red and a diagnostics message is sent over DP-Diagnostics.

The optical indicator on the corresponding I/O port allows defective sensors/actuators to be more easily and quickly localized.

**9.2 Diagnostics telegram** The diagnostics telegram is comprised of various blocks. The first 6 bytes are defined by the Profibus standard EN 50170. The following 4 bytes are device-specific and specifier-related diagnostics information (2 bytes each). For each channel-dependent diagnostic, 3 bytes of diagnostics information are added (min. 6 and max. 244 bytes).

#### 9.3 Norm diagnostics

Duto	Bit												
Буге	7 6 5 4 3 2 1												
0				Status 1									
1	Status 2												
2				Status 3									
3			Ma	ster address									
4			Indent_Numb	per_High_Byt	te: 0Bhex								
5			Indent_Numl	ber_Low_Byt	te: 1Ahex								

# Note

The following applies for the coding of norm-specific diagnostics: 1 = activated, 0 = deactivated

# Norm diagnostics coding

In the following the coding of bytes 0 to 3 of the norm diagnostics is described. Byte 4 and Byte 5 (Identnumber) are fixed.

#### Status 1

Byte 0	, status 1
Bit	Meaning
0	Station_non_existent The DP-Slave always sets the bit to 0. The DP-Master sets it to 1 if the DP-Slave cannot be reached.
1	Station_not_ready The DP Slave sets the bit to 1 if it is not yet ready for data exchange.
2	Cfg_Fault The DP Slave sets the bit to 1 if the configuration data last received from the Master do not agree with those which the DP Slave determined.
3	Ext_diag If the bit is set to 1, there is a diagnostics entry in the slave-specific diagnostics area (Ext_Diag_Data). A further diagnostic follows in the telegram.
4	Not supported The DP Slave sets the bit to 1 if a function was requested which is not supported.
5	Invalid_Slave-Response The DP slave always sets the bit to 0. The DP master sets it to 1 if the DP slave sends an implausible response.
6	Prm_fault The DP slave sets the bit to 1 if the last parameter telegram was incorrect (e.g. incorrect length, incorrect identification number, invalid parameters).
7	Master_lock The DP Slave always sets the bit to 0. The DP Master sets it to 1 if the DP Slave was parameterized by a different Master (Lock from another Master, here: Address in byte 3 not equal to FFhex and not equal to its own address).

Status 2	Byte 1	, status 2
	Bit	Meaning
	0	Prm_req The DP Slave always sets the bit to 1 if it needs to be reconfigured and parameterized. The bit remains set until parameterizing is done.
	1	Stat_Diag (static diagnostic) The Slave sets the bit to 1 if for example it can not send valid data. In this case the DP Master retrieves diagnostic data until the bit is reset to 0.
	2	Fixed at 1
	3	WD_On Monitoring activated/deactivated (Watchdog on).
	4	Freeze_Mode The Slave sets the bit to 1 if it has received the Freeze command.
	5	Sync_Mode The Slave sets the bit to 1 if it has received the Sync command.
	6	Not_Present The DP slave always sets the bit to 0. The DP master sets it to 1 for the DP slaves that are not included in the master parameter set.
	7	Deactivated The DP-Slave always sets the bit to 0. The DP-Master sets it to 1 if the DP-Slave is removed from the Master parameter set.
Status 3	Byte 2	status 3
	Bit	Meaning
	06	reserved
	7	Ext_Diag_Overflow If this bit is set, there is more diagnostics information than indicated in Ext_Diag_Data. For example the DP slave sets the bit to 1 if there is more channel-dependent diagnostics information than the DP slave can enter in its send buffer. A DP Master sets the bit to 1 if the DP Slave sends more diagnostics information than the Master can hold in its diagnostics buffer.
Addross	Buto 2	address of the mester.
Audress		DAAFARR AT TOA MARTARI
	Bit	, address of the master:
	Bit 0 7	Meaning Master_Add After parameterizing the address of the DP Master which has parameterized the DP Slave is entered. If the DP Slave has not be parameterized by a Master, it sets address FFhex.
ldent Number	Byte 3 Bit 0 7	Meaning Master_Add After parameterizing the address of the DP Master which has parameterized the DP Slave is entered. If the DP Slave has not be parameterized by a Master, it sets address FFhex. Ident High
ldent_Number_ High Byte	Bit 0 7 Byte 4 Bit	Meaning Master_Add After parameterizing the address of the DP Master which has parameterized the DP Slave is entered. If the DP Slave has not be parameterized by a Master, it sets address FFhex. Ident High Meaning
ldent_Number_ High_Byte	Byte 3 Bit 0 7 Byte 4 Bit 0 7	Meaning         Master_Add         After parameterizing the address of the DP Master which has parameterized the DP         Slave is entered. If the DP Slave has not be parameterized by a Master, it sets         address FFhex.         Ident High         BNI PBS-501/502: 0Bhex
ldent_Number_ High_Byte Ident Number	Byte 3 Bit 0 7 Byte 4 0 7 Byte 5	Meaning Master_Add After parameterizing the address of the DP Master which has parameterized the DP Slave is entered. If the DP Slave has not be parameterized by a Master, it sets address FFhex.  Ident High Meaning BNI PBS-501/502: 0Bhex Ident Low
Ident_Number_ High_Byte Ident_Number_ Low_Byte	Byte 3 Bit 0 7 Byte 4, 0 7 Byte 5 Bit	Meaning Master_Add After parameterizing the address of the DP Master which has parameterized the DP Slave is entered. If the DP Slave has not be parameterized by a Master, it sets address FFhex.  Ident High Meaning BNI PBS-501/502: 0Bhex Ident Low

9.4	Device-specific	
	diagnostics	

Device-specific	Byte				Bit				
diagnostics	Dyte	7	6	5	4	3	2	1	0
	0				Header				
	1			S	Status type				
	2			S	lot number				
	3			Sta	tus specifier				
	4								
Byte     7     6     5     4     3     2       0     1     Status type     1     Status type     2       2     Stot number     3     Status specifier       4     Status message 1     5     Status message 1       5     Status message 1     5     Status message 1       6     Note     The following applies for the coding of device-specific diagnostics: 1 = activated, 0 = deactivated       Coding for devicespecific diagnostics     Byte 0, header     Meaning       6    7     Header 00: Device-specific diagnostics       05     Number of bytes     Status type       Bit     Meaning       6    7     Header 00: Device-specific diagnostics       05     Number of bytes     Status type       Bit     Meaning       7     1=Status block, 0= Atarm block       0 - 6     Status read       3     DSE Link status       2     Module status       32126     Manufacturer-spec       3     DSE Link status       272     Reserved       2     Reserved       3     DSE Link status       3     DSE Link status       4.29     Reserved       3     DSE Link status									
Byte     7     6     5     4     3     2     1       0     0     Header     1     Status type     2     1       2     Stot number     3     Status specifier     4       4     Status message 1     5     5       5     Status message 1     5     5       Note       The following applies for the coding of device-specific diagnostics: 1 = activated, 0 = deactivated       Coding for device-specific diagnostics (05 Number of bytes       Bit     Meaning       67     Header 00: Device-specific diagnostics       05     Number of bytes       Status type       Bit     Meaning       7     1=Status block, 0= Atam block       05     Number of bytes       Status type       Bit     Meaning       7     1=Status block, 0= Atam block       0     Reserved     30       3     DXB Link status     32126       4.29     Reserved     127       2     Meaning     0       0    7     Number of the slot       Status specifier     Bit     Meaning       0    7     Status specifier is always 0. <t< td=""><td></td></t<>									
	•	Note							
	<b>1</b>	The follo	owing applies	for the codin	a of device-s	pecific dia	anostics	s:	
		1 = active	vated $0 = de$	activated	9 0. 001.00 0		.g		
			,						
Coding for devicespecific diagnostics									
Header	Byte 0	. header							
	Bit	,			Meaning				
	6 7	Header 00	· Device-sne	cific diagnosti	CS .				
	07	Number of	hytes	cine diagnosti	00				
	05	Number of	Dytes						
Status type	Buto 1	status tur							
Status type	Dyte I	, status typ			Mooning				
		1 Statua k		mhlaak	wearing				
	1		DIOCK, U= Alan	III DIOCK	00	A			
	0-6	Status cod	le ,		30	ACKNOWI	eagmen	tiora	
		U Re	eserved		~ (	paramete	er comm	land	
		1 St	atus message	е	31	Status re	ad		
		2 M	odule status		32126	Manufac	turer-sp	ecific	
		3 D)	KB Link status	S	127	Reserve	d		
		4.29 Re	eserved						
Slot number	Byte 2,	slot numbe	ər						
	Bit				Meaning				
	0 7	Number of	the slot						
Status specifier	Byte 3,	status spe	cifier						
•	Bit	·			Meaning				
	07	Status spe	cifier is alway	vs 0.					
	•			,					
Status message 1	Byte 4.	status mes	ssage 1						
	Bit		<u>-</u>		Meaning				
	0 7	Status of	modules 0-3		mouning				
	0	0. Valid d	lata from this	module					
			data defect	in module					
		2: Invalid	data, uerect	at modulo					
		2. Invalid	data, micone						
		5. Invalid	uata, missing	y module					
Status massage 2	Byto 5	status mos	2000 2						
otatus messaye z	Dyte 0,	Status met	saye z		Mooning				
		Ctotus of	modulos 4.7		weathing				
	07		Inouules 4-7	modula					
		U: valid c	ata from this						
		1: invalid	data, defect	in module					
		2: Invalid	data, incorre	ct module					
		3: Invalid	data, missing	g module					

9.5	ID-specific	Buto				В	it						
	diagnostics	Буге	7	6	5	4	3	2	1	0			
		0				Hea	ader						
		1				Mod	ules						
			Note										
		Ĭ	The fo	llowing an	olies for the	coding of	identifier-s	specific dia	anostics.				
			1 = ac	tivated 0 =	= deactivate	h occarrig of			griootico.				
			1 – 40										
	Coding for identifierspecific diagnostics												
	Header	Byte 0,	header										
		Bit				Mea	aning						
		67	Header (	01: Identifie	er-specific o	liagnostics							
		05	Number	of bytes									
	Modules	Byte 1,	module	S									
		Bit				Mea	ning						
		0 7	Modules	with diagn	ostics:								
			0:	Header mo	dule								
			17:	Reserved									

9.6	Channel-	Durte						Bit						
	dependent	Буте	7		6	5		4	3	2	1	0		
	diagnostics	0						Header						
	-	1						Channel						
		2						Error						
		LL												
		Note												
		The following applies for the coding of channel-dependent diagnostics:												
		I ne tollowing applies for the coding of channel-dependent diagnostics: <ol> <li>activated 0 – deactivated</li> </ol>												
			1 - 404	ratea,	<b>v</b> = <b>u</b>	ououratou								
	Coding for													
	devicespecific													
	diagnostics													
	-													
	Header	Byte 0	, header											
		Bit						Meaning						
		67	Header 10	<u>): Cha</u>	nnel-c	lependent	dia	gnostics						
		05	Affected n	nodule	): 									
			0: Hea	ader m	nodule									
			1 <i>1</i> : Res	serveo										
	Channel	Byte 1	channel											
	Ondriner	Bit						Meaning						
		67	Type:					meaning						
		0	1: Input											
			2: Output											
		3: Input and output												
		05 Number of affected channels in the module												
			Header m	odule	and sl	hort circuit		O-Link ports						
			module		1 -			_			_			
			00: Port 0	pin 4	08: F	Port 0 pin 2	1	16: Reserved		2430	: Reserv	ed		
			01: Port 1	pin 4	09: F	ort 1 pin 2	1	17: Reserved		31: Ur	ndervolta	ge		
			02: Port 2	pin 4	10: F	ort 2 pin 2	1	18: Reserved						
			03: Port 3	pin 4	11: F	ort 3 pin 2		19: Reserved	4					
			04: POR 4	pin 4	12: 1	ort 4 pin 2		20: IO-LINK devic	e port 4					
			05. FUIL5	pin 4	11. 5	ort 6 pin 2		21. IO-LINK device	e port 6					
			00. F0110	pin 4	14. F	Port 7 pin 2			e port 0					
			07.10117	pin <del>-</del>	15.1									
	Error	Byte 2	error											
		Bit						Meaning						
		0 4	Error code	e:										
			1: Short-c	ircuit				10–15: Re	eserved					
			2: Underv	oltage				16–22: Ma	anufactur	er-spe	cific			
			3: Overvo	Itage				23: Actuat	or warnii	ng				
			4: Overloa	ad				24: Actuat	or short	circuit				
			5: Overter	nperat	ture			25: Low vo	oltage bu	is/sens	or supply	ý		
			6: Cable b	oreak				26: Extern	al diagno	ostic				
			7: Upper I	imit ex	ceede	ed		27: Senso	r has wro	ong cor	nfiguratio	n		
			8: Lower I	imit no	ot reac	nea		28: LOW V	bitage ac	tuator :	supply			
		5 7	9. EITOT					29-31: IVI8	anuiaciul	er-spe	CITC			
		5 /	1 · Rit					1. Ruto						
			2.2 hits					5. Word						
			3: 4 hits					6: 2 words	3					
		L	5. i bito					0. 2 00103	•					

## 10 Appendix

10.1 Scope of delivery	<ul> <li>The following accessories accompany the BN</li> <li>IO block</li> <li>4 blind plugs M12</li> <li>Ground strap</li> <li>M4x6 screws</li> <li>20 labels</li> </ul>	II PBS:			
10.2 Order code	Balluff Network Interface         Profibus         Function         502 = IP67 IO modules, 4 x IO-Link ports, 4         Variants         101 = with display, software release 001         Mechanical configuration         Z001 = Material: die-cast zinc, matte nicke         Bus termination: 1 x M12x1 interna         Supply voltage: 7/8" male thread         IO ports: 8 x M12 internal thread	BNI PBS-502-101-Z001			
10.3 Ordering information	Type code Ordering code				
	BNI PBS-502-101-Z001	BNI005R			

## 10 Appendix

10.4 ASCII table

Decimal	Hex	Control	ASCII	Decimal	Hex	ASCII	Decimal	Hex	ASCII
		code							
0	00	Ctrl @	NUL	43	2B	+	86	56	V
1	01	Ctrl A	SOH	44	2C	,	87	57	W
2	02	Ctrl B	STX	45	2D	-	88	58	Х
3	03	Ctrl C	ETX	46	2E		89	59	Y
4	04	Ctrl D	EOT	47	2F	/	90	5 A	Z
5	05	Ctrl E	ENQ	48	30	0	91	5B	[
6	06	Ctrl F	ACK	49	31	1	92	5C	\
7	07	Ctrl G	BEL	50	32	2	93	5D	[
8	08	Ctrl H	BS	51	33	3	94	5E	٨
9	09	Ctrl I	HT	52	34	4	95	5F	_
10	0 A	Ctrl J	LF	53	35	5	96	60	`
11	0B	Ctrl K	VT	54	36	6	97	61	Α
12	0C	Ctrl L	FF	55	37	7	98	62	В
13	0D	Ctrl M	CR	56	38	8	99	63	С
14	0E	Ctrl N	SO	57	39	9	100	64	d
15	0F	Ctrl O	SI	58	3 A	:	101	65	е
16	10	Ctrl P	DLE	59	3B	;	102	66	f
17	11	Ctrl Q	DC1	60	3C	<	103	67	g
18	12	Ctrl R	DC2	61	3D	=	104	68	ĥ
19	13	Ctrl S	DC3	62	3E	>	105	69	i
20	14	Ctrl T	DC4	63	3F	?	106	6 A	i
21	15	Ctrl U	NAK	64	40	@	107	6B	k
22	16	Ctrl V	SYN	65	41	Α	108	6C	L
23	17	Ctrl W	ETB	66	42	В	109	6D	m
24	18	Ctrl X	CAN	67	43	С	110	6E	n
25	19	Ctrl Y	EM	68	44	D	111	6F	0
26	1 A	Ctrl Z	SUB	69	45	E	112	70	р
27	1B	Ctrl [	ESC	70	46	F	113	71	q
28	1C	Ctrl \	FS	71	47	G	114	72	r
29	1D	Ctrl ]	GS	72	48	Н	115	73	S
30	1E	Ctrl ^	RS	73	49	1	116	74	t
31	1F	Ctrl _	US	74	4 A	J	117	75	u
32	20		SP	75	4B	K	118	76	V
33	21		!	76	4C	L	119	77	W
34	22		"	77	4D	М	120	78	Х
35	23		#	78	4E	N	121	79	Y
36	24		\$	79	4F	0	122	7 A	Ζ
37	25		%	80	50	Р	123	7B	{
38	26		&	81	51	Q	124	7C	
39	27		1	82	52	R	125	7D	}
40	28		(	83	53	S	126	7E	~
41	29		)	84	54	Т	127	7F	DEL
42	2 A		*	85	55	U			

# www.balluff.com

Balluff GmbH Schurwaldstrasse 9 73765 Neuhausen a.d.F. Germany Tel. +49 7158 173-0 Fax +49 7158 5010 balluff@balluff.de