



## Content

<b>1</b>	<b>Notes</b>	<b>3</b>
1.1.	<b>Structure of the guide</b>	<b>3</b>
1.2.	<b>Typographical Conventions</b>	<b>3</b>
	Enumerations	3
	Actions	3
	Syntax	3
	Cross-references	3
1.3.	<b>Symbols</b>	<b>3</b>
1.4.	<b>Abbreviations</b>	<b>3</b>
1.5.	<b>Deviating views</b>	<b>3</b>
<b>2</b>	<b>Safety</b>	<b>4</b>
2.1.	<b>Intended use</b>	<b>4</b>
2.2.	<b>Installation and startup</b>	<b>4</b>
2.3.	<b>General safety notes</b>	<b>4</b>
2.4.	<b>Resistance to aggressive substances</b>	<b>4</b>
	Hazardous voltage	4
<b>3</b>	<b>Getting Started</b>	<b>5</b>
3.1.	<b>Module overview</b>	<b>5</b>
3.2.	<b>Mechanical connection</b>	<b>6</b>
3.3.	<b>Electrical connection</b>	<b>6</b>
	Power Supply	6
	Grounding	6
	PROFINET Interface	6
	I/O-Port	7
	Port	7
<b>4</b>	<b>Technical data</b>	<b>8</b>
4.1.	<b>Dimensions</b>	<b>8</b>
4.2.	<b>Mechanical data</b>	<b>8</b>
4.3.	<b>Operating conditions</b>	<b>8</b>
4.4.	<b>Electrical data</b>	<b>8</b>
4.5.	<b>PROFINET</b>	<b>9</b>
4.6.	<b>Function indicators</b>	<b>9</b>
	Module status	9
	I/O Port	9
<b>5</b>	<b>Integration</b>	<b>10</b>
5.1.	<b>Configuration</b>	<b>10</b>
	GSDML file	10
	<b>Integration of the module</b>	<b>10</b>
	Configuration of the header module	11
	Hardware configuration	12
	Device name, Profinet address	13
	Establishing device relationship	14
	Assigning device name	14
	Concluding the configuration	15
5.2.	<b>Functions in module properties</b>	<b>15</b>
	Module settings	15
	Port functions	15
	Safe state	15
5.3.	<b>Bit mapping and function</b>	<b>16</b>
	Inputs pin 4	16
	Inputs pin 2	16
	Outputs pin 4	16

Outputs pin 2	16
Actuator shutdown pin 4 / pin 2	16
Actuator warning pin 4 / pin 2	16
Restart pin 4 / pin 2	16
Peripheral error, socket	17
Short-circuit	17
Sensor supply	17
Station diagnostics	17
<b>6 Diagnostics</b>	<b>18</b>
<b>6.1. Diagnostics message</b>	<b>18</b>
<b>6.2. Block Header</b>	<b>19</b>
Block Type	19
Block Length	19
Block Version High	19
Block Version Low	19
Alarm Type	19
API	19
Slot	19
Subslot	19
Module ID	20
Submodule ID	20
<b>6.3. AlarmSpecifier</b>	<b>20</b>
Sequence Number	20
Channel Diagnostic	20
Manufacturer-Specific Diagnosis	20
Submodules	20
Diagnostic State	20
ARDiagnosis State	20
User Structure ID	20
<b>6.4. Channel Number</b>	<b>21</b>
<b>6.5. Channel Properties</b>	<b>21</b>
Type	21
Accumulative	21
Maintenance	21
Specifier	22
Direction	22
<b>6.6. Channel Error Type</b>	<b>22</b>
<b>7 Webserver</b>	<b>23</b>
<b>7.1. General Information</b>	<b>23</b>
<b>7.2. Navigation / Info</b>	<b>24</b>
<b>7.3. Login/Logout</b>	<b>25</b>
<b>7.4. "Home" dialog</b>	<b>26</b>
<b>7.5. "Config" dialog</b>	<b>28</b>
<b>7.6. "Log" dialog</b>	<b>30</b>
<b>8 Monitoring &amp; Diagnostics</b>	<b>31</b>
<b>8.1. General</b>	<b>31</b>
<b>8.2. SNMP MIBs</b>	<b>31</b>
<b>9 Appendix</b>	<b>33</b>
<b>9.1. Included material</b>	<b>33</b>
<b>9.2. Order code</b>	<b>33</b>
<b>9.3. Order Information</b>	<b>33</b>
<b>Notes</b>	<b>34</b>

## 1 Notes

### 1.1. Structure of the guide

The guide is organized so that the chapters build on one another  
Chapter 2: Basic safety information  
Chapter 3: Getting started  
Chapter 4: Technical data  
....

### 1.2. Typographical Conventions

The following typographical conventions are used in this Guide.

#### Enumerations

Enumerations are shown in list form with bullet points.

- Entry 1,
- Entry 2.

#### Actions

Action instructions are indicated by a preceding triangle. The result of an action is indicated by an arrow.

- Action instruction 1.
- ↗ Action result.
- Action instruction 2.

Procedures can also be shown as numbers in brackets.

- (1) Step no. 1
- (2) Step no. 2
- (3)

#### Syntax

Numbers:

Decimal numbers are shown without additional indicators (e.g. 123),

Hexadecimal numbers are shown with the additional indicator hex (e.g. 00<sub>hex</sub>) or with the prefix "0x" (e.g. 0x00)

#### Cross-references

### 1.3. Symbols



#### Note

This symbol indicates general notes.

---



#### Attention!

This symbol indicates a security notice which must be observed.

---

### 1.4. Abbreviations

BNI	Balluff Network Interface
I	Standard input port
PNT	ProfiNet™
EMC	Electromagnetic Compatibility
FE	Function ground
O	Standard output port

### 1.5. Deviating views

Product views and illustrations in this manual may differ from the actual product. They are intended only as illustrative material.

## 2 Safety

**2.1. Intended use** This guide describes The BNI PNT-... serves as a decentralized input and output module for connecting to an ProfiNet™ network.

**2.2. Installation and startup**



**Attention!**

Installation and startup are to be performed only by trained specialists. Qualified personnel are persons who are familiar with the installation and operation of the product, and who fulfills the qualifications required for this activity. Any damage resulting from unauthorized manipulation or improper use voids the manufacturer's guarantee and warranty. The Operator is responsible for ensuring that applicable of safety and accident prevention regulations are complied with.

**2.3. General safety notes**

**Commissioning and inspection**

Before commissioning, carefully read the operating manual.

The system must not be used in applications in which the safety of persons is dependent on the function of the device.

**Authorized Personnel**

Installation and commissioning may only be performed by trained specialist personnel.

**Intended use**

Warranty and liability claims against the manufacturer are rendered void by:

- Unauthorized tampering
- Improper use
- Use, installation or handling contrary to the instructions provided in this operating manual

**Obligations of the Operating Company**

The device is a piece of equipment from EMC Class A. Such equipment may generate RF noise. The operator must take appropriate precautionary measures. The device may only be used with an approved power supply. Only approved cables may be used.

**Malfunctions**

In the event of defects and device malfunctions that cannot be rectified, the device must be taken out of operation and protected against unauthorized use.

Intended use is ensured only when the housing is fully installed.

**2.4. Resistance to aggressive substances**



**Attention!**

The BNI modules generally have a good chemical and oil resistance. When used in aggressive media (eg chemicals, oils, lubricants and coolants each in high concentration (ie, low water content)) must be checked prior application-related material compatibility. In the event of failure or damage to the BNI modules due to such aggressive media are no claims for defects.

**Hazardous voltage**



**Attention!**

Disconnect all power before servicing equipment.



**Note**

In the interest of product improvement, the Balluff GmbH reserves the right to change the specifications of the product and the contents of this manual at any time without notice.

3 Getting Started

3.1. Module overview




Figure 1 – Overview BNI PNT-xxx-105-Z015

- |    |                                    |    |                      |
|----|------------------------------------|----|----------------------|
| 1  | Mounting hole                      | 11 | Port 6               |
| 2  | PROFINET™ port 2                   | 12 | Port 4               |
| 3  | Display                            | 13 | Port 2               |
| 4  | Power Supply In                    | 14 | Port 0               |
| 5  | Status LED: Communication / Module | 15 | Power Supply Out     |
| 6  | Port 1                             | 16 | Label                |
| 7  | Pin/Port LED: Signal status        | 17 | PROFINET™ port 1     |
| 8  | Port 3                             | 18 | Grounding connection |
| 9  | Port 5                             |    |                      |
| 10 | Port 7                             |    |                      |

### 3 Getting Started


#### 3.2. Mechanical connection

The module is attached using 2 M6 screws and 2 washers.  
Isolation pad as accessory available

#### 3.3. Electrical connection


##### Power Supply

##### Power supply "IN" (7/8", male)



Pin	Function	Description
1	GND Bus- / Sensor and actuator power supply	0 V
2	Function ground	FE
3	Bus- / Sensor power supply	+24 V
4	Actuator power supply	+24 V

##### Power supply "OUT" (7/8" female)




Pin	Function	Description
1	GND Bus- / Sensor and actuator power supply	0 V
2	Function ground	FE
3	Bus- / Sensor power supply	+24 V
4	Actuator power supply	+24 V

##### Note



Provide sensor/bus power and actuator power from separate power sources if possible.  
Total current <9A per Pin. The total current of all modules may not exceed 9A even when daisy chaining the actuator supply.

#### Grounding




##### Note



The FE connection from the housing to the machine must be low-impedance and kept as short as possible.

#### PROFINET Interface

M12, D-coded, female



Pin	Function	
1	Tx+	Transmit Data +
2	Rx+	Receive Data +
3	Tx-	Transmit Data -
4	Rx-	Receive Data -

##### Note



Unused I/O port socket must be fitted with cover caps to ensure IP67 protection rating.

3 Getting Started

I/O-Port



Pin	Function		
	Input/Output	Output	Input
1	+24V, 200mA	+24V, 200mA*	+24V, 200mA
		n.c.	
2	Input / Output 2A	Output 2A*	Input
		n.c.	
3	GND	GND	GND
4	Input / Output 2A	Output 2A	Input
5	FE	FE	FE

\* Only for BNI PNT-206-105-Z015



**Note**

For the digital sensor inputs follow the input guideline per EN61131-2, type 2.



**Note**

Each output serves a maximum current of 2,0 amperes. Total current of the module has to be lower than 4 amperes per Pin.



**Note**


Unused I/O port socket must be fitted with cover caps to ensure IP67 protection rating.

Port

	Port	
	0-3	4-7
BNI PNT-104-105-Z015	Input	
BNI PNT-202-105-Z015	Output	
BNI PNT-206-105-Z015	Output	
BNI PNT-302-105-Z015	Input / Output	
BNI PNT-305-105-Z015	Input	Output

## 4 Technical data

### 4.1. Dimensions



### 4.2. Mechanical data

Housing material	Die case zinc, matt nickel plated
Enclosure rating per IEC 60529	IP 67 (only when plugged-in and threaded-in)
Supply voltage	7/8" 5-pin (male and female)
Input ports / Output ports	M12, A-coded (8 x female)
Dimensions (W x H x D in mm)	68 x 224 x 37.9
Mounting type	2-hole screw mount
Ground strap attachment	M4
Weight	Approx. 670 gr.

### 4.3. Operating conditions

Operating temperature $T_a$	-5 °C ... 70 °C
Storage temperature	-25 C ... 70 °C

### 4.4. Electrical data


Supply voltage	18...30.2 V DC, per EN 61131-2
Ripple	<1%
No-load current at 24 V	130 mA

**4 Technical data**

**4.5. PROFINET**

PROFINET port	1 x 10Base-/100Base-Tx
Connection for PROFINET port	M12, D-coded
Cable types per IEEE 802.3	Shielded twisted pair min. STP CAT 5/ STP CAT 5e
Data transmission rate	10/100 Mbit/s
Max. cable length	100 m
Flow control	Half Duplex/Full Duplex (IEEE 802.3x-Pause)

**4.6. Function indicators**



**Module status**

LED	Status	Function
US	green	Input power OK
	red	Low Input power (<18V)
UA	green	Output power OK
	red	Low Output power (< 18V)
SF	off	No error
	red	Watchdog timeout; channel, generic or extended diagnosis present; system error
	red flashing	DCP signal service is initiated via the bus
BF	off	No error
	red	No configuration; or low speed physical link; or no physical link
	red flashing	No data exchange
100	off	Bus clock: 10 Mbit/s
	yellow	Bus clock: 100 Mbit/s
LK	green	Data transfer

**I/O Port**

Each port has two two-colour LEDs to indicate the I/O-States

Status	Function	Description
off	I/O State	State of the Input or Output Pin is 0
yellow	I/O State	State of the Input or Output Pin is 1

Status	Port configuration		
	Diagnostic Input	Input	Output
red	Input low	short-circuit between Pin 1 und 3	short-circuit on output Pin
red flashing	-	-	short-circuit between Pin 1 und 3

## 5 Integration

### 5.1. Configuration

When planning Profibus devices, a device is depicted as a modular system with a header module and several data modules. The screenshots shown here have been taken from the configuration software of the Siemens HW config.


#### GSDML file

The device data required for project planning is saved in GSDML files (**G**eneric **S**tation **D**escription **M**arkup **L**anguage). The GSDML files are available in two languages as an Internet download ([www.balluff.com](http://www.balluff.com)). The data modules of an IO-Link block are displayed in the project planning software according to the slot.

The GSDML file makes the possible data modules available (input or output of different data ranges). For configuration of the IO-Link blocks, the corresponding data modules are assigned to a slot.

#### Integration of the module

The device can be found by searching in the catalog and inserted in the Profinet section by drag & drop.



The module BNIPNTxxx105Z015 with the submodules PN-IO, port 1-M12, port 2-M12 are used for Profinet communication.


In X1 PN-IO, functions such as prioritized run-up or the domains for the ring topology can be selected.

In slot 0 the port function (input, output, diagnostics input) or diagnostics messages can be defined.

## 5 Integration

### Configuration of the header module

Double-click on the header module to open its properties. Click on the "Parameter" tab to open a menu selection for defining the port functions and diagnostic functions.



### Note



#### Standard input and output:

For each port, the function (N.C., N.O., diagnostic input (pin 2)) can be arbitrarily selected for each port at pin 2 and pin 4.

## 5 Integration

### Hardware configuration

The standard I/O modules must now be configured appropriately for the configuration of the header module.

If necessary, these can be taken over into the configuration table from the hardware catalog by means of drag & drop.

#### **Module addressing:**

Double-clicking on the addressable modules allows you to change the addressing in the "Addresses" window

#### **Configuring a standard input / output:**

If one of the possible port pins (pin 4) is to be configured with a standard function (input, output), the "Standard I/O" placeholder module must be used for the corresponding slot. To address the inputs and outputs, input pin 2 / 4 and output 2 / 4 must be taken over from the catalog and used in the configuration according to the given modules.

With the remaining modules, the various functions are mapped into the process data areas.


Baugruppe	Strecke	E-Adresse	A-Adresse	Typ	Anmelde.
890PS70052040	0	0		890 PS700-005-2040	890092
PH40	0	0 x1		890PS70052040	
IOL_IO_32/32 byte_1	0	1	0..31	IOL_IO_32/32 byte	
IOL_L_24 byte_1	0	2	32..55	IOL_L_24 byte	
IOL_Q_16 byte_1	0	3	32..47	IOL_Q_16 byte	
IOLink Input with SIO mode_1	0	4		IOLink Input with SIO mode	
IO-Link Kommunikationsstatus_1	0	5	56	IO-Link Kommunikationsstatus	
IO-Link ID Valid_1	0	6	57	IO-Link ID Valid	
Aktionsbelegung Pin 2_1	0	7	58	Aktionsbelegung Pin 2	
Aktionsbelegung Pin 4_1	0	8	59	Aktionsbelegung Pin 4	
Aktionsarmung Pin 2_1	0	9	60	Aktionsarmung Pin 2	
Aktionsarmung Pin 4_1	0	10	61	Aktionsarmung Pin 4	
Input Pin 2_1	0	11	62	Input Pin 2	
Input Pin 4_1	0	12	63	Input Pin 4	
IO-Link Diagnose ein / ausschalten	0	13	64	IO-Link Diagnose ein / ausschalten	
Output Pin 2_1	0	14	65	Output Pin 2	
Output Pin 4_1	0	15	66	Output Pin 4	
Peripheriefehler Buchse_1	0	16	67	Peripheriefehler Buchse	
Restart Pin 2_1	0	17	68	Restart Pin 2	
Restart Pin 4_1	0	18	69	Restart Pin 4	
Sensorenempfang Kurzschluss_1	0	19	70	Sensorenempfang Kurzschluss	
Stationsdiagnose_1	0	20	71	Stationsdiagnose	

## 5 Integration

**Device name,  
Profinet address**

Double-click on the module in the Profinet line to view the communication parameters of the module.


The device name and the Profinet address (IP) are configured here.



## 5 Integration

### Establishing device relationship

"Device view " → Right-click on the module → "Assign device name".




### Assigning device name

Select the desired name and use "Assign name" to assign the marked device that you found.

The device name must be the same as that previously configured under device properties (see previous page)

Identification takes place via the MAC address (on the rear of the device) or via the Blink Test.



## 5 Integration

### Concluding the configuration

Download the configuration into HW config.

At this point, the bus error on the module should disappear.

If the module still reports a bus error, there could be a problem in one of the following areas:

- Device relationship not established.  
Scan the network and check whether the device is signaling under the correct device name and correct IP address.  
Adapt the Ethernet address or device name if necessary, assign the device name to the device once again and download the configuration.

### 5.2. Functions in module properties

Description of the functions in module properties

#### Module settings

Global diagnostics:

This function can be used to permit / suppress all diagnostics messages of the module. (optical diagnostics signals and diagnostics in configured diagnostics modules are not affected)

Sensor supply undervoltage:

This function can be used to permit / suppress the diagnostics message Sensor supply undervoltage. (optical diagnostics and diagnostics in configured diagnostics modules are not affected)

Actuator supply undervoltage:

This function can be used to permit / suppress the diagnostics message Actuator supply undervoltage. (optical diagnostics signals and diagnostics in configured diagnostics modules are not affected)

Sensor connection to output:

This function can be used to permit / suppress the diagnostics message Sensor Short-circuit on the module output. (Visual diagnostics and diagnostics in configured diagnostics modules is not affected) Function applies only to channels/pins which are configured as outputs. Channels/pins configured as inputs are unaffected.

#### Port functions

The function for every individual port pin can be defined here:

Make contact = input as normally open contact

Break contact = input as normally closed contact

Output = output function

#### Safe state

This function is a supplement to an output configuration of the respective port pin.

For each port pin, a safe status can be predefined which is assumed in the event of a failure in bus communication.

**5.3. Bit mapping and function**

Bit mapping and function of the configurable modules

**Inputs pin 4  
Inputs pin 2  
Outputs pin 4  
Outputs pin 2**

Signal from configured inputs or outputs are depicted in the modules  
Inputs pin 4 / Inputs pin 2 and Outputs pin 4, Outputs pin 2.

The "Inputs pin 2" module also depicts the diagnostic inputs of the diagnostic input function.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

**Actuator shutdown  
pin 4 / pin 2**

Depicts a short circuit between a set output to ground at the respective port pin.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

**Actuator warning  
pin 4 / pin 2**

Feedback if a voltage is being supplied at an output that is not set.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

**Restart pin 4 / pin 2**

If this function is configured, after an actuator short-circuit there is no automatic restart, but rather the port must be activated by inserting the corresponding bit.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

5 Integration

**Peripheral error, socket**

Feedback indicating the port at which an error occurred.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

**Short-circuit Sensor supply**

Feedback indicating the port at which there is a sensor supply short circuit.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Port 7	Port 6	Port 5	Port 4	Port 3	Port 2	Port 1	Port 0

**Station diagnostics**

Feedback indicating which fault occurred.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
IO-Link short circuit	Actuator Warning	Actuator Short-circuit	Sensor voltage Short-circuit	External error	Res.	US actuator	US sensor

6.1. Diagnostics message

The diagnostics message that is generated by the module in the event of an error is usually read out by the PLC and processed. It is also possible to read out the diagnosis from the module by means of function modules and evaluate it.

The diagnostics message is 34 bytes long and divided into 3 blocks: Block Header, Alarm Specifier, Channel Properties

Byte	Value	Meaning	Block
0	00	Block Type	Block Header
1	02		
2	00	Block Length	
3	1E		
4	01	Block Version High	
5	00	Block Version Low	
6	00	Alarm type	
7	01		
8	00	API	
9	00		
10	00		
11	00		
12	00	Slot number	
13	01	Subslot number	
14	00		
15	01	Module ID	
16	00		
17	00		
18	00		
19	17		
20	00	Submodule ID	
21	00		
22	00		
23	01		
24	XX	AlarmSpecifier	AlarmSpecifier
25	36		
26	80	User Structure ID	
27	00	Channel number	
28	XX		
29	XX	ChannelProperties	ChannelProperties
30	08		
31	00		
32	00	ChannelErrorType	
33	1 A		

## 6 Diagnostics

**6.2. Block Header** The first part of the diagnosis is the so-called Block Header, which is 24 bytes long.

**Block Type** The first 2 bytes of the Block Header are described by the Block Type to define the data type.

Possible values	Meaning
0x0002	Alarm Notification Low

**Block Length** 2 bytes of data that define the length of the following diagnostics message (for the complete diagnostics message, the 2 bytes from the Block Type and the 2 bytes from the Block Length must be added).

**Block Version High** 1 byte, preset to 0x01

**Block Version Low** 1 byte, preset to 0x00

**Alarm Type** 2 bytes; the information on the type of alarm is provided here

Possible values	Meaning
0x0001	Diagnostics

**API** 4 bytes, default is 0.

Possible values	Meaning
0x00000000	Default value

**Slot** 2 bytes of data that describe which slot of the module reports an error

Possible values	Meaning
0x0010	Slot 2-15 (Standard IO modules)
0x0011	Slot 2-15 (Standard IO modules)
0x0012	Slot 2-15 (Standard IO modules)
0x0013	Slot 2-15 (Standard IO modules)
0x0014	Slot 2-15 (Standard IO modules)
0x0015	Slot 2-15 (Standard IO modules)
0x0016	Slot 2-15 (Standard IO modules)
0x0017	Slot 2-15 (Standard IO modules)
0x0018	Slot 2-15 (Standard IO modules)

**Subslot** 2 bytes of data that describe which subslot of the slot reports an error

Possible values	Meaning
0x0001	Subslot 1

## 6 Diagnostics

**Module ID** 4 bytes of data that describe which module is inserted in the respective slot.  
(The module ID is saved in the GSDML)

Possible values	Meaning
0x00000059	Output pin 4
0x0000005A	Output pin 2
0x0000005B	Input pin 4
0x0000005C	Input pin 2

**Submodule ID** 4 bytes of data that describe which submodule is used with the respective module.  
(The submodule ID is saved in the GSDML)

Possible values	Meaning
0x00000001	BNI PNT-302-105-Z015 (header module)

**6.3. AlarmSpecifier** 2 bytes, subdivided as follows:

**Sequence Number** Bit 0-10, this counter is incremented with every new diagnostic message.

**Channel Diagnostic** Bit 11

Possible values	Meaning
0x00	No diagnosis related to channel is pending
0x01	Diagnosis related to channel is pending

**Manufacturer-Specific Diagnosis** Bit 12

Possible values	Meaning
0x00	No diagnosis related to manufacturer is pending
0x01	Diagnosis related to manufacturer is pending

**Submodules Diagnostic State** Bit 13

Possible values	Meaning
0x00	No further diagnosis of submodule present
0x01	At least one further diagnosis of the submodule present

Bit 14 reserved

**ARDiagnosis State** Bit 15

Possible values	Meaning
0x00	No further diagnosis of module is present
0x01	At least one further diagnosis of the module is present

**User Structure ID** 2 bytes, describes the type of diagnosis

Possible values	Meaning
0x8000	Channel-related diagnosis

**6 Diagnostics**

**6.4. Channel Number** Configuration as standard I/O

Error Type	Channel Number
Undervoltage US	8000
Undervoltage UA	8000
No UA	8000
Sensor Short circuit Pin 1 - 3	0.....n
Actor Short circuit Pin 2 - 3	0.....n
Actor Short circuit Pin 4 - 3	0.....n

**6.5. Channel Properties** 2 bytes, subdivided as follows:

**Type**

Possible values	Meaning
0x00	Used if the channel number is 0x8000 or none of the types defined below is relevant.
0x01	1 bit
0x02	2 bits
0x03	4 bits
0x04	8 bits
0x05	16 bits
0x06	32 bits
0x07	64 bits
0x08 – 0xFF	Reserved

Bit 0-7

**Accumulative** Bit 8 not used, always 0.

**Maintenance**

Possible values		Meaning
Bit 9	Bit 10	
0x00	0x00	Diagnostics

Bit 9-10

**Specifier**

Possible values	Meaning
0x00	Not used
0x01	Diagnosis appeared
0x02	Diagnosis left
0x03	Diagnosis left, but another is still active

Bit 11-12

**Direction**

Possible values	Meaning
0x00	Manufacturer-specific
0x01	Channel used as input
0x02	Channel used as output
0x03	Channel used as input and output

Bit 13-15

**6.6. Channel Error Type**

Error code in hex	Description
0x0000	Unknown error
0x0001	Short-circuit
0x0002	Undervoltage
0x0003	Overvoltage
0x0004	Overload
0x0005	Temperature limit exceeded
0x0006	Cable break
0x0007	Upper threshold exceeded
0x0008	Lower threshold undershot
0x0009	Error
0x001A	External error
0x001B	Sensor has incorrect configuration (IO-Link device)
0x0101	Actuator warning
0x0105	Actuator supply undervoltage
0x0104	No actuator power supply

## 7 Webservice

### 7.1. General Information

The BNI fieldbus module contains an integrated web server for retrieving detailed device information and for configuring the device.

To use the web interface you must first ensure that the module has been correctly integrated into your network. In addition the IP subnet of the BNI module must be accessible from the PC on which the browser is running. Please use Internet Explorer 10 or newer as the browser; older versions may result in display problems.

For open a connection with the web server, enter the IP address of the module in the address line of the browser. The homepage then appears with the essential device information.

The screenshot displays the web interface for the Balluff BNI PNT-302-105-Z015 module. The interface includes a navigation bar with the Balluff logo, the device ID, and icons for Home, Login, Config, Log, and Info. The main content area is titled 'Module Information' and lists the following details:


- Product Name: BNI PNT-302-105-Z015
- Order Code: BNI0052
- Name: MyNiceModule
- Location: 73765 Neuhausen a.d.F., Germany
- Contact: Balluff GmbH
- Firmware Revision: 3.2
- Hardware Revision: 6
- Station name: myweb
- IP Address: 192.168.0.4
- Subnet Mask: 255.255.255.0
- Gateway Address: 0.0.0.0
- MAC Address: 00:19:31:3F:FF:32
- Link Speed Port 1: 100 Mbit/s FULL
- Link Speed Port 2: No Link
- PLC Lock: No

Below the information is the 'PROFINET' logo and a photograph of the physical module. The module features eight RJ45 ports arranged in two columns of four. The top-left port is labeled '1' and has a green LED indicator. The top-right port is labeled '2' and has a yellow LED indicator. The middle-left port is labeled '3' and has a green LED indicator. The middle-right port is labeled '4' and has a green LED indicator. The bottom-left port is labeled '5' and has a green LED indicator. The bottom-right port is labeled '6' and has a green LED indicator. The bottom-most port is labeled '7' and has a green LED indicator. The label 'In/Out' is positioned between the middle and bottom rows of ports. Below the photograph is the text 'LED Legend'.

7.2. Navigation / Info

The navigation bar is located in the upper area of the window, which allows you to switch between the various dialogs of the web interface. To do this click on the corresponding icon.

When the "Info" tab is selected the following overview appears:



The "BALLUFF" logo at upper right links to the international Balluff homepage.

## 7 Websaver


### 7.3. Login/Logout

To make configuration settings on the fieldbus module using the web interface, you must first log in. Functionalities which cannot be used without logging in are indicated by the grayed out buttons.

The default password is:

BNI PNT-XXX-XXX-XXXX	"BNIPNT"
BNI EIP-XXX-XXX-XXXX	"BNIEIP"
BNI ECT-XXX-XXX-XXXX	"BNIECT"

The password cannot be changed!



After successfully logging in the dialogs are shown as follows:



Use the "Logout" button to log out again. After 5 minutes of no interaction with the Websaver the user is automatically logged out.



#### Note

For security reasons the fieldbus module shows only one login at a time with configuration access. Reading (without logging in) is however possible from multiple PCs at the same time on the fieldbus module.

7.4. "Home" dialog


Under "Home" you are given the essential information about the fieldbus itself and its network activity. You are also shown whether the configuration block was enabled by the controller (PLC).

Information is also shown about the current process data and the status of the module via the corresponding LEDs. After selecting "LED Legend" a Help dialog appears which explains the meaning of the LEDs

**BALLUFF** BNI PNT-302-105-Z015 Home Logout Config Log Info

**Module Information**

Product Name:	BNI PNT-302-105-Z015
Order Code:	BNI0052
Name:	MyNiceModule
Location:	73765 Neuhausen a.d.F., Germany
Contact:	Balluff GmbH
Firmware Revision:	3.2
Hardware Revision:	6
Station name:	myweb
IP Address:	192.168.0.4
Subnet Mask:	255.255.255.0
Gateway Address:	0.0.0.0
MAC Address:	00:19:31:3F:FF:32
Link Speed Port 1:	100 Mbit/s FULL
Link Speed Port 2:	No Link
PLC Lock:	No



LED Legend

**PROFINET**

7 Webservice

PNT:

**Module LED Functions**

Indicator	0	1
US	OK	Low
UA	OK	Low
SF	System error	IO-Link service
BF	No config	No data exchange
100	Connected	Not connected
LK	Link activity	No link activity

**Port LED Functions**

IO	0	1
IO-Link	IO-Link	IO-Link
IO-Link	IO-Link	IO-Link
IO-Link	IO-Link	IO-Link

EIP:

**Module LED Functions**

Indicator	0	1
US	OK	Low
UA	OK	Low
Mod	IO error	Config Error
Net	No config	No data exchange
100	100 Mbit/s	10 Mbit/s
LK	Link activity	No link activity

**Port LED Functions**


IO	0	1
IO-Link	IO-Link	IO-Link
IO-Link	IO-Link	IO-Link
IO-Link	IO-Link	IO-Link

> LED Legend

7.5. "Config" dialog

The configuration page enables configuration of the module. You can change the module information texts and the (for EIP) IP-Configuration.

PNT / ECT:



## 7 Webservice

EIP:

The screenshot shows the web interface for the Balluff BNI EIP-302-105-Z015 module. The interface is divided into two main sections: Module Configuration and Port Configuration.

**Module Configuration:**

- Name:** ?
- Location:** 73765 Neuhausen a.d.F, Germany
- Contact:** Balluff GmbH
- IP Configuration:**
  - DHCP Client
  - Static IP
    - IP Address:** 192.168.1.1
    - Subnet Mask:** 255.255.255.0
    - Gateway Address:** 192.168.1.1
  - Factory IP
    - IP Address:** 192.168.1.1
    - Subnet Mask:** 255.255.255.0
    - Gateway Address:** 192.168.1.1

In order to change the IP address, it's necessary to reboot the module after saving the configuration.

**Port Configuration:**

The Port Configuration section displays a central image of the module with eight ports. Each port is associated with a dropdown menu for its mode, which is currently set to "Digital Input/Output". The ports are arranged in two columns of four, with pin numbers 4 and 2 indicated for each port.

**Navigation:** The top right of the interface includes navigation icons for Home, Logout, Config, Log, and Info.

**Buttons:** At the bottom of the Module Configuration section, there are three buttons: "Save Configuration", "Reboot", and "Factory Reset".

The parameter set "Module Configuration" on the left side is used by clicking "Save Configuration" and permanently stored in the device.

The "Reboot" button reboots the device as if the power to the module had been turned off and on again.

Clicking on "Factory Reset" deletes the configuration and log files saved in the device and then performs a reboot, so that the device is restored to the default factory configuration as on delivery.

## 7.6. "Log" dialog

This dialog provides general service information about the device as well as a logging function.

The upper table (see screenshot below) contains important information for all service inquiries.

**Note**

If you have a detailed question about a specific situation, send us a screenshot of this Web site or print the site as a PDF.

Logging shows events which have occurred in chronological order. This provides a tool for detailed troubleshooting in equipment.

**BALLUFF** BNI PNT-302-105-Z015

Home Login Config **Log** Info

**Information**

Product name:	BNI PNT-302-105-Z015	Browser time:	2017-01-23 15:58:00.039
Firmware revision:	3.2	System uptime:	4 mins 46 secs 959 msec
MAC address:	00:19:31:99:CA:32	Free flash space:	2068 KB
IP address:	192.168.0.4	Web version:	2.0.110
Browser version:	Firefox 50.0		

**Log**

No.	Severity	Date	Origin	Message
0	Notice	2000-01-01 00:00:00.426	SYS	System startup (Oct 20 2016, 14:57:42)
1	Notice	2000-01-01 00:00:00.456	SYS	Set MAC address: 00:19:31:99:CA:32
2	Informational	2000-01-01 00:00:00.459	SYS	Configuration updated with new data from device file
3	Notice	2000-01-01 00:00:01.959	ETH	Port 0: Link Up (100 MBit/s, full duplex)
4	Notice	2000-01-01 00:04:42.911	WEB_IF	Login successful, IP address: 192.168.0.50
5	Notice	2000-01-01 00:04:45.129	WEB_IF	Logout, IP address: 192.168.0.50

Events are classified using the "**Severity**" column:

**Internal Error** (Emergency, Alert, Critical)

→ The fieldbus module has detected a fault in itself (hardware or software) which should not occur during normal operation. If this happens, the module must be serviced or replaced.

**External Error** (Error, Warning)

→ The fieldbus module has detected what may be a non-permissible event which is affecting the module from the outside. The system may require troubleshooting.

**Event** (Informational, Notice)

→ The fieldbus module has detected an important normal operating event and reports it. These may include for example configuration actions over the web interface and other configuration interfaces which are also recorded.

Clicking on "Set Module Time" sends the current browser time to the fieldbus module but does not permanently store it. After a reset, reboot or loss of power the time begins to run again from the year 2000.

Clicking on "Update Log" refreshes the display, and "Clear Log" deletes all entries. The log entries are stored in a ring buffer.

**8 Monitoring & Diagnostics**

**8.1. General**

The fieldbus module offers a number of diagnostics interfaces which are described in the following:

- Device diagnostics using the web interface
- Network diagnostics via SNMP
- Fieldbus-specific diagnostics using the PLC

The web interface and the fieldbus-specific diagnostics interface are each described in a separate section.

The monitoring and diagnostics interfaces on the device are accessed via the IP-based management interface over the Ethernet network. Alternately to the procedure for setting IP access described in the "Integration" section, other dedicated configuration tools can also be used together with the DCP protocol of PROFINET. The following parameters must then be set:

- IP address (IP)
- Subnet mask (SN)
- Gateway address (GW)
- Device name

The configuration settings can be reset to their factory defaults through the web interface.

Configuration settings are only possible if the module has no active connection with a controller unit.

**8.2. SNMP MIBs**

Monitoring and diagnostics of the device network settings can be done over the network using the SNMPv1 protocol. This can be accessed simply from a so-called SNMP browser or common network management applications.

The following MIBs are supported:

- MIB-2 (RFC 1213)
- LLDP-MIB (IEEE 802.1AB)

Information about the fieldbus module is provided in the module-specific information of the MIB-2:

MIB variable	Description
<b>sysDescr</b>	A textual description of the entity. This value should include the full name and version identification of the system's hardware type, software operating-system, and networking software.
<b>sysObjectID</b>	{1.3.6.1.4.1.44233.1.2.1} For Balluff products with Product enterprise Number (PEN) = 44233, the product list is defined in <b>BALLUFF-PRODUCTS-MIB</b>
<b>sysUpTime</b>	The time (in hundredths of a second) since the network management portion of the system was last re-initialized.
<b>sysContact</b>	The textual identification of the contact person for this managed node, together with information on how to contact this person. ("BALLUFF")
<b>sysName</b>	An administratively-assigned name for this managed node. By convention, this is the node's fully-qualified domain name. ("BNI PNT ....")
<b>sysLocation</b>	The physical location of this node (e.g. "73765 Neuhausen a.d.F, Germany")


The port-specific information of the MIB-2 describes diagnostic data about the network connections, including the IO-Link ports:

MIB variable	Ethernet port	IO-Link Port
<b>ifIndex</b>	A unique value, contiguously starting from 1.	
<b>ifDescr</b>	A textual string containing information about the interface, i.e. "Ethernet X"	"IO-Link X" / "IO-IN X" / "IO-OUT X"
<b>ifType</b>	IANAifType = 6 (ethernetCsmaCd) when Ethernet	IANAifType = 280 (sdci) when IO-Link-Port = 0 (other) when I/O-Port
<b>ifMTU</b>	length of Ethernet MTU	length of IO-Link process data (typically max. 32 bytes) or 1, when IO-port
<b>ifSpeed</b>	actual Ethernet speed	IO-Link speed (no device = 0 bit/s, Com1 Mode = 4800 bit/s, Com2 Mode 38400 bit/s, Com3 Mode = 230400 bit/s)
<b>ifPhysAddress</b>	MAC address assigned to this port	This object may contain an octet string of zero length, since IO-Link is a serial P2P protocol with no specific addressing.
<b>ifAdminStatus</b>	Up(1), Down(2), depending	Up(1), Down(2), depending if IO-Link capability is configured.
<b>ifOperStatus</b>	Up(1), Down(2), depending if an IO-Link device is connected and operable.	
<b>ifLastChange</b>	The value of sysUpTime at the time the interface entered its current operational state. If the current state was entered prior to the last re-initialization of the local network management subsystem, then this object contains a zero value.	n/a
<b>ifInOctets</b>	The total number of octets received on the interface, including framing characters.	
<b>ifInErrors</b>	n/a	Number of received frames that were rejected as invalid by the IO-Link-Master (Abort).
<b>ifOutOctets</b>	The total number of octets transmitted out of the interface, including framing characters.	
<b>ifOutErrors</b>	n/a	Number of retries by the IO-Link-Master, indicating unsuccessful packet transmissions.

## 9 Appendix

- 9.1. Included material** The BNI PNT consists of the following components:
- Standard I/O Module
  - 4 blind plugs M12
  - Ground strap
  - Screw M4x6
  - 20 labels

**9.2. Order code**



**9.3. Order Information**

Product ordering code	Order code
BNI PNT-104-105-Z015	BNI0053
BNI PNT-202-105-Z015	BNI005F
BNI PNT-206-105-Z015	BNI007L
BNI PNT-302-105-Z015	BNI0052
BNI PNT-305-105-Z015	BNI005K

**Notes**

**[www.balluff.com](http://www.balluff.com)**

Balluff GmbH  
Schurwaldstrasse 9  
73765 Neuhausen a.d.F.  
Germany  
Tel. +49 7158 173-0  
Fax +49 7158 5010  
[balluff@balluff.de](mailto:balluff@balluff.de)