


## **BNI EIP-104-105-Z015** **BNI EIP-202-105-Z015** **BNI EIP-302-105-Z015** **EtherNet/IP IP67 Modules** **User's Guide**



## Content

|  |  |           |
|--|--|-----------|
| <b>1</b>   | <b>Notes</b>                               | <b>3</b>  |
| 1.1.   | Structure of the guide                     | 3         |
| 1.2.   | Typographical Conventions                  | 3         |
| Enumerations   |  | 3         |
| Actions  |  | 3         |
| Syntax   |  | 3         |
| Cross-references   |  | 3         |
| 1.3.   | Symbols                                    | 3         |
| 1.4.   | Abbreviations                              | 3         |
| 1.5.   | Deviating views                            | 3         |
| <b>2</b>   | <b>Safety</b>                              | <b>4</b>  |
| 2.1.   | Intended use                               | 4         |
| 2.2.   | Installation and startup                   | 4         |
| 2.3.   | General safety notes                       | 4         |
| 2.4.   | Resistance to aggressive substances        | 4         |
| Hazardous voltage  |  | 4         |
| <b>3</b>   | <b>Getting Started</b>                     | <b>5</b>  |
| 3.1.   | Module overview                            | 5         |
| 3.2.   | Mechanical connection                      | 6         |
| 3.3.   | Electrical connection                      | 6         |
| Power Supply   |  | 6         |
| Grounding  |  | 6         |
| Ethernet IP Interface  |  | 6         |
| I/O-Port   |  | 7         |
| <b>4</b>   | <b>Technical data</b>                      | <b>8</b>  |
| 4.1.   | Dimensions                                 | 8         |
| 4.2.   | Mechanical data                            | 8         |
| 4.3.   | Operating conditions                       | 8         |
| 4.4.   | Electrical data                            | 8         |
| 4.5.   | Ethernet                                   | 9         |
| 4.6.   | Function indicators                        | 9         |
| Module status  |  | 9         |
| Port   |  | 9         |
| <b>5</b>   | <b>Integration</b>                         | <b>10</b> |
| 5.1.   | Integration into a Rockwell RS Logix 5000  | 10        |
| <b>6</b>   | <b>Configuration via Explicit Messages</b> | <b>14</b> |
| QuickConnect   |  | 14        |
| Rockwell Automation Products that are Compatible with QuickConnect |  | 15        |
| Example with Rockwell Components                                   |  | 16        |
| PLC Program  |  | 17        |
| Fault State  |  | 20        |
| Enable/Disable Fault State   |  | 20        |
| Fault State Action   |  | 20        |
| <b>7</b>   | <b>Process Data</b>                        | <b>21</b> |
| 7.1.   | Data Configuration BNI EIP-302-105-Z015    | 21        |
| 7.2.   | Process Data Inputs BNI EIP-302-105-Z015   | 21        |
| 7.3.   | Process Data Output BNI EIP-302-105-Z015   | 21        |
| 7.4.   | Data Configuration BNI EIP-202-105-Z015    | 22        |
| 7.5.   | Process Data Inputs BNI EIP-202-105-Z015   | 22        |
| 7.6.   | Process Data Output BNI EIP-202-105-Z015   | 22        |
| 7.7.   | Data Configuration BNI EIP-104-105-Z015    | 23        |

# Balluff Network Interface EtherNet/IP

|   |           |
|---|-----------|
| 7.8. Process Data Inputs BNI EIP-104-105-Z015 | 23        |
| 7.9. Process Data Output BNI EIP-104-105-Z015 | 23        |
| <b>8 Display</b>                              | <b>24</b> |
| 8.1. General                                  | 24        |
| 8.2. Address Specifications                   | 24        |
| 8.3. Controls and visualization               | 24        |
| 8.4. Display information                      | 24        |
| 8.5. Design and Symbols                       | 25        |
| 8.6. Startup                                  | 25        |
| 8.7. Main Menue                               | 25        |
| 8.8. IP Setup                                 | 26        |
| 8.9. Network Config                           | 26        |
| 8.10. Edit mode                               | 27        |
| 8.11. Module information                      | 28        |
| 8.12. General Informations                    | 28        |
| <b>9 Webservice</b>                           | <b>29</b> |
| 9.1. General Information                      | 29        |
| 9.2. Navigation / Info                        | 30        |
| 9.3. Login/Logout                             | 31        |
| 9.4. "Home" dialog                            | 32        |
| 9.5. "Config" dialog                          | 34        |
| 9.6. "Log" dialog                             | 36        |
| <b>10 Appendix</b>                            | <b>37</b> |
| 10.1. Included material                       | 37        |
| 10.2. Order code                              | 37        |
| 10.3. Order Information                       | 37        |
| <b>Notes</b>                                  | <b>38</b> |

|   |  |   |   |   |  |     |              |     |                               |    |                |   |                      |
|---|--|---|---|---|--|-----|--------------|-----|-------------------------------|----|----------------|---|----------------------|
| <b>1.1. Structure of the guide</b>  | The guide is organized so that the chapters build on one another.<br>Chapter 2: Basic safety information.<br>Chapter 3: The main steps for installing the device.<br>.....   |   |   |   |  |     |              |     |                               |    |                |   |                      |
| <b>1.2. Typographical Conventions</b>   | The following typographical conventions are used in this Guide.  |   |   |   |  |     |              |     |                               |    |                |   |                      |
| <b>Enumerations</b>   | Enumerations are shown in list form with bullet points. <ul style="list-style-type: none"> <li>• Entry 1,</li> <li>• Entry 2.</li> </ul>   |   |   |   |  |     |              |     |                               |    |                |   |                      |
| <b>Actions</b>  | Action instructions are indicated by a preceding triangle. The result of an action is indicated by an arrow. <ul style="list-style-type: none"> <li>➤ Action instruction 1.</li> <li>↪ Action result.</li> <li>➤ Action instruction 2.</li> </ul> Procedures can also be shown as numbers in brackets. <ul style="list-style-type: none"> <li>(1) Step no. 1</li> <li>(2) Step no. 2</li> </ul>  |   |   |   |  |     |              |     |                               |    |                |   |                      |
| <b>Syntax</b>   | Numbers:<br>Decimal numbers are shown without additional indicators (e.g. 123),<br>Hexadecimal numbers are shown with the additional indicator hex (e.g. 00 <sub>hex</sub> ) or with the prefix "0x" (e.g. 0x00)   |   |   |   |  |     |              |     |                               |    |                |   |                      |
| <b>Cross-references</b>   | Cross references indicate where additional information on the topic can be found.  |   |   |   |  |     |              |     |                               |    |                |   |                      |
| <b>1.3. Symbols</b>   | <hr/> <table border="0"> <tr> <td style="vertical-align: middle;"></td> <td><b>Note</b><br/>This symbol indicates general notes.</td> </tr> </table> <hr/> <table border="0"> <tr> <td style="vertical-align: middle;"></td> <td><b>Attention!</b><br/>This symbol indicates a security notice which must be observed.</td> </tr> </table> <hr/> |  | <b>Note</b><br>This symbol indicates general notes. |  | <b>Attention!</b><br>This symbol indicates a security notice which must be observed. |     |              |     |                               |    |                |   |                      |
|  | <b>Note</b><br>This symbol indicates general notes.  |   |   |   |  |     |              |     |                               |    |                |   |                      |
|  | <b>Attention!</b><br>This symbol indicates a security notice which must be observed.   |   |   |   |  |     |              |     |                               |    |                |   |                      |
| <b>1.4. Abbreviations</b>   | <table border="0"> <tr> <td>BNI</td> <td>Balluff Network Interface</td> </tr> <tr> <td>I</td> <td>Standard input port</td> </tr> <tr> <td>EIP</td> <td>EtherNet/IP™</td> </tr> <tr> <td>EMC</td> <td>Electromagnetic Compatibility</td> </tr> <tr> <td>FE</td> <td>Function earth</td> </tr> <tr> <td>O</td> <td>Standard output port</td> </tr> </table>  | BNI   | Balluff Network Interface                           | I   | Standard input port  | EIP | EtherNet/IP™ | EMC | Electromagnetic Compatibility | FE | Function earth | O | Standard output port |
| BNI   | Balluff Network Interface  |   |   |   |  |     |              |     |                               |    |                |   |                      |
| I   | Standard input port  |   |   |   |  |     |              |     |                               |    |                |   |                      |
| EIP   | EtherNet/IP™   |   |   |   |  |     |              |     |                               |    |                |   |                      |
| EMC   | Electromagnetic Compatibility  |   |   |   |  |     |              |     |                               |    |                |   |                      |
| FE  | Function earth   |   |   |   |  |     |              |     |                               |    |                |   |                      |
| O   | Standard output port   |   |   |   |  |     |              |     |                               |    |                |   |                      |
| <b>1.5. Deviating views</b>   | Product views and illustrations in this manual may differ from the actual product. They are intended only as illustrative material.  |   |   |   |  |     |              |     |                               |    |                |   |                      |

## 2 Safety

### 2.1. Intended use

This guide describes The BNI EIP-... serves as a decentralized input and output module for connecting to an EtherNet/IP™ network.

### 2.2. Installation and startup



#### Attention!

Installation and startup are to be performed only by trained specialists. Qualified personnel are persons who are familiar with the installation and operation of the product, and who fulfills the qualifications required for this activity. Any damage resulting from unauthorized manipulation or improper use voids the manufacturer's guarantee and warranty. The Operator is responsible for ensuring that applicable of safety and accident prevention regulations are complied with.

### 2.3. General safety notes

#### Commissioning and inspection

Before commissioning, carefully read the User's Guide.

The system must not be used in applications in which the safety of persons depends on the function of the device.

#### Intended use

Warranty and liability claims against the manufacturer shall be rendered void by damage from:

- Unauthorized tampering
- Improper use
- Use, installation or handling contrary to the instructions provided in this User's Guide.

#### Obligations of the owner/operator

The device is a piece of equipment in accordance with EMC Class A. This device can produce RF noise. The owner/operator must take appropriate precautionary measures against this for its use. The device may be used only with a power supply approved for this. Only approved cables may be connected.

#### Malfunctions

In the event of defects and device malfunctions that cannot be rectified, the device must be taken out of operation and protected against unauthorized use.

Intended use is ensured only when the housing is fully installed.

### 2.4. Resistance to aggressive substances



#### Attention!

The BNI modules generally have a good chemical and oil resistance. When used in aggressive media (eg chemicals, oils, lubricants and coolants each in high concentration (ie, low water content)) must be checked prior application-related material compatibility. In the event of failure or damage to the BNI modules due to such aggressive media are no claims for defects.

### Hazardous voltage



#### Attention!


Disconnect all power before servicing equipment.



#### Note

In the interest of product improvement, the Balluff GmbH reserves the right to change the specifications of the product and the contents of this manual at any time without notice.

3.1. Module overview



Overview BNI EIP-xxx-105-Z015

- |   |                                    |    |                      |
|---|------------------------------------|----|----------------------|
| 1 | Mounting hole                      | 10 | Port 14 / 15         |
| 2 | EtherNet/IP™ port 2                | 11 | Port 06 / 07         |
| 3 | Display                            | 12 | Port 04 / 05         |
| 4 | Power IN                           | 13 | Port 02 / 03         |
| 5 | Status-LED: Communication / Module | 14 | Port 00 / 01         |
| 6 | Port 08 / 09                       | 15 | Power OUT            |
| 7 | Pin/Port LED : Signal status       | 16 | Labels               |
| 8 | Port 10 / 11                       | 17 | EtherNet/IP™ port 1  |
| 9 | Port 12 / 13                       | 18 | Grounding connection |


3 Getting Started

3.2. Mechanical connection

The module is attached using 2 M6 screws and 2 washers.  
Isolation pad as accessory available

3.3. Electrical connection


Power Supply

|  <p>7/8" male</p> | Pin | Function | Description                             |
|--|-----|----------|---|
|  | 1   | +24 V    | Actuator power supply                   |
|  | 2   | +24 V    | Module / sensor power supply            |
|  | 3   | 0 V      | GND module / sensor and actuator supply |
| 4  |     |          |   |

**Note**  
 Provide sensor/bus power and actuator power from separate power sources if possible.  
 Total current <9A. The total current of all modules may not exceed 9A even when daisy chaining the actuator supply.

**Attention!**  
**Do not separate supply voltages**  
**Non-separate voltage supply circuits for sensor and actuator can result in undesired voltage drops in the sensor supply when switching actuators.**  
 ► Therefore always use separately protected voltage supplies for sensors and actuators.  
 Also be sure to sufficiently dimension the voltage supply of the device in order to cover startup and peak currents. Design the fusing concept accordingly.


Grounding



**Note**  
 The FE connection from the housing to the machine must be low-impedance and kept as short as possible.

Ethernet IP Interface

M12, D-coded, female




| Pin | Function |                 |
|-----|----------|-----------------|
| 1   | Tx+      | Transmit Data + |
| 2   | Rx+      | Receive Data +  |
| 3   | Tx-      | Transmit Data - |
| 4   | Rx-      | Receive Data -  |

### 3 Getting Started

#### I/O-Port

M12, A-coded, female



| Pin | Function    |           |                   |
|-----|-------------|-----------|-------------------|
|     | 104         | 202       | 302               |
| 1   | +24V, 200mA | n.c.      | +24V, 200mA       |
| 2   | Input       | n.c.      | Input / Output 2A |
| 3   | GND         | GND       | GND               |
| 4   | Input       | Output 2A | Input / Output 2A |
| 5   | FE          | FE        | FE                |



#### Note

For the digital sensor inputs follow the input guideline per EN61131-2, type 2.



#### Note

Each output serves a maximum current of 2 amperes. Total current of the module has to be lower than 9 amperes.




#### Note

Unused I/O port socket must be fitted with cover caps to ensure IP67 protection rating.

4 Technical data

4.1. Dimensions



4.2. Mechanical data

|                                |  |
|--------------------------------|--|
| Housing material               | Die case zinc, matt nickel plated            |
| Enclosure rating per IEC 60529 | IP 67 (only when plugged-in and threaded-in) |
| Supply voltage                 | 7/8" 4-pin male / female                     |
| Input ports / Output ports     | M12, A-coded (8 x female)                    |
| Dimensions (W x H x D in mm)   | 68 x 224 x 37.9                              |
| Mounting type                  | 2-hole screw mount                           |
| Ground strap attachment        | M4   |
| Weight                         | Approx. 670 g                                |

4.3. Operating conditions

|                     |                 |
|---------------------|-----------------|
| Ambient temperature | -5 °C ... 70 °C |
| Storage temperature | -25 C ... 70 °C |

4.4. Electrical data


|                       |                                |
|-----------------------|--------------------------------|
| Supply voltage        | 18...30.2 V DC, per EN 61131-2 |
| Ripple                | <1%                            |
| Input current at 24 V | 130 mA                         |

## 4 Technical data

### 4.5. Ethernet

|                                 |  |
|---------------------------------|--|
| Ethernet IP port                | 2 x 10Base-/100Base-Tx                           |
| Connection for Ethernet IP port | M12, D-coded                                     |
| Cable types per IEEE 802.3      | Shielded twisted pair min. STP CAT 5/ STP CAT 5e |
| Data transmission rate          | 10/100 Mbit/s                                    |
| Max. cable length               | 100 m  |
| Flow control                    | Half Duplex/Full Duplex (IEEE 802.3x-Pause)      |

### 4.6. Function indicators



#### Module status

| LED | Status             | Function  |
|-----|--------------------|---|
| UA  | green              | Output power OK                                       |
|     | red flashing       | Low Output power (< 18V)                              |
|     | red                | No output power (< 11V)                               |
| US  | green              | Input power OK  |
|     | red flashing       | Low Input power (<18V)                                |
| Mod | green flashing     | Wrong or no configuration on module                   |
|     | green              | Modul operating                                       |
|     | red flashing       | Fixed busclock is not possible                        |
|     | red-green flashing | Initial sequence                                      |
| Net | off                | Module got no IP address                              |
|     | green flashing     | Module got IP, but no connection could be established |
|     | green              | Connection established                                |
|     | red flashing       | Connection timeout                                    |
| 100 | off                | Bus clock: 10 Mbit/s                                  |
|     | yellow             | Bus clock: 100 Mbit/s                                 |
| LNK | green              | Data transfer   |

#### Port

Each Port has two two-colour LEDs to indicate the I/O-States.


|          | Status       | Function      | Description                           |
|----------|--------------|---------------|---------------------------------------|
| I/O Port | off          | I/O-State     | State of the Input or Output Pin is 0 |
|          | yellow       | I/O-State     | State of the Input or Output Pin is 1 |
|          | red flashing | Short-circuit | Short-circuit between Pin 1 and 3     |
|          | red          | Short-circuit | Short-circuit to dedicated Pin        |

## 5 Integration


### 5.1. Integration into a Rockwell RS Logix 5000

Here you see an example of how the module can be integrated into a Rockwell RS Logix 5000:

First go offline




Right-click Ethernet (on the correct scanner card)  
Select a new module




## 5 Integration

Then select the general Ethernet module as the ETHERNET module in the communication path




Now enter a user-defined tag name to select the general format Data-SINT, to enter the IP address of the module and to enter the correct connection parameters.




## 5 Integration

The new module and corresponding controller tags are generated automatically.




Then download the configuration



## 5 Integration

When the download is done, you can observe and control the tags using the Controller Tags option. Make sure you select the correct tag name, which you configured beforehand. The input, output and configuration data for this is described on the following pages. You can use these tags for the programming, too.



**6 Configuration via Explicit Messages**

**QuickConnect** The QuickConnect function makes it faster to boot up and integrate the BNI EIP-302-105-X015, BNI EIP-202-105-X015 and BNI EIP-104-105-X015 modules.

Enabling QuickConnect automatically takes over all necessary port properties on the module:

- Static IP address
- Ports at 100 Mbps full-duplex
- Auto-negotiation disabled
- Auto MDI-X disabled
- Prepared for linear topology

You can configure **QuickConnect** via the following class instance attribute of the explicit messages:

| Class      | Instance | Attribute | Value                                      |
|------------|----------|-----------|--|
| 245 (0xF5) | 1 (0x01) | 12 (0x0C) | 0: disabled (default)<br><b>1: enabled</b> |

---

**i Note** For QuickConnect to be enabled, ACD (Address Conflict Detection) must also be enabled. This is switched on by default.

---

The **ACD** can be reviewed and changed using the following class instance attributes of the explicit messages:

| Class      | Instance | Attribute | Value                                      |
|------------|----------|-----------|--|
| 245 (0xF5) | 1 (0x01) | 10 (0x0A) | 0: disabled<br><b>1: enabled</b> (default) |

Overview of the QuickConnect classes and connection time:

BNI EIP-302-105-x015 HW 4 SW 2.6:  
QuickConnect Class B, connection time 1 second

BNI EIP-202-105-x015 HW 4 SW 2.6:  
QuickConnect is not supported.

BNI EIP-104-105-x015 HW 4 SW 2.9:  
QuickConnect is not supported.

BNI EIP-302-105-x015 HW 6 SW ≥ 3.6:  
QuickConnect Class A, connection time 350 milliseconds

BNI EIP-202-105-x015 HW 6 SW ≥ 4.2:  
QuickConnect Class A, connection time 350 milliseconds

BNI EIP-104-105-x015 HW 6 SW ≥ 3.6:  
QuickConnect Class A, connection time 350 milliseconds

## 6 Configuration via Explicit Messages


### Rockwell Automation Products that are Compatible with QuickConnect

| Component   | Supported Rockwell Automation Products  |
|---|---|
| Controller  | ControlLogix® controllers: <ul style="list-style-type: none"> <li>• 1756-L6x</li> <li>• 1756-L7x</li> </ul> GuardLogix controllers: <ul style="list-style-type: none"> <li>• 1756-L6xS</li> <li>• 1756-L7xS</li> </ul> All controllers require firmware revision 20.001 or later.           |
| EtherNet/IP managed switch on the controller side                                     | Stratix 6000 switches: <ul style="list-style-type: none"> <li>• 1783-EMS04T</li> <li>• 1783-EMS08T</li> </ul> Stratix 8000 switches: <ul style="list-style-type: none"> <li>• 1783-MS06T or 1783-MS10T</li> <li>• 1783-RMS06T or 1783-RMS10T</li> <li>• 1783-MX08T or 1783-MX08F</li> </ul> |
| EtherNet/IP communication modules   | ControlLogix communication modules: <ul style="list-style-type: none"> <li>• 1756-EN2T with firmware revision 4.003</li> <li>• 1756-ENBT with firmware revision 6.002</li> </ul>  |
| Application logic that uses generic CIP Messages to inhibit and uninhibit I/O modules | Studio 5000 Logix Designer application, version 21.00.00 or later<br>or<br>RSLogix 5000 software, version 20.01.02  |

Source:  
 Allen-Bradley Ethernet/IP QuickConnect Application Technique  
 Page 13

6 Configuration via Explicit Messages

Example with  
Rockwell  
Components



Source:  
Allen-Bradley Ethernet/IP QuickConnect Application Technique, Page 12

Please also note the following:

- Direct connection between PLC and QuickConnect slave with crossover cable
- Slave-to-slave connection using patch cable
- For setting up the topology, only the linear topology with a maximum of 20 modules on the tool side is permitted.
- If needed, only one managed switch may be used between the PLC and Ethernet/IP slave.
- To trigger the QuickConnect sequence, an electrical lock signal is required that reads in the supply voltage of the QuickConnect slaves via the controller.

PLC Program

Add Application Logic

Add ladder logic to inhibit and uninhibit QuickConnect I/O modules:

- Run this logic in a periodic task with a recommended 10 ms update rate.
- The logic examples shown configure two ArmorBlock I/O modules. Modify the code as needed to configure as many as 20 ArmorBlock I/O modules.

**IMPORTANT** A connection time of 500 ms with 20 QuickConnect modules is supported with only a ControlLogix 1756-L7x controller and 1756-EN2T communication module. For average connection times per number of modules, see [Average Timing with Rockwell Automation Products on page 50](#).


Inhibit and Power Down

Add this logic to inhibit and power down the QuickConnect modules.

1. Rung 0: Inhibit the modules.

Before making a tool change, you must uninhibit the QuickConnect ArmorBlock I/O modules mounted to the tool before powering down. Use a GSV (Mode) instruction to monitor the present state of the modules and one SSV (Mode) instruction per module to inhibit the modules.

The input condition to start the inhibit process must come from an external input. For example, as the robot is traveling back to change out the tool, this input condition must be enabled. By the time the tool is being changed, the modules are inhibited and can proceed to powering down the tool and modules.




Source: Allen-Bradley Ethernet/IP QuickConnect Application Technique, Page 29

6 Configuration via Explicit Messages

2. Rung 1: Verify the modules are inhibited.

After the modules have been inhibited, verify that the modules have indeed been inhibited. Use one GSV (Entry Status) instruction per module. When the Entry Status value equals a decimal value of 24576, the module can be disconnected from the robotic arm and powered down.



3. Rung 2: Power down the modules.

This rung verifies that all the modules have been inhibited and powered down. The tool and modules can be physically disconnected from the robotic arm.



Source:  
Allen-Bradley Ethernet/IP QuickConnect Application Technique, Page 30

### Uninhibit and Power Up

Add this logic to uninhibit and power up the QuickConnect I/O modules.

**1. Rung 3: Power up the modules.**


Once the tool and module is connected, an external input module sends an electrical lock input signal. On receipt of the signal, start a timer to keep track of how long the tool and modules have been connected.

Every QuickConnect ArmorBlock I/O module has a delay time embedded in its electronic data sheet (EDS) file. This delay time is the amount of time the module takes to power up. The module takes about 300 ms to fully power up before establishing a connection to the controller.



**2. Rung 4: Uninhibit the modules.**

When the Timer.Acc is greater then or equal to the module delay time (300 ms), use an SSV (Mode) instruction to uninhibit the module. Use a GSV (Mode) instruction to verify the mode of the module at powerup.




Source: Allen-Bradley Ethernet/IP QuickConnect Application Technique, Page 31

**6 Configuration via Explicit Messages**

3. (Optional) Rung 5: Verify the modules are uninhibited.

After the modules have been uninhibited, verify that the modules have indeed been uninhibited. Use one GSV (Entry Status) instruction per module. When the Entry Status value equals a decimal value of 16384, the module has been uninhibited.



Source:  
Allen-Bradley Ethernet/IP QuickConnect Application Technique, Page 32

**Fault State**

A safe state that the port is to take on in the case of a loss of bus communication can be predefined for each output on the port pins.

The fault state settings can be configured using the following class instance attributes of the explicit messages.

**Enable/Disable Fault State**

| Class    | Instance                                | Attribute | Value   |
|----------|---|-----------|---|
| 9 (0x09) | 1 – 16<br>(corresponds to outputs 0-15) | 6         | 0: Fault state disabled<br>1: Fault state enabled |

**Fault State Action**

| Class    | Instance                                | Attribute | Value                              |
|----------|---|-----------|------------------------------------|
| 9 (0x09) | 1 – 16<br>(corresponds to outputs 0-15) | 5         | 0: Output on<br>1: Hold last state |

**Note**



The fault state settings are stored only temporarily in the module. They are deleted after a power reset.

To ensure a long-term fault state configuration, the configuration has to be programmed via the PLC so that the settings are transferred to the module again when the system is restarted.

## 7 Process Data

### 7.1. Data Configuration BNI EIP-302-105-Z015

Please enter the following values to your Control System. They describe the datasizes for input, output and config data.

|        | Instance ID | Data length |
|--------|-------------|-------------|
| INPUT  | 100         | 8           |
| OUTPUT | 101         | 6           |

### 7.2. Process Data Inputs BNI EIP-302-105-Z015

There are 8 bytes of Input data. Have a look at the tables below to see the mapping of the process data inputs.

| Byte | Bit |     |     |     |     |     |     |     | Description   |
|------|-----|-----|-----|-----|-----|-----|-----|-----|---|
|      | 7   | 6   | 5   | 4   | 3   | 2   | 1   | 0   |   |
| 0    | I32 | I34 | I22 | I24 | I12 | I14 | I02 | I04 | Input data<br>I04 → Input on port 0 pin 4   |
| 1    | I72 | I74 | I62 | I64 | I52 | I54 | I42 | I44 |   |
| 2    | S3  |     | S2  |     | S1  |     | S0  |     | Short circuit status<br>Short circuit between Pin 1 and 3 on stated port                  |
| 3    | S7  |     | S6  |     | S5  |     | S4  |     |   |
| 4    | O22 | O34 | O22 | O24 | O12 | O14 | O02 | O04 | Overload status<br>O04 → Overload on port 0 pin 4<br>Only if port is configured as output |
| 5    | O72 | O74 | O62 | O64 | O52 | O54 | O42 | O44 |   |
| 6    | 0   | 0   | 0   | 0   | 0   | 0   | PS  | PA  | Power status<br>PS: Sensor power<br>PA: actor power                                       |
| 7    | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | Reserved  |

### 7.3. Process Data Output BNI EIP-302-105-Z015

There are 6 bytes of output data. Have a look at the tables below to see the mapping of the process data outputs.

| Byte | Bit |     |     |     |     |     |     |     | Description  |
|------|-----|-----|-----|-----|-----|-----|-----|-----|--|
|      | 7   | 6   | 5   | 4   | 3   | 2   | 1   | 0   |  |
| 0    | O32 | O34 | O22 | O24 | O12 | O14 | O02 | O04 | Output data<br>O04 → Output on port 0 pin 4  |
| 1    | O72 | O74 | O62 | O64 | O52 | O54 | O42 | O44 |  |
| 2    | R32 | R34 | R22 | R24 | R12 | R14 | R02 | R04 | Restart<br>Restart output here after a detected short-circuit  |
| 3    | R72 | R74 | R62 | R64 | R52 | R54 | R42 | R44 |  |
| 4    | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | Reserved   |
| 5    | 0   | 0   | 0   | 0   | 0   | DL  | GO  | RO  | Display Control<br>DL: Display lock / PLC lock<br>GO: Green LED on Display on<br>RO: Red LED on Display on |

7 Process Data

7.4. Data Configuration BNI EIP-202-105-Z015

Please enter the following values to your Control System. They describe the datasizes for input, output and config data.

|        | Instance ID | Data length |
|--------|-------------|-------------|
| INPUT  | 100         | 6           |
| OUTPUT | 101         | 6           |

7.5. Process Data Inputs BNI EIP-202-105-Z015

There are 6 bytes of Input data. Have a look at the tables below to see the mapping of the process data inputs.

| Byte | Bit |     |   |     |   |     |    |     | Description   |
|------|-----|-----|---|-----|---|-----|----|-----|---|
|      | 7   | 6   | 5 | 4   | 3 | 2   | 1  | 0   |   |
| 0    | 0   | I34 | 0 | I24 | 0 | I14 | 0  | I04 | Handshake data<br><i>I04 → Status on port 0 pin 4</i>   |
| 1    | 0   | I74 | 0 | I64 | 0 | I54 | 0  | I44 |   |
| 2    | 0   | O34 | 0 | O24 | 0 | O14 | 0  | O04 | Overload status<br><i>O04 → Overload on port 0 pin 4</i><br><i>Only if port is configured as output</i> |
| 3    | 0   | O74 | 0 | O64 | 0 | O54 | 0  | O44 |   |
| 4    | 0   | 0   | 0 | 0   | 0 | 0   | PS | PA  | Power status<br><i>PS: Sensor power</i><br><i>PA: actor power</i>                                       |
| 5    | 0   | 0   | 0 | 0   | 0 | 0   | 0  | 0   | Reserved  |

7.6. Process Data Output BNI EIP-202-105-Z015

There are 6 bytes of output data. Have a look at the tables below to see the mapping of the process data outputs.

| Byte | Bit |     |   |     |   |     |    |     | Description   |
|------|-----|-----|---|-----|---|-----|----|-----|---|
|      | 7   | 6   | 5 | 4   | 3 | 2   | 1  | 0   |   |
| 0    | 0   | O34 | 0 | O24 | 0 | O14 | 0  | O04 | Output data<br><i>O04 → Output on port 0 pin 4</i>  |
| 1    | 0   | O74 | 0 | O64 | 0 | O54 | 0  | O44 |   |
| 2    | 0   | R34 | 0 | R24 | 0 | R14 | 0  | R04 | Restart<br><i>Restart output here after a detected short-circuit</i>  |
| 3    | 0   | R74 | 0 | R64 | 0 | R54 | 0  | R44 |   |
| 4    | 0   | 0   | 0 | 0   | 0 | 0   | 0  | 0   | Reserved  |
| 5    | 0   | 0   | 0 | 0   | 0 | DL  | GO | RO  | Display Control<br><i>DL: Display lock / PLC lock</i><br><i>GO: Green LED on Display on</i><br><i>RO: Red LED on Display on</i> |

## 7 Process Data

### 7.7. Data Configuration BNI EIP-104-105-Z015

Please enter the following values to your Control System. They describe the datasizes for input, output and config data.

|        | Instance ID | Data length |
|--------|-------------|-------------|
| INPUT  | 100         | 6           |
| OUTPUT | 101         | 2           |

### 7.8. Process Data Inputs BNI EIP-104-105-Z015

There are 6 bytes of Input data. Have a look at the tables below to see the mapping of the process data inputs.

| Byte | Bit |     |     |     |     |     |     |     | Description   |
|------|-----|-----|-----|-----|-----|-----|-----|-----|---|
|      | 7   | 6   | 5   | 4   | 3   | 2   | 1   | 0   |   |
| 0    | I32 | I34 | I22 | I24 | I12 | I14 | I02 | I04 | Input data<br><i>I04 → Input on port 0 pin 4</i>                                |
| 1    | I72 | I74 | I62 | I64 | I52 | I54 | I42 | I44 |   |
| 2    | S3  |     | S2  |     | S1  |     | S0  |     | Short circuit status<br><i>Short circuit between Pin 1 and 3 on stated port</i> |
| 3    | S7  |     | S6  |     | S5  |     | S4  |     |   |
| 4    | 0   | 0   | 0   | 0   | 0   | 0   | PS  | PA  | Power status<br><i>PS: Sensor power<br/>PA: actor power</i>                     |
| 5    | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | <i>Reserved</i>   |

### 7.9. Process Data Output BNI EIP-104-105-Z015

There are 2 bytes of output data. Have a look at the tables below to see the mapping of the process data outputs.

| Byte | Bit |   |   |   |   |    |    |    | Description   |
|------|-----|---|---|---|---|----|----|----|---|
|      | 7   | 6 | 5 | 4 | 3 | 2  | 1  | 0  |   |
| 0    | 0   | 0 | 0 | 0 | 0 | 0  | 0  | 0  | <i>Reserved</i>   |
| 1    | 0   | 0 | 0 | 0 | 0 | DL | GO | RO | Display Control<br><i>DL: Display lock / PLC lock<br/>GO: Green LED on Display on<br/>RO: Red LED on Display on</i> |

8 Display

8.1. General

With the implemented display, the address is set directly on the BNI EIP... devices. The following address types are implemented:

- IP address
- Subnet mask
- Gateway address.

Each address type consists of 4 octets.


Additional the display shows information about the hard- and firmware revision.

There is a lock function for the display which can be activated out of the control system. If the lock is set editing isn't possible anymore.

8.2. Address Specifications

IP Address: 192.168.1.1  
 Subnetmask: 255.255.255.0  
 Gatewayaddress: 192.168.1.1


8.3. Controls and visualization



- 1 Display
- 2 Arrow-Key
- 3 Octett-Cursor

- 4 Address type cursor
- 5 „Set“-Key
- 6 LED

8.4. Display information




IP: IP address  
 SN: Subnet address  
 GW: Gateway address


3: first octet  
 2: second octet  
 1: third octet  
 0: fourth octet

8.5. Design and Symbols


There are some symbols used in the following flow-charts to describe the display-functionality:



8.6. Startup




8.7. Main Menu



- Scrolling in main menu with short-time keypress on set-key
- Step in menu with short-time keypress on arrow-key


8 Display

8.8. IP Setup




- Long-time keypress on set key starts editing mode.
- Configuration of the favored value by short-time keypress on arrow-key

8.9. Network Config



- Long-time keypress on set key starts editing mode.
- Configuration of the favored value by short-time keypress on arrow-key
- Long-time keypress on arrow key uses fast program mode
- Shorttime keypress on set key saves entered value and scrolls to the next octet. The 4.octet is the start of editing
- The whole entered address gets saved by short keypress on set value when editing first octet. The entered value can immediately seen on the ip overview screen.
- Manual changes to IP, subnet or gateway results in automatic change to “static” in IP Setup.

## 8.10. Edit mode




- In the Network Configuration menu, select IP / Subnet or Gateway Address.
- Press the set button long to switch to edit mode.
- Press the arrow key briefly to change the number.
- Press the Set button briefly to move to the next position.
- After the last digit, press the set button briefly to move to the next octet of the address or to accept the new number after the last octet.

**Note**

The module has to be restarted to work with the new configuration.

8 Display

8.11. Module information



- By short-time keypress on arrow key you can scroll through module information menu.
- Informations are the product name, the module revisions and the MacID.

8.12. General Informations

- Longtime keypress for „fast scrolling“ in editing mode
- 10 seconds without keypress results in leaving actual screen and entering the default screen mode (4<sup>th</sup> octet of ip address). Unsaved changes gets lost
- Differences between new configuration and the configuration the module is working with are shown by a unequal-symbol. In this case the time to default screen is only 5 seconds.
- In editing mode the screen flashes. In fast scroll mode the screen is flickering
- If the module receives a single ping, the word “ping” is shown in the display screen for a few seconds. Afterwards the screen is reset to the screen which had been shown before. By short-time key press on set key the ping-mode can be left preterm.
- If the module receives a double ping, the word “ping” is shown in the display. This screen can be left only by short-time key press on set key. The screen shown before ping gets viewed again.
- The Led function at the display leds can be defined user specific by setting some bits in the process data inputs.
- The function plc-lock can also be used by setting a bit in the process data inputs.



**Note:**

Editing mode can not be chosen in display if the plc lock bit in process data inputs is. (See bit layout process data outputs)

9.1. General Information

The BNI fieldbus module contains an integrated web server for retrieving detailed device information and for configuring the device.

To use the web interface you must first ensure that the module has been correctly integrated into your network. In addition the IP subnet of the BNI module must be accessible from the PC on which the browser is running. For the supported web browser, please refer to the corresponding data sheet.

For open a connection with the web server, enter the IP address of the module in the address line of the browser. The homepage then appears with the essential device information.

The screenshot shows the web interface for the Balluff BNI PNT-302-105-Z015 module. The interface includes a navigation bar with icons for Home, Login, Config, Log, and Info. The main content area is titled 'Module Information' and lists the following details:

- Product Name: BNI PNT-302-105-Z015
- Order Code: BNI0052
- Name: MyNiceModule
- Location: 73765 Neuhausen a.d.F, Germany
- Contact: Balluff GmbH
- Firmware Revision: 3.2
- Hardware Revision: 6
- Station name: myweb
- IP Address: 192.168.0.4
- Subnet Mask: 255.255.255.0
- Gateway Address: 0.0.0.0
- MAC Address: 00:19:31:3F:FF:32
- Link Speed Port 1: 100 Mbit/s FULL
- Link Speed Port 2: No Link
- PLC Lock: No

To the right of the text is an image of the physical module, a vertical DIN rail mount with eight green RJ45 ports. Above the ports are status LEDs labeled 'In' and 'Out'. Below the image is the 'LED Legend'.

**PROFI NET**


LED Legend

## 9 Webservice

### 9.2. Navigation / Info

The navigation bar is located in the upper area of the window, which allows you to switch between the various dialogs of the web interface. To do this click on the corresponding icon.

When the "Info" tab is selected the following overview appears:



The "BALLUFF" logo at upper right links to the international Balluff homepage.


9.3. Login/Logout

To make configuration settings on the fieldbus module using the web interface, you must first log in. Functionalities which cannot be used without logging in are indicated by the grayed out buttons.


The default password is:

|                      |          |
|----------------------|----------|
| BNI PNT-XXX-XXX-XXXX | "BNIPNT" |
| BNI EIP-XXX-XXX-XXXX | "BNIEIP" |
| BNI ECT-XXX-XXX-XXXX | "BNIECT" |

The password cannot be changed!



After successfully logging in the dialogs are shown as follows:



Use the "Logout" button to log out again. After 5 minutes of no interaction with the Webserver the user is automatically logged out.

---

**Note**  
 For security reasons the fieldbus module shows only one login at a time with configuration access. Reading (without logging in) is however possible from multiple PCs at the same time on the fieldbus module.

---

## 9 Webservice

### 9.4. "Home" dialog

Under "Home" you are given the essential information about the fieldbus itself and its network activity. You are also shown whether the configuration block was enabled by the controller (PLC).

Information is also shown about the current process data and the status of the module via the corresponding LEDs. After selecting "LED Legend" a Help dialog appears which explains the meaning of the LEDs

**BALLUFF** BNI PNT-302-105-Z015 Home Logout Config Log Info

**Module Information**

|                    |                                |
|--------------------|--------------------------------|
| Product Name:      | BNI PNT-302-105-Z015           |
| Order Code:        | BNI0052                        |
| Name:              | MyNiceModule                   |
| Location:          | 73765 Neuhausen a.d.F, Germany |
| Contact:           | Balluff GmbH                   |
| Firmware Revision: | 3.2                            |
| Hardware Revision: | 6                              |
| Station name:      | myweb                          |
| IP Address:        | 192.168.0.4                    |
| Subnet Mask:       | 255.255.255.0                  |
| Gateway Address:   | 0.0.0.0                        |
| MAC Address:       | 00:19:31:3F:FF:32              |
| Link Speed Port 1: | 100 Mbit/s FULL                |
| Link Speed Port 2: | No Link                        |
| PLC Lock:          | No                             |



**PROFINET**

LED Legend

PNT:

**Module LED Functions**

| US  | UA            | SF               | BF    | 100 | LK1 | 100 | LK2 |
|-----|---------------|------------------|-------|-----|-----|-----|-----|
| US  | OK            | Low              |       |     |     |     |     |
| UA  | OK            | Low              | Alarm |     |     |     |     |
| SF  | Signal error  | IO-Link Service  |       |     |     |     |     |
| BF  | No config     | No data exchange |       |     |     |     |     |
| 100 | Connected     | Not connected    |       |     |     |     |     |
| LK  | Link activity | No link activity |       |     |     |     |     |

**Port LED Functions**

| IO      | 0            | 1             |
|---------|--------------|---------------|
| IO      | Open circuit | Short circuit |
|         | IO-Link      | IO-Link       |
| IO-Link | Wrong device | Short circuit |



EIP:

**Module LED Functions**

| US  | UA            | MODNET           | 100       | LK1     | 100 | LK2 |
|-----|---------------|------------------|-----------|---------|-----|-----|
| US  | OK            | Low              |           |         |     |     |
| UA  | OK            | Low              | Alarm     |         |     |     |
| Mod | Signal error  | Config Error     |           |         |     |     |
| Net | No config     | No data exchange | Connected | Timeout |     |     |
| 100 | 100 Mbit/s    | 10 Mbit/s        |           |         |     |     |
| LK  | Link activity | No link activity |           |         |     |     |

**Port LED Functions**

| IO      | 0            | 1             |
|---------|--------------|---------------|
| IO      | Open circuit | Short circuit |
|         | IO-Link      | IO-Link       |
| IO-Link | Wrong device | Short circuit |




> LED Legend

## 9 Webservice

### 9.5. "Config" dialog

The configuration page enables configuration of the module. You can change the module information texts and the (for EIP) IP-Configuration.

PNT / ECT:



EIP:



The parameter set "Module Configuration" on the left side is used by clicking "Save Configuration" and permanently stored in the device.

The "Reboot" button reboots the device as if the power to the module had been turned off and on again.

Clicking on "Factory Reset" deletes the configuration and log files saved in the device and then performs a reboot, so that the device is restored to the default factory configuration as on delivery.

9 Webservice

9.6. "Log" dialog

This dialog provides general service information about the device as well as a logging function. The upper table (see screenshot below) contains important information for all service inquiries.

**Note**  
 If you have a detailed question about a specific situation, send us a screenshot of this Web site or print the site as a PDF.

Logging shows events which have occurred in chronological order. This provides a tool for detailed troubleshooting in equipment.

**Information**

|                    |                      |                   |                          |
|--------------------|----------------------|-------------------|--------------------------|
| Product name:      | BNI PNT-302-105-Z015 | Browser time:     | 2017-01-23 15:58:00.039  |
| Firmware revision: | 3.2                  | System uptime:    | 4 mins 46 secs 959 msecs |
| MAC address:       | 00:19:31:99:CA:32    | Free flash space: | 2068 KB                  |
| IP address:        | 192.168.0.4          | Web version:      | 2.0.110                  |
| Browser version:   | Firefox 50.0         |                   |                          |

**Log** Set module time Clear Log Update Log

| No. | Severity      | Date                    | Origin | Message  |
|-----|---------------|-------------------------|--------|--|
| 0   | Notice        | 2000-01-01 00:00:00.426 | SYS    | System startup (Oct 20 2016, 14:57:42)               |
| 1   | Notice        | 2000-01-01 00:00:00.456 | SYS    | Set MAC address: 00:19:31:99:CA:32                   |
| 2   | Informational | 2000-01-01 00:00:00.459 | SYS    | Configuration updated with new data from device file |
| 3   | Notice        | 2000-01-01 00:00:01.959 | ETH    | Port 0: Link Up (100 MBit/s, full duplex)            |
| 4   | Notice        | 2000-01-01 00:04:42.911 | WEB_IF | Login successful, IP address: 192.168.0.50           |
| 5   | Notice        | 2000-01-01 00:04:45.129 | WEB_IF | Logout, IP address: 192.168.0.50                     |

Events are classified using the "Severity" column:

**Internal Error** (Emergency, Alert, Critical)

→ The fieldbus module has detected a fault in itself (hardware or software) which should not occur during normal operation. If this happens, the module must be serviced or replaced.

**External Error** (Error, Warning)

→ The fieldbus module has detected what may be a non-permissible event which is affecting the module from the outside. The system may require troubleshooting.

**Event** (Informational, Notice)

→ The fieldbus module has detected an important normal operating event and reports it. These may include for example configuration actions over the web interface and other configuration interfaces which are also recorded.

Clicking on "Set Module Time" sends the current browser time to the fieldbus module but does not permanently store it. After a reset, reboot or loss of power the time begins to run again from the year 2000.

Clicking on "Update Log" refreshes the display, and "Clear Log" deletes all entries. The log entries are stored in a ring buffer.


## 10 Appendix

### 10.1. Included material

The BNI EIP consists of the following components:

- I/O-block
- 4 blind plugs M12
- Ground strap
- Screw M4x6
- 20 labels

### 10.2. Order code



### 10.3. Order Information

| Product ordering code | Order code |
|-----------------------|------------|
| BNI EIP-104-105-Z015  | BNI004M    |
| BNI EIP-202-105-Z015  | BNI005J    |
| BNI EIP-302-105-Z015  | BNI004F    |

**Notes**

**[www.balluff.com](http://www.balluff.com)**

Balluff GmbH  
Schurwaldstrasse 9  
73765 Neuhausen a.d.F.  
Germany  
Tel. +49 7158 173-0  
Fax +49 7158 5010  
[balluff@balluff.de](mailto:balluff@balluff.de)