EN



P1KTxxx

Reflex Sensor



Operating Instructions

Table of Contents

| 1. | General | 3 |
|----|---|----|
| | 1.1 Information Concerning these Instructions | 3 |
| | 1.2 Explanations of Symbols | |
| | 1.3 Limitation of Liability | 4 |
| | 1.4 Copyrights | 4 |
| 2. | For Your Safety | .5 |
| | 2.1 Use for Intended Purpose | 5 |
| | 2.2 Use for Other than the Intended Purpose | 5 |
| | 2.3 Personnel Qualifications | |
| | 2.4 Modification of Products | |
| | 2.5 General Safety Precautions | 6 |
| | 2.6 Approvals and protection class | |
| 3. | Technical Data | |
| | 3.1 Accessory Products | _ |
| | 3.2 Layout | |
| | 3.3 Control Panel | |
| | 3.4 Scope of Delivery | |
| 4. | Transport and Storage | |
| | 4.1 Transport | |
| | 4.2 Storage | |
| 5. | Installation and Electrical Connection | 11 |
| | 5.1 Installation | |
| | 5.2 Electrical Connection | |
| | 5.3 Diagnostics | 12 |
| 6. | Settings | 13 |
| 7. | I/O-Link | 13 |
| 8. | Maintenance Instructions | 14 |
| 9. | Proper Disposal | 14 |
| 10 | Appendix | |
| | 10.1 List of Abbreviations | |
| | 10.2 Change Index, Operating Instructions. | |
| | 10.3 ELL Declaration of Conformity | |



1. General

1.1 Information Concerning these Instructions

- These instructions apply to the product with ID code P1KTxxx.
- They make it possible to use the product safely and efficiently.
- These instructions are an integral part of the product and must be kept on hand for the entire duration of its service life.
- · Local accident prevention regulations and national work safety regulations must be complied with as well.
- The product is subject to further technical development, and thus the information contained in these operating instructions may also be subject to change. The current version can be found at www.wenglor.com in the product's separate download area.



NOTE!

The operating instructions must be read carefully before using the product and must be kept on hand for later reference.

1.2 Explanations of Symbols

- · Safety precautions and warnings are emphasized by means of symbols and attention-getting words
- · Safe use of the product is only possible if these safety precautions and warnings are adhered to

The safety precautions and warnings are laid out in accordance with the following principle:



Attention-Getting Word! Type and Source of Danger!

Possible consequences in the event that the hazard is disregarded.

· Measures for averting the hazard.

The meanings of the attention-getting words, as well as the scope of the associated hazards, are listed below.



DANGER!

This word indicates a hazard with a high degree of risk which, if not avoided, results in death or severe injury.



WARNING!

This word indicates a hazard with a medium degree of risk which, if not avoided, may result in death or severe injury.



CAUTION!

This word indicates a hazard with a low degree of risk which, if not avoided, may result in minor or moderate injury.



ATTENTION!

This word draws attention to a potentially hazardous situation which, if not avoided, may result in property damage.



NOTE!

A note draws attention to useful tips and suggestions, as well as information regarding efficient, error-free use.

1.3 Limitation of Liability

- The product has been developed in consideration of the current state-of-the-art and applicable standards and guidelines. Subject to change without notice.
- A valid declaration of conformity can be accessed at www.wenglor.com in the product's separate download area.
- wenglor sensoric elektronische Geräte GmbH (hereinafter referred to as "wenglor") excludes all liability in the event of:
 - · Non-compliance with the instructions
 - Use of the product for purposes other than those intended
 - · Use by untrained personnel
 - · Use of unapproved replacement parts
 - · Unapproved modification of products
- These operating instructions do not include any guarantees from wenglor with regard to the described procedures or specific product characteristics.
- wenglor assumes no liability for printing errors or other inaccuracies contained in these operating instructions, unless wenglor was verifiably aware of such errors at the point in time at which the operating instructions were prepared.

1.4 Copyrights

- The contents of these instructions are protected by copyright law.
- · All rights are reserved by wenglor.
- Commercial reproduction or any other commercial use of the provided content and information, in particular graphics and images, is not permitted without previous written consent from wenglor.

4 General



2. For Your Safety

2.1 Use for Intended Purpose

The product is based on the following functional principle:

Reflex Sensor

This sensor is used for object detection in accordance with the reflex sensor principle.

In the case of reflex sensors, the emitter and the receiver are located in the same housing. The object to be detected reflects the light beam coming from the emitter. The receiver absorbs the reflected light and the analysis electronics process it as a switching signal. Due to the fact that bright objects are more reflective than dark objects, they can be detected from greater distances.

This product can be used in the following industry sectors:

- Special machinery manufacturing
 Consumer goods industry
- Heavy machinery manufacturing
- · Logistics
- · Automotive industry
- Food industry
- Packaging industry
- Pharmaceuticals industry
- Plastics industry
- Woodworking industry

- · Paper industry
- · Electronics industry
- · Glass industry
- Steel industry
- Aviation industry
- · Chemicals industry
- Alternative energy
- · Raw materials extraction

2.2 Use for Other than the Intended Purpose

- Not a safety component in accordance with 2006/42/EC (Machinery Directive)
- The product is not suitable for use in potentially explosive atmospheres.
- The product may only be used with accessories supplied or approved by wenglor, or combined with approved products. A list of approved accessories and combination products can be accessed at www.wenglor.com on the product detail page.

DANGER!



Risk of personal injury or property damage in case of use for other than the intended purpose!

Use for other than the intended purpose may lead to hazardous situations.

Observe instructions regarding use for intended purpose.

2.3 Personnel Qualifications

- Suitable technical training is a prerequisite.
- In-house electronics training is required.
- Trained personnel must have uninterrupted access to the operating instructions.



DANGER!

Risk of personal injury or property damage in case of incorrect initial start-up and maintenance!

Personal injury and damage to equipment may occur.

• Adequate training and qualification of personnel.

2.4 Modification of Products

DANGER!






Personal injury and damage to equipment may occur. Non-observance may result in loss of the CE marking and the guarantee may be rendered null and void.

Modification of the product is impermissible.

2.5 General Safety Precautions

NOTE!





- In the event of possible changes, the respectively current version of the operating instructions can be accessed at www.wenglor.com in the product's download area.
- Read the operating instructions carefully before using the product.
- Protect the sensor against contamination and mechanical influences.

2.6 Approvals and protection class









6 For Your Safety



3. Technical Data

| Order Number | | P1KT | |
|----------------------------|-------------------------|---------------|----------|
| Technical Data | | 001 | 003 |
| Optical Data | | | |
| Detection range | | 700 | mm |
| Switching hysteresis | | < 1 | 0 % |
| Light source | | Red light | |
| Service life (ambient temp | p. = +25 °C) | 100,000 hours | |
| Max. permissible ambien | t light | 10,000 lux | |
| Aperture angle | | < 6° | |
| Spot diameter | | See ta | able 1 |
| Electrical Data | | | |
| Supply power | | 1030 | O V DC |
| IO-Link supply voltage | | 1830 | O V DC |
| Current consumption (op | erating voltage = 24 V) | ≤ 20 | mA |
| Switching frequency | | 500 | Hz |
| Switching frequency (spe | eed mode) | 1000 |) Hz |
| Response time | | 1 r | ns |
| Response time (speed m | ode) | 0.5 | |
| Temperature drift | | < 1 | 0 % |
| Temperature range | | -40 | .60 °C |
| Switching output voltage | | < 2 V | |
| Switching output switching | ng current | 100 | mA |
| Switching output residua | l current | < 50 μA | |
| Short-circuit protection | | Yes | |
| Reverse polarity protecte | d | Yes | |
| Overload-proof | | Yes | |
| Lockable | | Yes | |
| Interface | | IO-Link | |
| IO-Link version | | 1.1 | |
| Protection class | | I | <u> </u> |
| | PNP | × | |
| Output function | NPN | | × |
| | NC, NO antivalent | × | × |
| Connection Diagram No. | | 215 | 213 |
| Mechanical Data | | | |
| Setting method | | Potentiometer | |
| Housing material | | Plastic | |
| Degree of protection | | IP68 | |
| Connection | | M8×1, 4-pin | |
| Lens cover | | PM | MA |
| Technical Safety Data | | | |
| MTTFd (EN ISO 13849-1) | | 2630, 72 a | |

Spot Diameter

| Detection range | 100 mm | 300 mm | 700 mm |
|-----------------|--------|--------|--------|
| Spot diameter | 20 mm | 40 mm | 80 mm |

Table 1


Detection Range

| Reference Material | Detection Range |
|--------------------|-----------------|
| White (90 %) | 700 mm |
| Gray (18 %) | 400 mm |
| Black (6 %) | 200 mm |

Table 2

3.1 Accessory Products

wenglor can provide you with suitable connection technology for your product.




PNP-NPN converter BG7V1P-N-2M

IO-Link master

wTeach2 software DNNF005

3.2 Layout



- 1 = emitter diode2 = receiver diode
- M3 screw = 0.5 Nm
- Potentiometer = 40 Nmm
- Dimensions specified in mm (1 mm = 0.03937")

8 Technical Data



3.3 Control Panel



05 = switching distance adjuster 30 = switching status indicator / contamination warning

68 = supply power indicator

3.4 Scope of Delivery

- Sensor
- · Safety precautions
- Mounting-Set 01

4. Transport and Storage

4.1 Transport

Upon receipt of shipment, the goods must be inspected for damage in transit. In the case of damage, conditionally accept the package and notify the manufacturer of the damage. Then return the device, making reference to damage in transit.

4.2 Storage

The following points must be taken into condition with regard to storage:

- Do not store the product outdoors.
- Store the product in a dry, dust-free place.
- · Protect the product against mechanical impacts.
- · Protect the product against exposure to direct sunlight.

ATTENTION!



Risk of property damage in case of improper storage!

The product may be damaged.

• Storage instructions must be complied with.



5. Installation and Electrical Connection

5.1 Installation

- Protect the product from contamination during installation.
- · Observe all applicable electrical and mechanical regulations, standards, and safety rules.
- Protect the product against mechanical influences.
- Make sure that the sensor is mounted in a mechanically secure fashion.
- Specified torque values must be complied with (see "3. Technical Data" on page 7).

ATTENTION!



Risk of property damage in case of improper installation!

The product may be damaged.

• Installation instructions must be complied with.

CAUTION!





Risk of personal injury or property damage during installation!

Personal injury and damage to the product may occur.

A safe installation environment must be assured.

5.2 Electrical Connection





| Legen | d | | |
|----------|---------------------------------|------------|--|
| + | Supply Voltage + | | |
| - | Supply Voltage 0 V | | |
| ~ | Supply Voltage (AC Voltage) | | |
| Α | Switching Output | (NO) | |
| Ā | Switching Output | (NC) | |
| V | Contamination/Error Output | (NO) | |
| V | Contamination/Error Output | (NC) | |
| E | Input (analog or digital) | | |
| T | Teach Input | | |
| Z | Time Delay (activation) | | |
| S | Shielding | | |
| RxD | Interface Receive Path | | |
| TxD | Interface Send Path | | |
| RDY | Ready | | |
| GND | Ground | | |
| CL | Clock | | |
| E/A | Output/Input programmable | | |
| 0 | IO-Link | | |
| PoE | Power over Ethernet | | |
| IN | Safety Input | | |
| OSSD | Safety Output | | |
| Signal | Signal Output | | |
| BI_D+/- | Ethernet Gigabit bidirect. data | line (A-D) | |
| ENons422 | Encoder 0-pulse 0-0 (TTL) | | |

| nc | not connected |
|-----------|------------------------------|
| U | Test Input |
| Ū | Test Input inverted |
| W | Trigger Input |
| 0 | Analog Output |
| 0- | Ground for the Analog Output |
| BZ | Block Discharge |
| Awv | Valve Output |
| a | Valve Control Output + |
| b | Valve Control Output 0 V |
| SY | Synchronization |
| E+ | Receiver-Line |
| S+ | Emitter-Line |
| ÷ | Grounding |
| SnR | Switching Distance Reduction |
| Rx+/- | Ethernet Receive Path |
| Tx+/- | Ethernet Send Path |
| Bus | Interfaces-Bus A(+)/B(-) |
| La | Emitted Light disengageable |
| Mag | Magnet activation |
| RES | Input confirmation |
| EDM | Contactor Monitoring |
| ENARS422 | Encoder A/Ā (TTL) |
| ENBR\$422 | Encoder B/B (TTL) |
| | |

PT Platinum measuring resistor

| ENA | Encoder A |
|--|--|
| ENB | Encoder B |
| Amin | Digital output MIN |
| Амах | Digital output MAX |
| Аок | Digital output OK |
| SY In | Synchronization In |
| SY OUT | Synchronization OUT |
| OLT | Brightness output |
| М | Maintenance |
| DIN IE | |
| DIN IE | C 757 |
| DIN IE | C 757 Black |
| DIN IE | C 757 Black Brown |
| BK BN | C 757 Black Brown Red |
| DIN IE BK BN RD | C 757 Black Brown |
| BK BN RD OG | C 757 Black Brown Red Orange |
| BK BN RD OG YE | C 757 Black Brown Red Orange Yellow |
| BK BN RD OG YE GN | C 757 Black Brown Red Orange Yellow Green |
| BK BN RD OG YE GN BU | C 757 Black Brown Red Orange Yellow Green Blue |
| BK BN RD OG YE GN BU VT | C 757 Black Brown Red Orange Yellow Green Blue Violet |
| BK BN RD OG YE GN BU VT GY | C 757 Black Brown Red Orange Yellow Green Blue Violet Grey |

DANGER!



Risk of personal injury or property damage due to electric current!

Voltage conducting parts may cause personal injury or damage to equipment.


• The electric device may only be connected by appropriately qualified personnel.

5.3 Diagnostics

Causes for Triggering the Contamination Warning (blinking LED):

| Display LED | Diagnosis/Cause | Elimination | |
|-------------------------------------|---|--|--|
| | Contamination | Carefully clean the optic cover with a cloth. | |
| Continuous blinking | s blinking Aged emitter diode Replace the sensor. | | |
| at approx. 2.5 Hz | Unreliable working range | Increase the sensor's switching distance. Reduce distance between sensor and object. | |
| | Short-circuit | Check electrical wiring and eliminate the short-circuit. | |
| Continuous blinking at approx. 5 Hz | Over-temperature | Disconnect the sensor from supply power and allow it to cool down. | |
| | Hardware error | Replace the sensor. | |

Contamination Warning Flowcharts



Indicator



Required action in case of fault:

NOTE!

- · Shut down the machine.
- Analyze and eliminate the cause of error with the help of the diagnostics information.
 - If the error cannot be eliminated, please contact wenglor's support department.
 - · Do not operate in case of indeterminate malfunctioning.
 - The machine must be shut down if the error cannot be unequivocally clarified or reliably eliminated.

DANGER!



Risk of personal injury or property damage in case of non-compliance!

The system's safety function is disabled. Personal injury and damage to equipment.

· Required action as specified in case of fault.

6. Settings

- Adjust and securely mount the sensor such that the spot strikes the object to be detected.
- Turn the potentiometer all the way to the left.
- Turn up the potentiometer until activation occurs and, if required, turn it up a bit more for increased switching reliability.

7. I/O-Link

Further settings are possible via the IO-Link interface. The IODD can be found at www.wenglor.com in the product's download area.

8. Maintenance Instructions

NOTE!



- This wenglor sensor is maintenance-free.
- Cleaning and inspection of the plug connections at regular intervals are advisable.
- Do not clean the sensor with solvents or cleansers which could damage the product.
- The product must be protected against contamination during initial start-up.

9. Proper Disposal

wenglor sensoric GmbH does not accept the return of unusable or irreparable products. Respectively valid national waste disposal regulations apply to product disposal.

10. Appendix

10.1 List of Abbreviations

| Abbreviation | Meaning |
|--------------|--------------------------------|
| Tu | Ambient temperature |
| Ub | Supply voltage |
| IODD | IO Device Description |
| MTTFd | Mean Time to Dangerous Failure |

10.2 Change Index, Operating Instructions

| Version | Date | Description/Change |
|---------|----------|---|
| 1.0.0 | 16.03.17 | Initial version of the operating instructions |
| 1.1.0 | 04.12.17 | "3. Technical Data" on page 7 |

10.3 EU Declaration of Conformity

The EU declaration of conformity can be found on our website at www.wenglor.com in the product's download area.

14 Maintenance Instructions

