







## **Model Number**

### OBE20M-R101-S2EP-IO-V31-IR

Thru-beam sensor with 4-pin, M8 x 1 connector

### **Features**

- Miniature design with versatile mounting options
- IO-link interface for service and process data
- Various frequencies for avoiding mutual interference (cross-talk immunity)
- Extended temperature range -40°C ... 60°C
- · High degree of protection IP69K


# **Product information**

The miniature optical sensors are the first devices of their kind to offer an end-to- end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.


## **Dimensions**



## **Electrical connection emitter**



### **Electrical connection receiver**



### **Pinout**


Wire colors in accordance with EN 60947-5-2




1	BN	(brown)	
2	WH	(white)	
3	BU	(blue)	
	DI	0.1.1.5	

## Indicators/operating means

## Emitter



### Receiver



- Operating indicator
- Light-on/dark-on changeover switch
- Sensitivity adjuster
- 3 Operating indicator / light on
- 4 Signal indicator
- 5 Operating indicator / dark on

## **Accessories**

### IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

#### OMH-R101

Mounting Clamp

## OMH-R101-Front

Mounting Clamp

### OMH-4.1

Mounting Clamp

## OMH-ML6

Mounting bracket

### OMH-ML6-U

Mounting bracket

### OMH-ML6-Z

Mounting bracket

### V31-GM-2M-PUR

Female cordset single-ended, M8, 4-pin, PUR cable

#### V31-WM-2M-PUR

Female cordset single-ended, M8, 4-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com

	Technical data		
	System components		
	Emitter		OBE20M-R101-S-IO-V31-IR
	Receiver		OBE20M-R101-2EP-IO-V31-IR
	General specifications		
	Effective detection range		0.2 20 m
	Threshold detection range		25 m
	Light source		LED
	Light type		modulated infrared light 850 nm
	LED risk group labelling		exempt group
	Diameter of the light spot		approx. 100 mm at a distance of 1 m
	Angle of divergence		5.4 °
	Ambient light limit		EN 60947-5-2 : 30000 Lux
	Functional safety related parame	eters	
	MTTF <sub>d</sub>		462 a
	Mission Time (T <sub>M</sub> )		20 a
	Diagnostic Coverage (DC)		0 %
	Indicators/operating means Operation indicator		LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode
	Function indicator		Yellow LED: Permanently lit - light path clear Permanently off - object detected
			Flashing (4 Hz) - insufficient operating reserve
	Control elements		Receiver: light/dark switch
	Control elements		Receiver: sensitivity adjustment
	Parameterization indicator		IO link communication: green LED goes out briefly (1 Hz)
	Electrical specifications		10 001/100
	Operating voltage	U <sub>B</sub>	10 30 V DC max. 10 %
	Ripple No-load supply current	I <sub>0</sub>	Emitter: ≤ 14 mA Receiver: ≤ 13 mA at 24 V supply voltage
	Protection class		III
	Interface		
	Interface type		IO-Link (via C/Q = pin 4)
	Transfer rate		COM 2 (38.4 kBaud)
	IO-Link Revision		1.1
	Min. cycle time		2.3 ms
	Process data witdh		Emitter: Process data output: 2 Bit Receiver: Process data input: 2 Bit Process data output: 2 Bit
	SIO mode support		yes
	Device ID		Emitter: 0x110401 (1115137) Receiver: 0x110301 (1114881)
	Compatible master port type		A
	Input		
	Test input		emitter deactivation at +U <sub>B</sub>
	Output		
ĮĘ,	Switching type		The switching type of the sensor is adjustable. The default setting is:  C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link /Q - Pin2: NPN normally closed / light-on, PNP normally open / dark-on
291120_eng.xm	Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected
911	Switching voltage		max. 30 V DC
	Switching current		max. 100 mA , resistive load
1-1	Usage category		DC-12 and DC-13 ≤ 1.5 V DC
19-1	Voltage drop Switching frequency	U <sub>d</sub>	1000 Hz
50	Response time	'	0.5 ms
sne	•		0.5 1115
Date of issue: 2019-11-14	Directive conformity  Electromagnetic compatibility		
ate	Directive 2014/30/EU		EN 60947-5-2/A1:2012
	Ambient conditions		LN 00041-0-2/A1.2012
Release date: 2019-11-14 11:11	Ambient temperature		-40 60 °C (-40 140 °F)
÷.	Storage temperature		-40 70 °C (-40 158 °F)
919-	Mechanical specifications		·
e: 2	Housing width		13.9 mm
dat	Housing height		41.4 mm
ase	Housing depth		18.3 mm
ee	•		


Refer to "General Notes Relating to Pepperl+Fuchs Product Information".


Degree of protection	IP67 / IP69 / IP69K
Connection	M8 x 1 connector, 4-pin
Material	
Housing	PC (Polycarbonate)
Optical face	PMMA
Mass	Emitter: approx. 10 g receiver: approx. 10 g
Compliance with standards and directives	
Standard conformity	
Product standard	EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012
Standards	UL 60947-5-2: 2014 IEC 61131-9:2013 EN 62471:2008 EN 61131-9:2013
Approvals and certificates	

 $\mathsf{E87056}$  , cULus Listed , class 2 power supply , type rating 1


# **Curves/Diagrams**

**UL** approval





# **Functions and Operation**



- 1 Light-on / dark-on changeover switch
- 2 Sensing range /sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

**FPEPPERL+FUCHS** 

To unlock the adjustment functions turn the sensing range adjuster for more than 180 degrees.

## **Sensing Range / Sensitivity**

Turn sensing range / sensivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range /sensivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

## **Light-on / Dark-on Configuration**

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on / dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

### **Restore Factory Settings**

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensivity adjustment is locked. In order to reactivate the sensing range /sensivity adjustment, turn the sensing range / sensivity adjuster for more than 180 degrees.