

Model Number

OBE20M-R100-S2EP-IO-0,3M-V1-L

Laser thru-beam sensor with fixed cable and M12 connector, 4-pin

Features

- Miniature design with versatile • mounting options
- DuraBeam Laser Sensors durable ٠ and employable like an LED
- IO-link interface for service and • process data
- Various frequencies for avoiding mutual interference (cross-talk immunity)
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K


Product information

The R100 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design - from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.


The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.



Electrical connection emitter



Electrical connection receiver



2 3 4

Pinout



Wire colors in accordance with EN 60947-5-2 BN WH BU BK (brown (white) (blue) (black)

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Emitter

Receiver

Ø

 (\mathbb{P})

Indicators/operating means Laserlabel Operating indicator 1 CLASS 1 I. I. I ASER 1 PRODUCT 1 2 Light-on/Dark-on changeover switch 1 CLASS 1 2 Sensitivity adjuster LASER PRODUCT 3 Operating indicator / dark on T IEC 60825-1: 2007 certified. i ti Complies with 21 CFR 1040.10 and 1040.11 except 4 4 Signal indicator 5 Operating indicator / light on for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 5 CLASS 1 LASER PRODUCT IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 Accessories V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable V1-G-2M-PUR Female cordset, M12, 4-pin, PUR cable IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection OMH-R10X-01 Mounting bracket OMH-R10X-02 Mounting bracket OMH-R10X-04 Mounting bracket OMH-R10X-10 Mounting bracket OMH-ML100-03 _eng.xml Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm 281006_ OMH-ML100-031 Mounting aid for round steel issue: 2018-09-19 ø 10 ... 14 mm or sheet 1 mm ... 5 mm V31-GM-2M-PUR Female cordset, M8, 4-pin, PUR cable V31-WM-2M-PUR Date of Female cordset, M8, 4-pin, PUR cable Other suitable accessories can be found at www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

2

Germany: +49 621 776 4411

fa-info@de.pepperl-fuchs.com



Laser thru-beam	senso	r	OBE
Technical data			
System components			
Emitter		OBE20M-R100-S-IO-0,3M-V1-L	
Receiver		OBE20M-R100-2EP-IO-0,3M-V1-L	
General specifications			
Effective detection range		0 20 m	
Threshold detection range		30 m	
Light source		laser diode	
Light type		modulated visible red light	
Laser nominal ratings			
Note		LASER LIGHT , DO NOT STARE INTO BEAM	
Laser class		1	
Wave length		680 nm	
Beam divergence		> 5 mrad ; d63 < 2 mm in the range of 250 mm 750 n	۱m
Pulse length Repetition rate		1.6 μs max. 17.6 kHz	
max. pulse energy		9.6 nJ	
Diameter of the light spot		approx. 50 mm at a distance of 20 m	
Angle of divergence		approx. 0.3 °	
Ambient light limit		EN 60947-5-2 : 30000 Lux	
Functional safety related paran	neters		
MTTFd		440 a	
Mission Time (T _M)		20 a	
Diagnostic Coverage (DC)		0 %	
Indicators/operating means			
Operation indicator		LED green:	
		constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode	
Function indicator		Yellow LED: Permanently lit - light path clear Permanently off - object detected Flashing (4 Hz) - insufficient operating reserve	
Control elements		Receiver: light/dark switch	
Control elements		Receiver: sensitivity adjustment	
Parameterization indicator		IO link communication: green LED goes out briefly (1 H	z)
Electrical specifications		40 001/00	
Operating voltage	UB	10 30 V DC max. 10 %	
Ripple		max. 10 % Emitter: < 13 mA	
No-load supply current Protection class	I _O	Emitter: ≤ 13 mA Receiver: ≤ 13 mA at 24 V supply voltage	
Interface		111	
Interface type		IO-Link (via C/Q = pin 4)	
Transfer rate		COM 2 (38.4 kBaud)	
IO-Link Revision		1.1	
Min. cycle time		2.3 ms	
Process data witdh		Emitter: Process data output: 2 Bit Receiver:	
		Process data input: 2 Bit Process data output: 2 Bit	
SIO mode support		yes	
Device ID		Emitter: 0x110402 (1115138) Reciever: 0x110302 (1114882)	
Compatible master port type		A	
Input			
Test input		emitter deactivation at +U _B	
Output			
Switching type		The switching type of the sensor is adjustable. The defa setting is: C/Q - Pin4: NPN normally open / dark-on, PNP normally light-on, IO-Link /Q - Pin2: NPN normally closed / light-on, PNP normally dark-on	/ closed /
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reve polarity protected, overvoltage protected	rse
Switching voltage		max. 30 V DC	

Switching voltage Switching current

Usage category

Response time

Product standard

Laser safety

www.pepperl-fuchs.com

Conformity

Switching frequency

Communication interface

Voltage drop

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

Germany: +49 621 776 4411 fa-info@us.pepperl-fuchs.com fa-info@de.pepperl-fuchs.com

max. 100 mA , resistive load

DC-12 and DC-13

 \leq 1.5 V DC

IEC 61131-9

EN 60947-5-2 EN 60825-1:2014

1250 Hz

0.4 ms

 U_{d}

f

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





Ambient conditions	
Ambient temperature	-40 60 °C (-40 140 °F) , fixed cable -25 60 °C (-13 140 °F) , movable cable not appropriate for conveyor chains
Storage temperature	-40 70 °C (-40 158 °F)
Mechanical specifications	
Housing width	11 mm
Housing height	37.1 mm
Housing depth	21.5 mm
Degree of protection	IP67 / IP69 / IP69K
Connection	300 mm fixed cable with M12 x 1, 4-pin connector
Material	
Housing	PC (Polycarbonate)
Optical face	PMMA
Mass	Emitter: approx. 10 g receiver: approx. 10 g
Cable length	0.3 m
Approvals and certificates	
UL approval	E87056 , cULus Listed , class 2 power supply , type rating 1

UL approval FDA approval

IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

Curves/Diagrams






Release date: 2018-06-08 14:05 Date of issue: 2018-09-19 281006_eng.xml

PEPPERL+FUCHS

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

4

Functions and Operation



- 1 Light-on / dark-on changeover switch 2 - Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.

