Thru-beam sensor

OBE25M-R200-SEP-IO-V3



Model Number

OBE25M-R200-SEP-IO-V3 Thru-beam sensor

with 3-pin, M8 x 1 connector

Features

- Medium design with versatile • mounting options
- IO-link interface for service and ٠ process data
- Various frequencies for avoiding • mutual interference (cross-talk immunity)
- Extended temperature range ٠ -40°C ... 60°C
- High degree of protection IP69K


Product information

The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.


Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and can be adapted to the application environment.



Electrical connection emitter



Electrical connection receiver



3

Pinout




Wire colors in accordance with EN 60947-5-2 BN BU BK (brown) (blue) (black)

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

Emitter

Receiver



1	Sensitivity adjustment	
2	Light-on / dark-on changeover switch	
3	Operating indicator / dark on	
4	Signal indicator	
5	Operating indicator / light on	

Operating indicator

1

Accessories

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

OMH-MLV12-HWK

Mounting bracket for series MLV12 sensors

OMH-R200-01

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

OMH-R20x-Quick-Mount Quick mounting accessory

OMH-MLV12-HWG Mounting bracket for series MLV12 sensors

V3-WM-2M-PUR

Female cordset single-ended, M8, 3-pin, PUR cable

V3-GM-2M-PUR

Female cordset single-ended, M8, 3-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com

2

Technical data		
System components Emitter	05	E25M-R200-S-IO-V3
Receiver		E25M-R200-EP-IO-V3
General specifications	05	
Effective detection range	0	25 m
Threshold detection range	33	n
Light source	LEI	
Light type		dulated visible red light
LED risk group labelling Alignment aid		mpt group) red (in receiver lens)
	illur flas	ninated constantly: beam is interrupted, hes: reaching switching point, sufficient stability control
Diameter of the light spot	app	rox. 850 mm at a distance of 25 m
Angle of divergence		rox. 2 °
Ambient light limit		60947-5-2 : 40000 Lux
Functional safety related parame	ters 462	a
Mission Time (T _M)	20	-
Diagnostic Coverage (DC)	60	%
Indicators/operating means		
Operation indicator	cor flas) green: stantly on - power on hing (4Hz) - short circuit hing with short break (1 Hz) - IO-Link mode
Function indicator	Per	ow LED: manently lit - light path clear manently off - object detected shing (4 Hz) - insufficient operating reserve
Control elements	Red	eiver: light/dark switch
Control elements	Red	eiver: sensitivity adjustment
Electrical specifications	11 10	20 1/ DC
Operating voltage Ripple	D	30 V DC <. 10 %
No-load supply current	I ₀ Em	tter: ≤ 15 mA eiver: ≤ 15 mA at 24 V Operating voltage
Protection class	111	
Interface		
Interface type		_ink (via C/Q = pin 4)
Device profile	Sm Red	ntification and diagnosis art Sensor: æiver: type 2.4 tter: -
Transfer rate	CO	M 2 (38.4 kBaud)
IO-Link Revision	1.1	
Min. cycle time Process data witdh	2.3 5m	ms tter:
Process data witun	Pro Pro Rec Pro	cess data input: 0 bit cess data output: 1 bit :eiver: cess data input: 2 bit cess data output: 2 bit
SIO mode support	yes	
Device ID	Red	tter: 0x111401 (1119233) eiver: 0x111301 (1118977)
Compatible master port type	A	
Input Test input	om	tter deactivation at +U _B
Output	eill	
Switching type	set C/C	switching type of the sensor is adjustable. The default ing is: ! - Pin4: NPN normally open / dark-on, PNP normally closed /
Signal output	1 p	t-on, IO-Link ush-pull (4 in 1) output, short-circuit protected, reverse arity protected, overvoltage protected
Switching voltage	•	A 30 V DC
Switching current		x. 100 mA , resistive load
Usage category		12 and DC-13
Voltage drop	u	5 V DC
Switching frequency		0 Hz
	0.5	ms
Response time	0.0	
Response time Conformity		61131-9
Response time	IEC	61131-9 60947-5-2
Response time Conformity Communication interface	IEC	
Response time Conformity Communication interface Product standard	IEC EN	

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com


Mechanical specifications


H Н H

Housing width	15 mm
Housing height	50.6 mm
Housing depth	41.7 mm
Degree of protection	IP67 / IP69 / IP69K
Connection	Connector plug, M8 x 1, 3 pin, rotatable by 90°
Material	
Housing	PC (Polycarbonate)
Optical face	PMMA
Mass	Emitter: approx. 35 g receiver: approx. 35 g

Approvals and certificates

UL approval CCC approval E87056, cULus Listed, class 2 power supply, type rating 1 CCC approval / marking not required for products rated ≤36 V





Functions and Operation

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

4

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.