


# **Dimensions**





# **Model Number**


#### M7/MV7/59/76a/102/115

Thru-beam sensor with 2 m fixed cable

#### **Features**

- Reliable sensor for standard applications
- Miniature design with versatile mounting options
- Automatic adjustment of sensitivity via TEACH-IN
- Resistant against noise: reliable operation under all conditions
- Certified by ECOLAB

# **Electrical connection**




- O = Light on
- = Dark on

# **Product information**

Small, robust, effective, and reliable - these are the properties of the ML7 sensor series. Due to their small size, number of versions, and two different lens positions, they are particularly suited for installation in tight spaces. The robust design and high quality of Pepperl+Fuchs mean they can also be used under harsh environmental conditions. The efficient technology, switching frequencies up to 1000 Hz, high resistance to ambient light, and 4-in-1 output make the series suitable for non-contact object detection.

# Indicators/operating means



1	Operating display	green
2	Signal display (Receiver)	yellow
3	Teach-In button (Receiver)	
1	Ontical center	

Technical data				
System components				
Emitter		M7/76a/115		
Receiver		MV7/59/102/115		
General specifications				
Effective detection range		0 3.5 m		
Threshold detection range		4.5 m		
Light source		LED		
Light type Target size Diameter of the light spot		modulated visible red light		
		min. 7 mm		
		approx. 180 mm at a distance of 3.5 m		
Angle of divergence		approx. 3 °		
Ambient light limit		40000 Lux		
Functional safety related para	meters			
MTTF <sub>d</sub>		1130 a		
Mission Time (T <sub>M</sub> )		20 a		
Diagnostic Coverage (DC)		60 %		
Indicators/operating means				
Operation indicator		Receiver: LED green, flashes in case of short-circuit Emitter:		
		LED green		
Function indicator		Receiver: LED yellow, lights up when light beam is free, flashes when falling short of the stability control		
Control elements		Receiver: Teach-In key		
Electrical specifications				
Operating voltage	$U_B$	10 30 V DC , class 2		
Ripple		max. 10 %		
No-load supply current	I <sub>0</sub>	Emitter: ≤ 17 mA Receiver: ≤ 15 mA		
Input				
Test input		emitter deactivation at +U <sub>B</sub>		
Output				
Switching type		dark on		
Signal output		1 NPN output, short-circuit protected, reverse polarity protected, open collector		
Switching voltage		max. 30 V DC		
Switching current		max. 100 mA		
Voltage drop	$U_d$	≤ 1.5 V DC		
Switching frequency	f	1000 Hz		
Response time		0.5 ms		
Conformity				
Product standard		EN 60947-5-2		
Ambient conditions				
Ambient temperature		-20 60 °C (-4 140 °F)		
Storage temperature		-40 75 °C (-40 167 °F)		
Mechanical specifications				
Housing width		23 mm		
Housing height		31 mm		
Housing depth		11 mm		
Degree of protection		IP67 / IP69K		
Connection		2 m fixed cable		
Material				
Housing		PC (glass-fiber-reinforced Makrolon)		
Optical face		PMMA		
Mass		approx. 100 g (emitter and receiver)		
Approvals and certificates				
Protection class		II, rated voltage ≤ 250 V AC with pollution degree 1-2 according to IEC 60664-1		
UL approval		cULus		

## **Accessories**

## Montagekit OMH-ML7-01

Mounting set consisting of bracket OMH-ML-01 sheet OMH-ML7-03, and fastening material

## Montagekit OMH-ML7-02

Mounting set consisting of bracket OMH-ML-02 sheet OMH-ML7-03, and fastening material

#### OMH-ML7-01

Mounting aid for ML7 and ML8 series, Mounting bracket

#### **OMH-ML7-02**

Mounting aid for ML7 and ML8 series, Mounting bracket

#### **OMH-ML7-03**


Mounting aid for ML7 and ML8 series, Fixing plate


Other suitable accessories can be found at www.pepperl-fuchs.com

CCC approval

CCC approval / marking not required for products rated ≤36 V

# **Curves/Diagrams**





# Teach-In

Connect the sensors to operating voltage, the green LEDs green lights up constantly.

The receiver operates at max. sensitivity (delivery status) or with the last teached values.

- Mount transmitter and receiver opposite each other and align roughly.
- Adjust the transmitter to the receiver.
- Press the Teach-In button on the receiver as an acknowledgement the green LED will quickly turn off one time.
- Press the Teach-In button on the receiver until both LEDs green and yellow are blinking in parallel (2 Hz). Release the Teach-In button now.
- While the green and yellow LEDs are blinking alternating (2 Hz) on the receiver the unit is in the internal set up procedure.
- Teach-In successful: Both LEDs green and yellow on the receiver are on. The unit is ready to use and in switching mode now.
- Teach-In not successful: Both LEDs on the receiver are flashing alternating (4 Hz) for approx. 5 seconds. Afterwards the sensor returns to max. sensitivity setting. Please retry the Teach-In procedure beginning by step 1.