

CE 🚷 IO-Link

## **Model Number**

# OQT400-R200-2EP-IO-V31

Triangulation sensor (SbR) with 4-pin, M8 x 1 connector

## **Features**

- Medium design with versatile • mounting options
- Multi Pixel Technology (MPT) -٠ flexibility and adaptability
- Reduction of device variety several • switch points within one sensor
- Reliable detection of all surfaces, independent of color and structure
- Low sensitivity to target color
- IO-link interface for service and process data

## **Product information**


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.


The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and

can be adapted to the application environment.



# **Electrical connection**





## Pinout



dance with EN 60947-5-2 (brown) (white) (blue) (black) BN BN BU BK

# Indicators/operating means





1	Mode rotary switch	
2	Teach-in button	
3	Switching output display Q2	YE
4	Switching output display Q1	YE
5	Operating indicator	GN

Q1B	Switching output 1/switch point B
Q1A	Switching output 1/switch point A
Q2A	Switching output 2/switch point A
Q2B	Switching output 2/switch point B
0	Keylock

295670-100123\_eng.xml 2019-10-31 Date of issue: Release date: 2018-07-27 10:13

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com <sup>5</sup> PEPPERL+FUCHS 1

Housing depth Degree of protection Connection Material Housing

Optical face

www.pepperl-fuchs.com

Mass

Technical data		Accessories					
General specifications	40 400 mm	IO-Link-Master02-USB					
Detection range	40 100 mm	IO-Link master, supply via USB port or					
Detection range min. Detection range max.	40 400 mm	separate power supply, LED indicators,					
0	40 400 mm	M12 plug for sensor connection					
Adjustment range Reference target	standard white, 100 mm x 100 mm						
Light source	LED	V31-GM-2M-PUR					
Light type	modulated visible red light	Female cordset single-ended, M8, 4-pin,					
LED risk group labelling	exempt group	PUR cable					
Black/White difference (6 %/90 %)	<5 %	V31-WM-2M-PUR					
		Female cordset single-ended, M8, 4-pin,					
Diameter of the light spot	approx. 15 mm at a distance of 400 mm	PUR cable					
Angle of divergence	approx. 2.5 °	OMH-MLV12-HWK					
Ambient light limit	EN 60947-5-2 : 70000 Lux	-					
Functional safety related parameters		Mounting bracket for series MLV12					
MTTFd	600 a	sensors					
Mission Time (T <sub>M</sub> )	20 a	OMH-R200-01					
Diagnostic Coverage (DC)	0 %						
Indicators/operating means		Mounting aid for round steel ø 12 mm or					
Operation indicator	LED green:	sheet 1.5 mm 3 mm					
	constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode	OMH-R20x-Quick-Mount Quick mounting accessory					
Function indicator	LED yellow:	, , , , , , , , , , , , , , , , , , ,					
	constantly on - switch output active constantly off - switch output inactive	OMH-MLV12-HWG Mounting bracket for series MLV12					
Control elements	Teach-In key	sensors					
Control elements	5-step rotary switch for operating modes selection						
Electrical specifications		Other suitable accessories can be found at					
Operating voltage U <sub>B</sub>	10 30 V DC	www.pepperl-fuchs.com					
Ripple	max. 10 %						
No-load supply current I <sub>0</sub>	< 25 mA at 24 V supply voltage						
Protection class	III						
Interface							
Interface type	IO-Link ( via C/Q = pin 4 )						
Device profile	Identification and diagnosis Smart Sensor type 0						
Transfer rate	COM 2 (38.4 kBaud)						
IO-Link Revision	1.1						
Min. cycle time	2.3 ms						
Process data witdh	Process data input 2 Bit Process data output 2 Bit						
SIO mode support	yes						
Device ID	0x111801 (1120257)						
Compatible master port type	A						
Output							
Switching type	The default setting is: C/Q - Pin4: NPN normally open, PNP normally closed, IO-Link Q2 - Pin2: NPN normally open, PNP normally closed						
Signal output	2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected						
Switching voltage	max. 30 V DC						
Switching current	max. 100 mA , resistive load						
Usage category	DC-12 and DC-13						
Voltage drop U <sub>d</sub>	≤ 1.5 V DC	ģ					
Switching frequency f	217 Hz						
Response time	2.3 ms						
Conformity							
Communication interface	IEC 61131-9	ă					
Product standard	EN 60947-5-2						
Ambient conditions							
Ambient temperature	-40 60 °C (-40 140 °F)						
Storage temperature	-40 70 °C (-40 158 °F)						
Mechanical specifications	· · · /						
Housing width	15 mm						
Housing height	50.6 mm						
Housing depth	41.7 mm						
Degree of protection	41.7 mm IP67 / IP69 / IP69K						
Connection	4-pin, M8 x 1 connector, 90° rotatable						
Material	י איז, איט א ד טטווופטנטו, שי וטומומטופ						
Material	PC (Polycorbonoto)	Ċ					

Date of issue: 2019-10-31 295670-100123\_eng.xml Release date: 2018-07-27 10:13

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

PC (Polycarbonate)

PMMA

approx. 35 g

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com


# **EPPERL+FUCHS**


2

## Approvals and certificates

UL approval CCC approval  $\label{eq:stability} E87056\ ,\ cULus\ Listed\ ,\ class\ 2\ power\ supply\ ,\ type\ rating\ 1\\ CCC\ approval\ /\ marking\ not\ required\ for\ products\ rated\ {$\le36$ V}$ 

## **Curves/Diagrams**





## Settings

### Teach-In (TI)

Use the rotary switch for switching signal Q1 or Q2 to select the relevant switching threshold A and/or B to teach in.

· The yellow LEDs indicate the current state of the selected output.

To teach in a switching threshold, press and hold the "TI" button for approximately 1 s, until the yellow and green LEDs flash in phase. Teach-in starts when the "TI" button is released.

- Teach-in successful: the yellow and green LEDs flash alternately at 2.5 Hz.
- Teach-in unsuccessful: the yellow and green LEDs quickly flash alternately at 8 Hz.


After an unsuccessful Teach-in, the sensor continues to operate with the previous valid setting after the relevant visual fault signal is issued.

Set switching mode: you can define different switching modes by teaching in the relevant distance data for switching thresholds A and B.


#### 1. Single point mode:

Pepperl+Fuchs Group

www.pepperl-fuchs.com



#### 2. Window mode:



Teach in switching thresholds: you can teach in or overwrite a taught-in switching threshold at any time. To do this, press the "TI" button again.

Reset a value: you can reset a taught-in value. To do this, press the "TI" button for > 4 s, until the yellow and green LEDs go out. The reset process itself starts when the "TI" button is released.

· Reset successful: the yellow and green LEDs flash alternately at 2.5 Hz.

#### **Resetting to Factory Settings**

To revert back to factory settings, press the "TI" button for > 10 s with the rotary switch set to position "O," until the yellow and green LEDs go out at the same time. The reset process itself starts when the "TI" button is released.

· Reset to factory settings successful: the yellow and green LEDs light up at the same time. The sensor then continues to operate with factory settinas.

OQT

- Factory setting for switching signal Q1:
- Switching signal high active, BGS mode (background suppression) · Factory setting for switching signal Q2:
- Switching signal high active, BGS mode (background suppression)

## **Configuration via IO-Link interface**

## Configuring different operating modes via the IO-Link interface

The devices are equipped with an IO-Link interface as standard for diagnostics and parameterization tasks to ensure optimum adjustment of the sensors to the relevant application. Four different operating modes can be set, among other features:

# Background suppression operating mode (one switch point):

• Detection of objects irrespective of type and color in a defined detection range. Objects in the background are suppressed.

			i	active d	letecti	on ran	ge			
_						. ,				Background suppression

#### Background evaluation operating mode (one switch point):

 Detection of objects irrespective of type and color against a defined background. Reliable detection of objects at close range (detection range) >= 0 mm). The background serves as reference.

active detection range	
	Background evaluation
Single point mode operating mode (one switch point).	

## Single point mode operating mode (one switch point):

- Detection of objects irrespective of type and color in a defined detection range. Objects in the background are suppressed.
- The switch point corresponds exactly to the set point.



## Window mode operating mode (two switch points):

- Detection of objects irrespective of type and color in a defined detection range. Reliable detection when object leaves the detection range.
- · Window mode with two switch points.

active detection range

Background suppression

## Center window mode operating mode (one switch point):

Foreground suppression **Background suppression** · Detection of objects irrespective of type and color in a defined detection range. Sets a defined window around a given object. Objects outside this window are not detected.

Window mode with one switch point.




Foreground suppression

**Background suppression** 

# Two point mode operating mode (hysteresis operating mode):

• Detection of objects irrespective of type and color between a defined switch-on and switch-off point.

	Refer to "General Notes Rela	ting to Pepperl+Fuchs Product Inform	ation".		
4	Pepperl+Fuchs Group www.pepperl-fuchs.com	USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com	Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com	Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com	EPPPERL+FUCHS



Inactive operating mode:

• Evaluation of switching signals is deactivated.

The associated IODD device description file can be found in the download area at www.pepperl-fuchs.com.