

CE **OIO**-Link

Model Number

OBT300-R103-EP-IO-0,3M-V3

Triangulation sensor (BGS) with fixed cable and 3-pin, M8 connector

Features

- Miniature design with versatile • mounting options
- Best background suppressor in its ٠ class
- Precision object detection, almost • irrespective of the color
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and process data


Product information

The R103 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.




Electrical connection



Pinout



Indicators/operating means



1	Light-on/dark-on changeover switch
2	Sensing range adjuster
3	Operating indicator / dark on
4	Function indicator
5	Operating indicator / light on

Date of issue: 2018-06-08 Release date: 2018-06-08 14:39

eng.xml

267075-100267_

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



OBT300-R103-EP-IO-0,3M-V3

Technical data			
General specifications			
Detection range			
Detection range min.			
Detection range max.			
Adjustment range			
Reference target			
Light source			

LED risk group labelling

Diameter of the light spot

Diagnostic Coverage (DC)

Indicators/operating means

Angle of divergence

Ambient light limit

Mission Time (T_M)

Operation indicator

Function indicator

Control elements

Control elements

Protection class

Interface type

Device profile

Transfer rate **IO-Link Revision**

Min. cycle time

Process data witdh

SIO mode support Device ID

Compatible master port type

Ripple

Interface

Output Switching type

Signal output

Switching voltage

Switching current

Usage category

Switching frequency

Communication interface

Voltage drop

Response time

Product standard Ambient conditions

Ambient temperature

Storage temperature Mechanical specifications Housing width Housing height

Housing depth Degree of protection Connection Material Housing Optical face

www.pepperl-fuchs.com

Conformity

Electrical specifications Operating voltage

No-load supply current

Black/White difference (6 %/90 %)

Functional safety related parameters

Light type

MTTF_d

5 ... 300 mm 5 ... 25 mm 5 ... 300 mm 25 ... 300 mm standard white, 100 mm x 100 mm LED modulated visible red light exempt group < 15 % at 300 mm approx. 18 mm at a distance of 300 mm approx. 3 EN 60947-5-2 : 40000 Lux

600 a 20 a 0%

UR

10

Ud

f

LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode LED yellow: constantly on - object detected constantly off - object not detected Light-on/dark-on changeover switch Sensing range adjuster

10 ... 30 V DC max. 10 % < 25 mA at 24 V supply voltage ш

IO-Link (via C/Q = pin 4) Smart Sensor COM 2 (38.4 kBaud) 1.1 2.3 ms Process data input 1 Bit Process data output 2 Bit 0x110604 (1115652) А

The switching type of the sensor is adjustable. The default setting is: C/Q - Pin4: NPN normally open / light-on, PNP normally closed / dark-on, IO-Link

1 push-pull (4 in 1) output, short-circuit protected, reverse polarity protected, overvoltage protected max. 30 V DC max. 100 mA , resistive load DC-12 and DC-13 \leq 1.5 V DC 500 Hz 1 ms IEC 61131-9 EN 60947-5-2

-40 ... 60 °C (-40 ... 140 °F) , fixed cable -25 ... 60 °C (-13 ... 140 °F) , movable cable not appropriate for conveyor chains -40 ... 70 °C (-40 ... 158 °F)

15 mm
36.5 mm
26.7 mm
IP67 / IP69 / IP69K
300 mm fixed cable with M8 x 1, 3-pin connector
PC (Polycarbonate)
PMMA

Accessories

IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

V3-WM-2M-PUR Cable socket, M8, 3-pin, PUR cable

OMH-R103-01 Mounting bracket

V31-GM-2M-PUR Female cordset, M8, 4-pin, PUR cable

V31-WM-2M-PUR Female cordset, M8, 4-pin, PUR cable

OMH-R101-Front Mounting Clamp

OMH-R101 Mounting Clamp

OMH-4.1 Mounting Clamp

OMH-ML6 Mounting bracket

OMH-ML6-U Mounting bracket

OMH-ML6-Z Mounting bracket

Other suitable accessories can be found at www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

approx. 17 g

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

Mass

Cable length


0.3 m


Approvals and certificates


UL approval

E87056 , cULus Listed , class 2 power supply , type rating 1

Curves/Diagrams








USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





Functions and Operation



- 1 Light-on / dark-on changeover switch
- 2 Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster / sensitivity adjuster for more than 180 degrees.

Sensing Range/ Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range / sensitivity adjuster for more than 180 degrees.

