



## **Model Number**

# OBT350-R101-EP-IO-V3-1T

Triangulation sensor (BGE) with fixed cable and 3-pin, M8 connector

### **Features**


- Miniature design with versatile • mounting options
- Precision object detection, almost ٠ irrespective of the color
- Extended temperature range • -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and process data

# **Product information**

The miniature optical sensors are the first devices of their kind to offer an end-to- end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.




## **Electrical connection**







# Indicators/operating means



	1	Light-on/dark-on changeover switch	
	2 Sensing range adjuster		
	3	Operating indicator / dark on	
	<ul><li>4 Signal indicator</li><li>5 Operating indicator / light on</li></ul>		

eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Technical data				
General specifications				
Detection range		5 350 mm		
Detection range min.		5 25 mm		
Detection range max.		5 350 mm		
Adjustment range		25 350 mm		
Reference target		standard white, 100 mm x 100 mm		
Light source		LED		
Light type		modulated visible red light		
LED risk group labelling		exempt group		
Black/White difference (6 %/90 %)		< 15 % at 350 mm		
Diameter of the light spot		approx. 20 mm at a distance of 350 mm		
Angle of divergence		approx. 3 °		
Ambient light limit		EN 60947-5-2 : 40000 Lux		
Functional safety related parame	ters			
MTTFd		600 a		
Mission Time (T <sub>M</sub> )		20 a		
Diagnostic Coverage (DC)		0 %		
Indicators/operating means				
Operation indicator		LED green: constantly on - power on		
		flashing (4Hz) - short circuit		
		flashing with short break (1 Hz) - IO-Link mode		
Function indicator		LED yellow:		
		constantly on - background detected (object not detected) constantly off - object detected		
Control elements		Light-on/dark-on changeover switch		
Control elements		Sensing range adjuster		
Electrical specifications				
Operating voltage	U <sub>B</sub>	10 30 V DC		
Ripple	СВ	max. 10 %		
No-load supply current	lo	< 25 mA at 24 V supply voltage		
Protection class	.0	III		
Interface				
Interface type		IO-Link ( via C/Q = pin 4 )		
Device profile		Smart Sensor		
Transfer rate		COM 2 (38.4 kBaud)		
IO-Link Revision		1.1		
Min. cycle time		2.3 ms		
Process data witdh		Process data input 1 Bit		
		Process data output 2 Bit		
SIO mode support		yes		
Device ID		0x110701 (1115905)		
Compatible master port type		A		
Output				
Switching type		The switching type of the sensor is adjustable. The default setting is:		
		C/Q - Pin4: NPN normally open / dark-on, PNP normally closed /		
		light-on, IO-Link		
Oirmal autaut				
Signal output		1 push-pull (4 in 1) output, short-circuit protected, reverse polarity protected, overvoltage protected		
Switching voltage		max. 30 V DC		
Switching current		max. 100 mA , resistive load		
Usage category		DC-12 and DC-13		
Voltage drop	Ud	≤ 1.5 V DC		
Switching frequency	f	500 Hz		
Response time		1 ms		
Conformity				
Communication interface		IEC 61131-9		
Product standard		EN 60947-5-2		
Ambient conditions				
Ambient temperature		-40 60 °C (-40 140 °F)		
<b>0</b>				
Storage temperature -40 70 °C (-40 158 °F)				
Mechanical specifications				
Housing width		13.9 mm		
Housing height		41.4 mm		
Housing depth		18.3 mm		
Degree of protection Connection		IP67 / IP69 / IP69K M8 x 1 connector 3-pin		
Material		M8 x 1 connector, 3-pin		
Housing		PC (Polycarbonate)		
Optical face		PMMA		
Mass		approx. 10 g		
11/1/200				

# Accessories

IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

V3-WM-2M-PUR Cable socket, M8, 3-pin, PUR cable

V31-GM-2M-PUR Female cordset, M8, 4-pin, PUR cable

V31-WM-2M-PUR Female cordset, M8, 4-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com

#### Approvals and certificates

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

2

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




#### UL approval

E87056, cULus Listed, class 2 power supply, type rating 1



## **Functions and Operation**



- 1 Light-on / dark-on changeover switch
- 2 Sensing range /sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster for more than 180 degrees.

## Sensing Range / Sensitivity

Turn sensing range / sensivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range /sensivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

## Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on / dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

## **Restore Factory Settings**

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensivity adjustment is locked. In order to reactivate the sensing range / sensivity adjustment, turn the sensing range / sensivity adjuster for more than 180 degrees.

