31





# **Model Number**

# ML100-8-HW-350-RT/95/102


Triangulation sensor (BGE) with 4-pin, M8 x 1 connector

#### **Features**


- User-friendliest photoelectric sensor • series for standard applications
- Miniature design ٠
- Background evaluation uses back-• ground as reference for detection of difficult targets
- Simplest alignment and commissio-٠ ning thanks to ultrabright transmitter LED
- Clear and functional display concept for the operating modes
- Full metal thread mounting ٠

#### **Product information**

The ML100 series is characterized by its miniature housing with integral, all-metal threaded bushings. All versions are equipped with a visible red transmitter LED. This greatly simplifies installation and commissioning. The switching states are easily visible from all directions thanks to the highly visible LEDs.



### **Electrical connection**




# Pinout



### Indicators/operating means

<sup>2</sup><sub>1</sub> 3



1	Light-Dark-switching		
2	Detection range adjuster		
3	Signal display	yellow	
4	Operating display	green	



Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

Technical data			Accessories	
General specifications			OMH-ML100-03	
Detection range		5 350 mm	Mounting aid for round steel ø 12 mm or	
Adjustment range		30 350 mm		
Light source		LED	sheet 1.5 mm 3 mm	
Light type		modulated visible red light	OMH-ML100-04	
Diameter of the light spot		approx. 20 mm at a distance of 350 mm	Mounting aid for ML100 series, Mounting bracket	
Angle of divergence		approx. 4 °		
Optical face		frontal	Diacket	
Ambient light limit		EN 60947-5-2:2007+A1:2012	OMH-ML100-05	
Functional safety related parameters			Mounting aid for ML100 series, Mounting	
MTTF <sub>d</sub>		860 a	bracket	
Mission Time (T <sub>M</sub> )		20 a	brachet	
Diagnostic Coverage (DC)		0 %	OMH-F10-ML100	
Indicators/operating means			Mounting aid for ML100 series	
Operation indicator		LED green: power on		
Function indicator		LED yellow ON: sensor detects background	OMH-10	
Control elements		Sensing range adjuster	Mounting aid	
Control elements		Light-on/dark-on changeover switch	V31-GM-2M-PUR	
Electrical specifications				
Operating voltage	UB	10 30 V DC	Female cordset, M8, 4-pin, PUR cable	
Ripple	- D	max. 10 %	V31-WM-2M-PUR	
No-load supply current	I <sub>0</sub>	< 20 mA	Female cordset, M8, 4-pin, PUR cable	
Output	0			
Switching type		The switching type of the sensor is adjustable. The default set- ting is: light on	OMH-ML100-S1 Mounting bracket	
Signal output		1 NPN output, short-circuit protected, reverse polarity protected, open collector	OMH-ML100-08	
Switching voltage		max. 30 V DC	Mounting aid for ML100 series, Snap-in	
Switching current		max. 100 mA , resistive load	Other witchle according and he found at	
Voltage drop	U <sub>d</sub>	≤ 1.5 V DC	Other suitable accessories can be found at	
Switching frequency	f	500 Hz	www.pepperl-fuchs.com	
Response time		1 ms		
Ambient conditions				
Ambient temperature		-30 60 °C (-22 140 °F)		
Storage temperature		-40 70 °C (-40 158 °F)		
Mechanical specifications				
Degree of protection		IP67		
Connection		connector M8 x 1 , 4-pin		
Material				
Housing		PC (Polycarbonate)		
Optical face		PMMA		
Mass		approx. 10 g		
Tightening torque, fastening screws		0.6 Nm		
Compliance with standards and ves	l directi	-		
Directive conformity				
EMC Directive 2004/108/EC		EN 60947-5-2:2007+A1:2012		
Standard conformity				
Standards		UL 60947-5-2		
Approvals and certificates				

UL approval

with a limited voltage output with (maybe integrated) fuse (max. 3.3 A according UL248), Type 1 enclosure CCC approval / marking not required for products rated ≤36 V

cULus Listed, Class 2 Power Source or listed Power Supply

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

www.pepperl-fuchs.com


2

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

PEPPERL+FUCHS

# **Curves/Diagrams**



# Notes

- 1. Set up the sensor to the background object.
- 2. Rotate the detection range adjuster clockwise until the yellow LED turns ON.
- Continue to rotate the detection range adjuster clockwise until the yellow LED turns OFF. З.
- 4. Now counter-clockwise rotate the detection range adjuster just until the yellow LED turns ON again.

Preferably the background should be light or white.

Object should move transversely to the sensor.

The background should not vary in height.

