



 $\epsilon$ 





#### **Model Number**

#### OBT650-R201-EP-IO-V3-1T

Triangulation sensor (BGE) with 3-pin, M8 x 1 connector

#### **Features**

- Medium design with versatile mounting options
- Secure and gapless detection, even near the surface through background evaluation
- Precision object detection, almost irrespective of the color
- Extended temperature range -40°C ... 60°C
- · High degree of protection IP69K
- IO-link interface for service and process data

# **Product information**


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design—from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and can be adapted to the application environment.

# **Dimensions**



### **Electrical connection**




### **Pinout**

Wire colors in accordance with EN 60947-5-2



BN (brown BU (blue) BK (black)

## Indicators/operating means



1	Sensitivity adjustment		
2	2 Light-on / dark-on changeover switch		
3	Operating indicator / dark on		
4	4 Signal indicator		
5	Operating indicator / light on		



Technical data		
General specifications		
Detection range		10 650 mm
Detection range min.		10 100 mm
Detection range max.		10 650 mm
Adjustment range		100 650 mm
Reference target		standard white, 100 mm x 100 mm
Light source		LED
Light type		modulated visible red light
LED risk group labelling  Black/White difference (6 %/90 %)		exempt group < 6 % at 650 mm
Diameter of the light spot		approx. 20 mm x 20 mm at a distance of 650 mm
Angle of divergence		approx. 2°
Ambient light limit		EN 60947-5-2 : 70000 Lux
Functional safety related parame	ters	
MTTF <sub>d</sub>		600 a
Mission Time (T <sub>M</sub> )		20 a
Diagnostic Coverage (DC)		0 %
Indicators/operating means		
Operation indicator		LED green:
		constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode
Function indicator		LED yellow: constantly on - background detected (object not detected)
Control place and		constantly off - object detected
Control elements		Light-on/dark-on changeover switch
Control elements		Sensing range adjuster
Cherating voltage	U <sub>R</sub>	10 30 V DC
Operating voltage Ripple	OB	max. 10 %
No-load supply current	I <sub>0</sub>	< 25 mA at 24 V supply voltage
Protection class	U	III
Interface		
Interface type		IO-Link ( via C/Q = pin 4 )
Device profile		Identification and diagnosis
		Smart Sensor type 2.4
Transfer rate		COM 2 (38.4 kBaud)
IO-Link Revision		1.1 2.3 ms
Min. cycle time Process data witdh		2.3 ms Process data input 1 Bit
SIO mode support		Process data output 2 Bit yes
Device ID		0x111711 (1120017)
Compatible master port type		Α
Output		
Switching type		The switching type of the sensor is adjustable. The default
		setting is: C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link
Signal output		1 push-pull (4 in 1) output, short-circuit protected, reverse polarity protected, overvoltage protected
Switching voltage		max. 30 V DC
Switching current		max. 100 mA , resistive load
Usage category Voltage drop	U <sub>d</sub>	DC-12 and DC-13 ≤ 1.5 V DC
Switching frequency	o <sub>d</sub>	500 Hz
Response time		1 ms
Conformity		
Communication interface		IEC 61131-9
Product standard		EN 60947-5-2
Ambient conditions		
Ambient temperature		-40 60 °C (-40 140 °F)
Storage temperature		-40 70 °C (-40 158 °F)
Mechanical specifications		
Housing width		15 mm
Housing height		61.7 mm
Housing depth		41.7 mm
Degree of protection		IP67 / IP69 / IP69K
Connection		Connector plug, M8 x 1, 3 pin, rotatable by 90°
Material Housing		PC (Polycarbonate)
		1 0 (1 diyourbonato)
		PMMA
Optical face Mass		PMMA approx. 44 g

### **Accessories**

### IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

### OMH-RL31-02

Mounting bracket narrow

### OMH-RL31-03

Mounting bracket narrow

### OMH-RL31-04

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

# OMH-RL31-07

Mounting bracket including adjustment

#### **OMH-R20x-Quick-Mount**

Quick mounting accessory

#### V3-WM-2M-PUR

Female cordset single-ended, M8, 3-pin, PUR cable

#### V3-GM-2M-PUR


Female cordset single-ended, M8, 3-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com



UL approval E87056 , cULus Listed , class 2 power supply , type rating 1
CCC approval CCC approval / marking not required for products rated ≤36 V

## Minimum object height



To unlock the adjustment functions, rotate the sensing range/sensitivity adjuster by more than 180°.

#### Sensing Range/Sensitivity

To increase the sensing range/sensitivity, rotate the sensing range/sensitivity adjuster clockwise.

To reduce the sensing range/sensitivity, rotate the sensing range/sensitivity adjuster counter-clockwise.

As soon as the end of the adjustment range is reached, the signal indicator flashes at 8 Hz.

### Configuring Light On/Dark On

Press the light-on/dark-on changeover switch for more than 1 second (but less than 4 seconds). "Light on/dark on" mode changes and the relevant operating indicator lights up.

If you press the light-on/dark-on changeover switch for longer than 4 seconds, the "light on/dark on" mode will switch back to the original setting. The current status is activated when the light-on/dark-on changeover switch is released.

### **Restoring Factory Settings**

Press the light-on/dark-on changeover switch for more than 10 seconds (but less than 30 seconds) until all LEDs go out. When the light-on/dark-on changeover switch is released, the signal indicator lights up. After 5 seconds, the sensor resumes operation with the factory settings.

The adjustment functions are locked after 5 minutes of inactivity. To unlock the adjustment functions, rotate the sensing range/sensitivity adjuster again by more than 180°.