

Model Number

OMT600-R200-IEP-IO-0,3M-V1-L

Distance sensor

with fixed cable and M12 connector, 4-pin

Features

- Medium design with versatile • mounting options
- Space-saving distance sensors in ٠ small standardized design
- Multi Pixel Technology (MPT) exact • and precise signal evaluation
- IO-link interface for service and process data
- Analog output 4 ... 20 mA

Product information


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and can be adapted to the application

environment.



Electrical connection




Pinout



dance with EN 60947-5-2 (brown) (white) (blue) (black) BN BN BU BK

Indicators/operating means




Q

0

m

8



Q1B	Switching output/switch point B
Q1A	Switching output/switch point A
Q2A	Analog output/value A
Q2B	Analog output/value B
0	Keylock

295670-100306_eng.xml Release date: 2019-07-01 10:57

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

⁵ PEPPERL+FUCHS 1

Technical data

General specifications 100 ... 600 mm Measurement range Reference target Light source Light type Laser nominal ratings Note Laser class Wave length Beam divergence Pulse length Repetition rate max. pulse energy Angle deviation Diameter of the light spot Angle of divergence Ambient light limit Resolution Functional safety related parameters MTTF_d 20 a Mission Time (T_M) Diagnostic Coverage (DC) 0% Indicators/operating means Operation indicator Function indicator **Control elements** Control elements Electrical specifications Operating voltage UB Ripple No-load supply current I_0 Protection class Interface Interface type Device profile Transfer rate **IO-Link Revision** Min. cycle time Process data witdh SIO mode support Device ID Compatible master port type Output Switching type Signal output Switching voltage Switching current Usage category Ud Voltage drop Response time Analog output Output type

standard white, 100 mm x 100 mm laser diode modulated visible red light LASER LIGHT, DO NOT STARE INTO BEAM 680 nm > 5 mrad, d63 < 2,8 mm in the range of 350 mm ... 800 mm 5.5 us approx. 2.4 kHz <40 nJ max. +/- 1.5 ° approx. 3 mm at a distance of 600 mm approx. 0.3 EN 60947-5-2 : 15000 Lux 0.1 mm 470 a

LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode LED yellow: constantly on - switch output active constantly off - switch output inactive Teach-In key 5-step rotary switch for operating modes selection

18 ... 30 V DC max. 10 % < 18 mA at 24 V supply voltage

10
IO-Link (via C/Q = pin 4)
Identification and diagnosis Smart Sensor type 0/type 3.3
COM 2 (38.4 kBaud)
1.1
3 ms
Process data input 4 byte Process data output 2 bits
yes
0x111908 (1120520)
A
The default setting is: C/Q - Pin4: NPN normally open, PNP normally closed, IO-Link I—Pin2: analog output 420 mA
1 push-pull output , 1 analog output , short-circuit-proof, reverse polarity protection, surge-proof
max. 30 V DC
max. 100 mA , resistive load
DC-12 and DC-13
\leq 1.5 V DC
2 ms
1 current output: 4 20 mA
> 1 k Ω voltage output ; \leq 470 Ω current output
2 ms
IEC 61131-9
EN 60947-5-2
EN 60825-1:2014
0.05 %/K
5 min
<1 %
0.75 %

Laserlabel

LASER IEC 60825-1:2014

Accessories

V1-G-2M-PUR Female cordset, M12, 4-pin, PUR cable

V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

OMH-MLV12-HWK

Mounting bracket for series MLV12 sensors

OMH-R200-01

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

OMH-R20x-Quick-Mount Quick mounting accessory

OMH-MLV12-HWG

Mounting bracket for series MLV12 sensors

Other suitable accessories can be found at www.pepperl-fuchs.com

10 ... 50 °C (50 ... 122 °F)

Germany: +49 621 776 1111 fa-info@us.pepperl-fuchs.com fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

Load resistor Recovery time Conformity

Laser safety Measurement accuracy Temperature drift Warm up time Repeat accuracy Linearity error

Ambient conditions Ambient temperature

Communication interface Product standard

Storage temperature	-40 70 °C (-40 158 °F)	
Mechanical specifications		
Housing width	15 mm	
Housing height	50.6 mm	
Housing depth	41.7 mm	
Degree of protection	IP67 / IP69 / IP69K	
Connection	300 mm fixed cable with M12 x 1, 4-pin connector	
Material		
Housing	PC (Polycarbonate)	
Optical face	PMMA	
Mass	approx. 45 g	
Cable length	0.3 m	
Approvals and certificates		
UL approval	E87056 , cULus Listed , class 2 power supply , type rating 1	
CCC approval	CCC approval / marking not required for products rated ≤36 V	
FDA approval	IEC 60825-1:2014 Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007	

Settings

Teach-In (TI)

Use the rotary switch for switching signal Q1 to select the relevant switching threshold A and/or B to teach in.

· The yellow LEDs indicate the current state of the selected output.

To teach in a switching threshold, press and hold the "TI" button for approximately 1 s, until the yellow and green LEDs flash in phase. Teach-in starts when the "TI" button is released.


Teach-in successful: the yellow and green LEDs flash alternately at 2.5 Hz.

Teach-in unsuccessful: the yellow and green LEDs quickly flash alternately at 8 Hz.


After an unsuccessful Teach-in, the sensor continues to operate with the previous valid setting after the relevant visual fault signal is issued.

Set switching mode: you can define different switching modes by teaching in the relevant distance data for switching thresholds A and B.

1. Single point mode:



2. Window mode:



Teach in switching thresholds: you can teach in or overwrite a taught-in switching threshold at any time. To do this, press the "TI" button again.

Reset a value: you can reset a taught-in value. To do this, press the "TI" button for > 4 s, until the yellow and green LEDs go out. The reset process itself starts when the "TI" button is released.

Reset successful: the yellow and green LEDs flash alternately at 2.5 Hz.

Minimum and maximum values for the analog output Q2 are taught in and deleted in the same way as those for the switching output.

The following applies:

A = Minimum voltage/current

B = Maximum voltage/current

Resetting to Factory Settings

To revert back to factory settings, press the "TI" button for > 10 s with the rotary switch set to position "O," until the yellow and green LEDs go out at the same time. The reset process itself starts when the "TI" button is released.

Reset to factory settings successful: the yellow and green LEDs light up at the same time. The sensor then continues to operate with factory settings.

OMT-IEP

- · Factory setting for switching signal Q1:
- Switching signal is high active, window mode
- · Analog output: current output, 4 mA ... 20 mA absolute mode

OMT-UEP

- Factory setting for switching signal Q1: Switching signal is high active, window mode
- Analog output: voltage output, 0 V ... 10 V absolute mode

Analog output

The analog output type can be configured as voltage or current output via IO-Link.

The following output types are available:

- Analog output 0 mA ...20 mA
- Analog output 4 mA ...20 mA
- Analog output 0 V ...10 V

The following operating modes are available:


- Absolute mode (default setting)
- Normalized mode
- Rising slope
- Falling slope

The following substitute values can optionally be configured:


- No substitute values used (default setting)
- · Substitute value for "no measured value" used
- · Substitute value for "no measured value" and "Measuring overrange" used

The sensor's tolerances are based on the digital process data.


Absolute mode (default setting, A and B = deleted)



Normal mode (A and B without teach-in / deleted)







fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com


EPPERL+FUCHS

fa-info@us.pepperl-fuchs.com

4

www.pepperl-fuchs.com

Falling slope (A > B)



Configuration via IO-Link interface

Setting different operating modes via the IO-Link interface

The devices are equipped with an IO-Link interface as standard for diagnostics and parameterization tasks to ensure optimum adjustment of the sensors to the relevant application.

Single point mode operating mode (one switch point):

- "Detection of objects irrespective of type and color in a defined detection range. Objects in the background are suppressed.
- "The switch point corresponds exactly to the set point.

active detection range	
	Background suppression

Window mode operating mode (two switch points):

- Detection of objects irrespective of type and color in a defined detection range. Reliable detection when object leaves the detection range.
- Window mode with two switch points.

c	cive detection range
Foreground suppression	Background suppression

detection

Center window mode operating mode (one switch point):

- Detection of objects irrespective of type and color in a defined detection range. Sets a defined window around a given object. Objects outside this window are not detected.
- Window mode with one switch point.

Release date: 2019-07-01 10:57 Date of issue: 2019-10-31 295670-100306 end.xml

www.pepperl-fuchs.com

active	detec	ction	range	
Foreground suppression				Background suppression

Two point mode operating mode (hysteresis operating mode):

fa-info@us.pepperl-fuchs.com

• Detection of objects irrespective of type and color between a defined switch-on and switch-off point.

	active detection range		
		Output	_
Output	Hysteresis		
la setta se su sta su setta su se se se se			
Inactive operating mode: • Evaluation of switching signals is deactivation	ted.		
The associated IODD device description	file can be found in the dowr	nload area at www.peppe	rl-fuchs.com
Refer to "General Notes Relating to Pepperl+Fuchs Product In	formation".		
Popport Euclos Group LISA: 1 220 486 0001	Gormony: 140 621 776 1111	Singaporo: (65.6770.0001	c

fa-info@de.pepperl-fuchs.com

fa-info@sg.pepperl-fuchs.com