# OBR7500-R100-2EP-IO-0,3M-V1

**Dimensions** 



c(Ul CE **OIO**-Link US

## **Model Number**

# OBR7500-R100-2EP-IO-0,3M-V1

Retroreflective sensor

with fixed cable and M12 connector, 4-pin

#### **Features**

- Miniature design with versatile • mounting options
- Extended temperature range ٠ -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and • process data


# **Product information**

The R100 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.




## **Electrical connection**







# Indicators/operating means



USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



UB

In

 $U_{d}$ 

**Technical data** General specifications Effective detection range

Reflector distance

Reference target Light source

Polarization filter

Angle of divergence

Ambient light limit

Function indicator

Control elements

Control elements

Ripple

Interface Interface type

Parameterization indicator **Electrical specifications** Operating voltage

No-load supply current

Protection class

Transfer rate

**IO-Link Revision** 

Process data witdh

SIO mode support

Compatible master port type

Device ID

Output Switching type

Min. cycle time

Light type

MTTF<sub>d</sub> Mission Time (T<sub>M</sub>)

Threshold detection range

LED risk group labelling

Diameter of the light spot

Diagnostic Coverage (DC) Indicators/operating means Operation indicator

Functional safety related parameters

OBR7500-R100-2EP-IO-0.3M-V1

	Accessories
0 7.5 m 0.03 7.5 m 10 m	IO-Link-Master02-USB IO-Link master, supply via USB p separate power supply, LED indi
H85-2 reflector LED	M12 plug for sensor connection V1-G-2M-PUR
modulated visible red light exempt group	Female cordset, M12, 4-pin, PUF
yes approx. 65 mm at a distance of 1 m 3.7 °	V1-W-2M-PUR Female cordset, M12, 4-pin, PUF
EN 60947-5-2	OMH-R10X-01 Mounting bracket
724 a 20 a 0 %	OMH-R10X-02 Mounting bracket
LED green: constantly on - power on	OMH-R10X-04 Mounting bracket
flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode Yellow LED:	OMH-R10X-10 Mounting bracket
Permanently lit - light path clear Permanently off - object detected Flashing (4 Hz) - insufficient operating reserve Light-on/dark-on changeover switch sensitivity adjustment	<b>OMH-ML100-03</b> Mounting aid for round steel ø 12 sheet 1.5 mm 3 mm
IO link communication: green LED goes out briefly (1 Hz)	OMH-ML100-031 Mounting aid for round steel ø 10 14 mm or sheet 1 mm
max. 10 % < 25 mA at 24 V supply voltage	<b>REF-H85-2</b> Reflector, rectangular 84.5 mm x
III IO-Link ( via C/Q = pin 4 )	84.5 mm, mounting holes
COM 2 (38.4 kBaud) 1.1	<b>REF-H50</b> Reflector, rectangular 51 mm x 6
2.3 ms Process data input 2 Bit	mounting holes, fixing strap OFR-100/100
Process data output 2 Bit yes	Reflective tape 100 mm x 100 mi
0x110201 (1114625) A	REF-H33 Reflector with screw fixing
The switching type of the sensor is adjustable. The default setting is: C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link	<b>REF-VR10</b> Reflector, rectangular 60 mm x 1 mounting holes
/Q - Pin2: NPN normally closed / light-on, PNP normally open / dark-on 2 push-pull (4 in 1)outputs, short-circuit protected, reverse	<b>V31-GM-2M-PUR</b> Female cordset, M8, 4-pin, PUR
polarity protected, overvoltage protected max. 30 V DC max. 100 mA , resistive load	V31-WM-2M-PUR Female cordset, M8, 4-pin, PUR
DC-12 and DC-13 ≤ 1.5 V DC	Other suitable accessories can be
1000 Hz 0.5 ms	www.pepperl-fuchs.com
IEC 61131-9 EN 60947-5-2	
-40 60 °C (-40 140 °F) , fixed cable -25 60 °C (-13 140 °F) , movable cable not appropriate for conveyor chains -40 70 °C (-40 158 °F)	
11 mm 37.1 mm	
21.5 mm	
IP67 / IP69 / IP69K	
300 mm fixed cable with M12 x 1, 4-pin connector	
PC (Polycarbonate) PMMA	
approx. 21 g	

port or dicators,

**JR** cable

JR cable

2 mm or

. 5 mm

61 mm,

19 mm,

R cable

R cable

e found at

# Signal output

Switching voltage Switching current Usage category Voltage drop Switching frequency Response time

Conformity

Communication interface Product standard

Ambient conditions Ambient temperature

Storage temperature **Mechanical specifications** 

Housing width Housing height Housing depth Degree of protection Connection Material Housing Optical face

www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

Mass

# Cable length


0.3 m


#### Approvals and certificates

UL approval


E87056 , cULus Listed , class 2 power supply , type rating 1

# **Curves/Diagrams**





#### **Functions and Operation**



- 1 Light-on / dark-on changeover switch
- 2 Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

## Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

## Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





# **Restore Factory Settings**

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.



4