



 $\epsilon$ 





# **Model Number**

## OBG8000-R200-2EP-IO-V15

Retroreflective sensor (glass) with 5-pin, M12 x 1 connector

# **Features**

- Medium design with versatile mounting options
- Detects transparent objects, i.e., clear glass, PET and transparent films
- Two machines in one: clear object detection or reflection operating mode with long range
- High degree of protection IP69K
- IO-link interface for service and process data

# **Product information**


The optical sensors in the series are the first devices to offer an end-to-end solution in a medium-sized standard design-from the thru-beam sensor through to the measuring distance sensor. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard

Multi Pixel Technology (MPT) ensures that the standard sensors are flexible and can be adapted to the application environment.

# **Dimensions**



# **Electrical connection**




# **Pinout**

Wire colors in accordance with EN 60947-5-2



BN WH BU BK	(brown (white) (blue)
BK	(black)
GY	(gray)

# Indicators/operating means



0	
L/D	Ν
	I

1	Mode rotary switch	
2	Teach-in button	
3	Operating indicator/dark-on	GN
4	Function indicator	YE
5	Operating indicator/light-on	GN

N	Normal operation	
I	10 % contrast detection	
Ш	18 % contrast detection	
Ш	40 % contrast detection	
L/D	Switching type	
0	Keylock	

## **Accessories**

### IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

### V15-W-2M-PUR

Female cordset, M12, 5-pin, PUR cable

## V15-G-2M-PUR

Female cordset, M12, 5-pin, PUR cable

#### V1-G-2M-PUR

Female cordset, M12, 4-pin, PUR cable

## V1-W-2M-PUR

Female cordset, M12, 4-pin, PUR cable

#### RFF-H85-2

Reflector, rectangular 84.5 mm x 84.5 mm, mounting holes

#### REF-C110-2

Reflector, round ø 84 mm, central mounting hole

#### FE-RR1

Reflector, round ø 80.87 mm, central mounting hole

### REF-VR10

Reflector, rectangular 60 mm x 19 mm, mounting holes

## OFR-100/100

Reflective tape 100 mm x 100 mm

### REF-H32G-2

# REF-ORR50G-2

### **OMH-MLV12-HWK**

Mounting bracket for series MLV12 sensors

## OMH-R200-01

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

## **OMH-R20x-Quick-Mount**

Quick mounting accessory

# **OMH-MLV12-HWG**

Mounting bracket for series MLV12 sensors

Other suitable accessories can be found at www.pepperl-fuchs.com

eng.xml 149 295670-100

Storage temperature

Housing width

Housing height

Housing depth

**Mechanical specifications** 

15 mm


50.6 mm


41.7 mm

-40 ... 70 °C (-40 ... 158 °F)

Degree of protection	IP67 / IP69 / IP69K	
Connection	5-pin, M12 x 1 connector, 90° rotatable	
Material		
Housing	PC (Polycarbonate)	
Optical face	PMMA	
Mass	approx. 37 g	
Cable length	0.3 m	
Approvals and certificates		
UL approval	E87056, cULus Listed, class 2 power supply, type rating 1	
CCC approval	CCC approval / marking not required for products rated ≤36 V	

# **Curves/Diagrams**





## Settings

Date of issue: 2019-10-31

Release date: 2019-02-11 10:56

Use the rotary switch to select the required operating mode: Normal mode (N) or contrast level I - III.

To teach in a threshold or activate an operating mode, press the "TI" button until the yellow and green LEDs flash in phase (approx. 1 s).

Release the "TI" button. Teach-in starts.

Successful teach-in is indicated by alternating flashing (2.5 Hz) of the yellow and green LEDs. The sensor will now operate in the selected operating mode with the taught-in threshold.

An unsuccessful teach-in is indicated by rapidly alternating flashing (8 Hz) of the yellow and green LEDs. After an unsuccessful teach-in, the sensor continues to operate with the previous valid setting after the relevant visual fault signal is issued.

Every taught-in switching threshold can be re-taught (overwritten) by pressing the "TI" button again.

Note: To ensure that the device functions reliably in Contrast mode, the device must be powered on at least 30 s before Teach-in.

Setting the Device to Maximum Sensitivity

Use the rotary switch to select the Normal mode (N) position.

Press the "TI" button for > 4 s. The yellow and green LEDs will go out.

Release the "TI" button.

The settings will be reset to maximum sensitivity. After successfully resetting, the yellow and green LEDs will flash alternately (2.5 Hz).

Switching between light on/dark on

Use the rotary switch to select the light on/dark on (L/D) position.

Press the "TI" button for > 1 s.

The respective operating indicator LED (L/D) will illuminate green and the switching type will change.

To reset the switching type, press the "TI" button for > 4 s.

The respective operating indicator LED (L/D) will illuminate green and the operating indicator will be reset to the most recently active switching type.

## **Reset to Default Settings**

Use the rotary switch to select the O position.

Press the "TI" button for > 10 s. The yellow and the green LEDs will both switch off.

Release the "TI" button. The yellow LED is on.

After resetting, the sensor will operate with the following default settings:

- Normal mode (N)
- Maximum sensitivity adjustment
- Dark on
- Pin 2 (white core): antivalent switching output

**5**PEPPERL+FUCHS