Distance sensor



CE 🚷 IO-Link

Model Number

OMT200-R101-2EP-IO

Distance sensor with fixed cable

Features


- Miniature design •
- MPT Multi Pixel Technology •
- IO-link interface for service and ٠ process data

Product information


The miniature optical sensors are the first devices of their kind to offer an end-to- end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.


The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.



Electrical connection



Indicators/operating means



2	Mode rotary switch
3	Switch output indicator Q2
4	Switch output indicator Q1
5	Operating indicator

Ι	Switch output 1 / switch point B
Ш	Switch output 1 / switch point A
Ш	Switch output 2 / switch point A
IV	Switch output 2 / B
V	Keylock

Pepperl+Fuchs Group

www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Technical data			İ
General specifications			Ľ
Measurement range		60 200 mm	
Reference target		standard white, 100 mm x 100 mm	
Light source		LED	
Light type		modulated visible red light	
LED risk group labelling		exempt group	
Angle deviation		max. +/- 1.5 °	
Diameter of the light spot		approx. 12 mm at a distance of 200 mm 4 °	
Angle of divergence Ambient light limit		4 EN 60947-5-2 : 30000 Lux	
Resolution		0.1 mm	
Functional safety related parame	eters		
MTTF _d		600 a	
Mission Time (T _M)		20 a	
Diagnostic Coverage (DC)		0 %	
Indicators/operating means			
Operation indicator		LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode	
Function indicator		LED yellow: constantly on - switch output active constantly off - switch output inactive	
Control elements		Teach-In key	
Control elements		5-step rotary switch for operating modes selection	
Electrical specifications	11	10 30 V DC	
Operating voltage Ripple	UB	max. 10 %	
No-load supply current	I ₀	< 25 mA at 24 V supply voltage	
Protection class	.0		
Interface			
Interface type		IO-Link (via C/Q = pin 4)	
Device profile		Smart Sensor	
Transfer rate		COM 2 (38.4 kBaud)	
IO-Link Revision		1.1	
Min. cycle time		3 ms	
Process data witdh SIO mode support		Process data input 3 Byte Process data output 2 Bit yes	
Device ID		0x110905 (1116421)	
Compatible master port type		A	
Output			
Switching type		The default setting is: C/Q - BK: NPN normally open, PNP normally closed, IO-Link Q2 - WH: NPN normally open, PNP normally closed	
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse polarity protected, overvoltage protected	
Switching voltage		max. 30 V DC	
Switching current		max. 100 mA , resistive load	
Usage category		DC-12 and DC-13	
Voltage drop	U _d	≤ 1.5 V DC	
Response time		2 ms	
Conformity Communication interface		IEC 61131-9	
Product standard		EN 60947-5-2	
Measurement accuracy		····· • • •	
Temperature drift		0.05 %/K	
Repeat accuracy		≤1 %	
Linearity error		±1%	
Ambient conditions			
Ambient temperature		10 60 °C (50 140 °F)	
Storage temperature		-40 70 °C (-40 158 °F)	
Mechanical specifications			
Housing width		13.9 mm	
Housing height		41.4 mm 18.3 mm	
Housing depth Degree of protection		18.3 mm IP67 / IP69 / IP69K	
Connection		2 m fixed cable	
Material			
Housing		PC (Polycarbonate)	
Optical face		PMMA	
Mass		approx. 36 g	
Cable length		2 m	
Approvals and certificates			

Female cordset, M8, 4-pin, PUR cable

Accessories

V31-GM-2M-PUR

V31-WM-2M-PUR Female cordset, M8, 4-pin, PUR cable IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection Other suitable accessories can be found at www.pepperl-fuchs.com

> Date of issue: 2018-12-17 267075-100206_eng.xml Release date: 2018-12-17 14:07

Approvals and certificates

Pepperl+Fuchs Group www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



E87056, cULus Listed, class 2 power supply, type rating 1

UL approval

Preferences

Teach-In:

You can use the rotary switch to select the relevant switching threshold A and/or B for teaching in for switch signal Q1 or Q2.

The yellow LEDs indicate the current state of the selected output.

To store a threshold value, press and hold the "TI" button until the yellow and green LEDs flash in phase (approx. 1 s). Teach-In starts when the "TI" button is released.

Successful Teach-In is indicated by alternating flashing (2.5 Hz) of the yellow and green LEDs.


An unsuccessful Teach-In is indicated by rapidly alternating flashing (8 Hz) of the yellow and green LEDs.

After an unsuccessful Teach-In, the sensor continues to operate with the previous valid setting after the relevant visual fault signal is issued.

Different switching modes can be defined by teaching in the relevant distance measured values

for the switching thresholds A and B:

Single point mode:



Window mode:



Every taught-in switching threshold can be retaught (overwritten) by pressing the "TI" button again.

Pressing and holding the "TI" button for > 4 s completely deletes the taught-in value. The yellow and green LEDs go out simultaneously to indicate that this procedure has been completed. Successful resetting is indicated by alternating flashing (2.5 Hz) of the yellow and green LEDs.

Resetting to Factory Default Settings

Press the ",TI" button for > 10 s in rotary switch position ',O' to reset to factory default settings. The yellow and green LEDs go out simultaneously to indicate the resetting.

Resetting process starts when the "TI" button is released and is indicated by the yellow LED. After the process the sensor works with factory default settings, immediately.

OMT:

- Factory default settings switch signal Q1: Switch signal active, window mode
- Factory default settings switch signal Q2:
- Switch signal active, window mode

OQT:

ena.xml

00206

267075-1

Date of issue: 2018-12-17

Release date: 2018-12-17 14:07

- Factory default settings switch signal Q1:
- Switch signal active, BGS mode (background suppression)
- Factory default settings switch signal Q2: Switch signal active, BGS mode (background suppression)

Configuration via IO-Link interface

Setting different operating modes via the IO-Link interface

The devices are equipped with an IO-Link interface as standard for diagnostics and parameterization tasks to ensure optimum adjustment of the sensors to the relevant application.

Single point mode operating mode (one switch point):

- "Detection of objects irrespective of type and color in a defined detection range. Objects in the background are suppressed.
- "The switch point corresponds exactly to the set point.

active detection range

			ground ression
•	ng mode (two switch points	•	
 Detection of objects irresp Window mode with two sv 	5.	etection range. Reliable detect	ion when object leaves the detection range
	active detection range		
Foreground suppre	ssion	Background suppression	
Center window mode	operating mode (one switch	n point):	
 Detection of objects irresp 	ective of type and color in a defined d	etection range. Sets a defined v	window around a given object. Objects outs

• Detection of objects irrespective of type and color in a defined detection range. Sets a defined window around a given object. Objects outside this window are not detected.

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 G

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



• Window mode with one switch point.


active	detection	range

Foreground suppression

Background suppression

Two point mode operating mode (hysteresis operating mode):

• Detection of objects irrespective of type and color between a defined switch-on and switch-off point.



Inactive operating mode:

• Evaluation of switching signals is deactivated.

The associated IODD device description file can be found in the download area at www.pepperl-fuchs.com.

